

LENNOX[®]

INSTALLATION
OPERATING &
MAINTENANCE MANUAL



PROVIDING **GLOBAL SYSTEM SOLUTIONS**

ROOFTOP
FLEXY™

English
July 2004



INSTALLATION OPERATION MAINTENANCE MANUAL

Ref. FLEXY_IOM/0704-E

The present manual applies to the following ROOFTOP versions :

FCA 85 - FCA 100 - FCA 120 - FCA 140 - FCA 160 - FCA 190
FCK 85 - FCK 100 - FCK 120 - FCK 140 - FCK 160 - FCK 190
FHA 85 - FHA 100 - FHA 120 - FHA 140 - FHA 160 - FHA 190
FHK 85 - FHK 100 - FHK 120 - FHK 140 - FHK 160 - FHK 190
FDA 85 - FDA 100 - FDA 120 - FDA 140 - FDA 160 - FDA 190
FDK 85 - FDK 100 - FDK 120 - FDK 140 - FDK 160 - FDK 190
FGA 85 - FGA 100 - FGA 120 - FGA 140 - FGA 160 - FGA 190
FGK 85 - FGK 100 - FGK 120 - FGK 140 - FGK 160 - FGK 190

FXA 25 - FXA 30 - FXA 35 - FXA 40 - FXA 55 - FXA 70 - FXA 85 - FXA 100 - FXA 110 - FXA 140 - FXA 170
FXK 25 - FXK 30 - FXK 35 - FXK 40 - FXK 55 - FXK 70 - FXK 85 - FXK 100 - FXK 110 - FXK 140 - FXK 170

NOTES FOR UNIT FITTED WITH GAS BURNER :

THE UNIT MUST BE INSTALLED IN ACCORDANCE WITH LOCAL SAFETY CODES AND REGULATIONS AND CAN ONLY BE USED IN WELL VENTILLATED AREA.

PLEASE READ CAREFULLY THE MANUFACTURER'S INSTRUCTIONS BEFORE STARTING THIS UNIT.

THIS MANUAL IS ONLY VALID FOR UNITS DISPLAYING THE FOLLOWING CODES:

GB	IR	GR	DA	NO	FI	IS
----	----	----	----	----	----	----

In case these symbols are not displayed on the unit, please refer to the technical documentation which will eventually detail any modifications required to the installation of the unit in a particular country.



CONTENTS

IMPORTANT NOTICE	3
INSTALLATION	
TRANSPORT - HANDLING	4
INSTALLATION	12
INSTALLATION ON A ROOF MOUNTING FRAME	13
INSTALLATION ON POSTS	15
COMMISSIONING	16
OPERATION	
VENTILATION	21
AIR FLOW BALANCING	23
FILTERS	39
FANSTART OPERATION	40
FX AIR FLOW BALANCING	41
HOT WATER COILS	44
GAS BURNERS	45
CONTROL FUNCTIONS	
USING THE KP 17 COMFORT DISPLAY	57
USING THE KP02 MAINTENANCE DISPLAY	58
USING THE KP07 REMOTE GRAPHICAL DISPLAY	72
BMS CONTACTS KIT	81
CLIMATIC™ PARAMETERS	82
CONTROL INTERFACE CLIMALINK/CLIMALOOK	88
WIRING DIAGRAMS	
ELECTRICAL WIRING DIAGRAMS LIST OF ITEMS	96
ELECTRICAL WIRING DIAGRAMS	100
TROUBLESHOOTING	
SAFETY AND ERROR CODES	117
MAINTENANCE DIAGNOSTIC	123
MAINTENANCE PLAN	126
WARRANTY	129
CERTIFICATES	
ISO 9001 CERTIFICATION	130
PED CERTIFICATION OF CONFORMITY	131
GLAS WOOL FIRE CLASS	132
33 KW GAS BURNER CE CERTIFICATION OF CONFORMITY	133
60 KW GAS BURNER CE CERTIFICATION OF CONFORMITY	134
120 KW GAS BURNER CE CERTIFICATION OF CONFORMITY	135
180 kW GAS BURNER CE CERTIFICATION OF CONFORMITY	136
INSULATION FIRE CLASS	137

IMPORTANT NOTICE

All work on the unit must be carried out by a qualified and authorised employee.

Non-compliance with the following instructions may result in injury or serious accidents.

Work on the unit:

- The unit shall be isolated from the electrical supply by disconnection and locking using the main isolating switch.
- Workers shall wear the appropriate personal protective equipment (helmet, gloves, glasses, etc.).

Work on the electrical system:

- Work on electric components shall be performed with the power off (see below) by employees having valid electrical qualification and authorisation.

Work on the refrigerating circuit(s):

- Monitoring of the pressures, draining and filling of the system under pressure shall be carried out using connections provided for this purpose and suitable equipment.
- To prevent the risk of explosion due to spraying of coolant and oil, the **relevant circuit shall be drained and at zero pressure** before any disassembly or unbrazing of the refrigerating parts takes place.
- There is a residual risk of pressure build-up by degassing the oil or by heating the exchangers after the circuit has been drained. **Zero pressure shall be maintained** by venting the drain connection to the atmosphere on the low pressure side.
- The brazing shall be carried out by a qualified brazer. The brazing shall comply with standard NF EN1044 (minimum 30% silver).

Replacing components:

- In order to maintain CE marking compliance, replacement of components shall be carried out using spare parts, or using parts approved by Lennox.
- Only the coolant shown on the manufacturer's nameplate shall be used, to the exclusion of all other products (mix of coolants, hydrocarbons, etc.).

CAUTION:

In the event of fire, refrigerating circuits can cause an explosion and spray coolant gas and oil.



Site details / Informations site		Controller/ Contrôleur
Site / Site	Model/Model	Serial No/ No Série
Unit Ref/ N° Affaire	Refrigerant / Réfrigérant	
Installer/ Installateur		

(1) ROOF INSTALLATION / INSTALLATION SUR LE TOIT

Sufficient Access OK / Accès Suffisants Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Condensate drain fitted / Drainage condensats Installé Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Roofcurb / Costière OK <input type="checkbox"/> Not OK/PasOK <input type="checkbox"/>
--	---	--

(2) CONNECTIONS CHECK / VERIFICATIONS DE RACCORDEMENTS

Phase check/ Vérification des Phases Yes / Oui <input type="checkbox"/> No / Non <input type="checkbox"/>	Voltage between Phases Tension entre Phases	1 / 2	2 / 3	1 / 3
--	--	-------------	-------------	-------------

(3) CLIMATIC CONFIGURATION CHECK / VERIFIER LA CONFIGURATION CLIMATIC

CLIMATIC 50 Configured according to the Options and Specifications / CLIMATIC 50 configuré en fonction des options et des spécifications: Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>
--

(4) SUPPLY BLOWER SECTION / VENTILATION TRAITEMENT

Type / Type:		N°1	N°2
Power displayed on plate / Puissance affichée sur la plaque:	KW
Voltage displayed on plate / Tension affichée sur la plaque:	V
Current displayed on plate / Intensité affichée sur la plaque:	A
Fan Type / Type de Ventilateur:		Forward / Action <input type="checkbox"/> Backward / Réaction <input type="checkbox"/>	Forward / Action <input type="checkbox"/> Backward / Réaction <input type="checkbox"/>
Displayed Belt Length / Longueur Courroie affichée:	mm
Tension Checked/ Tension Vérifiée:		Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>
Alignment Checked / Alignement Vérifié:		Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>
Motor Pulley Dia/ Poulie Moteur Dia: D _M	mm
Fan Pulley Dia/ Poulie Ventilateur Dia: D _P	mm
Fan Speed / Vitesse rotation Ventilateur = Motor rpm x D _M / D _P	rpm
Averaged Measured Amps / Intensité Mesurée moyenne:	A
Shaft Mechanical Power (Refer to airflow balancing) Puissance Mécanique à l'Arbre (Voir section réglage débit)	W
Operating point checked / Vérif. Point de fonctionnement:		Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>
Estimated Airflow / Estimation Débit d'Air	m ³ /h

(5) AIRFLOW PRESS. SENSOR CHECK / VERIF. DES SECURITES PRESSOSTATS D'AIR

Measured pressure drop / Pertes de charge au pressostat mbar	Set Points Adjusted / Changement des consignes: Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/> If Yes enter new values/ Si oui noter les nouvelles consignes: 3410: 3411: 3412:
---	---

(6) EXTERNAL SENSOR CHECKS / VERIFICATION DES CAPTEURS EXTERNES

Check electrical connections / Vérification des connexions électriques: Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Check and record temp. in menu 2110 / Vérifier et mesurer les températures. Dans menu 2110: Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	
	100% Fresh Air / 100% Air neuf	100% return Air / 100% Air repris
Supply Temperature / Température Soufflage°C°C
Return Temperature / Température reprise°C°C
Outdoor Temperature / Température extérieure°C°C

(7) MIXING AIR DAMPERS CHECKS / VERIFICATIONS VOILETS DE MELANGE

Dampers open & close freely/ Volets s'ouvrent et se ferment OK Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	% Minimum FA: %minimum Air Neuf:%	Power exhaust checked/ Ventilateur extraction Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Enthalpy sensor(s) checked/ Control enthalpie installé Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>
--	---	---	--



(8) REFRIGERATION SECTION / SECTION REFRIGERATION

Outdoor Fan Motor Current / Intensité Moteurs Batterie externe:				Check Rotation	Compressor Voltage/ Tension Compresseur.
Motor 1 / Moteur 1	L1A	L2A	L3A	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	
Motor 2 / Moteur 2	L1A	L2A	L3A	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	
Motor 3 / Moteur 3	L1A	L2A	L3A	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	
Motor 4 / Moteur 4	L1A	L2A	L3A	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	
Motor 5 / Moteur 5	L1A	L2A	L3A	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	
Motor 6 / Moteur 6	L1A	L2A	L3A	Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	

Compressor Amps COOLING / Intensité Compresseur MODE FROID				Pressures & Temperatures / Pressions & températures			
	Phase 1	Phase 2	Phase 3	Temperatures / Temperatures		Pressures / Pressions	
				Suction/ Asp	Disch / refoul	LP/ BP	HP / HP
Comp 1 A A A °C °C Bar Bar
Comp 2 A A A °C °C Bar Bar
Comp 3 A A A °C °C Bar Bar
Comp 4 A A A °C °C Bar Bar

Check Reversing valves./ Vérifier vannes d'inversion: Valve1/Vanne1: Yes/Oui No/ Non Valve2/Vanne2: Yes/Oui No/ Non Valve3/Vanne3: Yes/Oui No/ Non Valve4/Vanne4: Yes/Oui No/ Non

Compressor Amps HEATING / Intensité Compresseur en Pompe à Chaleur				Pressures & Temperatures / Pressions & températures			
	Phase 1	Phase 2	Phase 3	Temperatures / Temperatures		Pressures / Pressions	
				Suction/ Asp	Disch / refoul	LP/ BP	HP / HP
Comp 1 A A A °C °C Bar Bar
Comp 2 A A A °C °C Bar Bar
Comp 3 A A A °C °C Bar Bar
Comp 4 A A A °C °C Bar Bar
HP cut out / Coupure HP				LP cut out / Coupure sécurité BP			
Refrigerant charge / Charge réfrigérant				C1 :kg	C2 :kg	C3 :kg	C4 :kg

(8) ELECTRIC HEATER SECTION / SECTION RECHAUFFEUR ELECTRIQUE

Type / Type:	Serial No/ No Série:.....
AMPS 1 st stage (Baltic) / Intensité 1 ^{er} étage (Baltic)	AMPS 2 nd stage (Baltic) / Intensité 2 ^e étage (Baltic)
1	2
2	3
3	1
1	2
2	3

(9) HOT WATER COIL SECTION / SECTION BATTERIE EAU CHAUDE

Check Three Way Valve Movement / Vérification Mouvement Vanne trois voies: Yes/Oui No/ Non

(10) GAS HEATING SECTION / RAMPE GAZ

Gas Burner N°1 / Brûleur gaz N°1				Gas Burner N°2 / Brûleur gaz N°2			
Size / Taille:	Valve type / Type vanne:			Size / Taille:	Valve type / Type vanne:		
Pipe size/ tuyauterie:	Gas type / Type gas : G			Pipe size/ tuyauterie	Gas type / Type gas : G		
Line press./ press. ligne :	Drop test / test pression Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>			line press./ press. ligne :	Drop test / test pression Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>		
Check manifold pressure/ Pression injection: High fire/Grande allure..... Low fire/Petite allure.....				Check manifold pressure/ Pression injection: High fire/Grande allure..... Low fire/Petite allure.....			
Pressure cut out airflow press switch / Pression coupure pressostat débit d'air :mbar /Pa				Pressure cut out airflow press switch / Pression coupure pressostat débit d'air :mbar /Pa			
Motor amps I moteur:A	Flue temp / temp fumées °C	CO2 %:%	CO ppm:%	Motor Amps I Moteur:A	Flue temp / temp fumées °C	CO2 %:%	CO ppm:%

(11) REMOTE CONTROL BMS CHECK / VERIFICATIONS BMS CONTROL A DISTANCE

Type / Type:	Sensor type / Type Capteur	KP07 KP/17 checked/ vérifiées: Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>	Interconnect wiring checked: Yes/Oui <input type="checkbox"/> No/ Non <input type="checkbox"/>
--------------	----------------------------	--	--



It is recommended that you fill the two tables below before transferring the zone settings to the Climatic controller.
 Il est recommandé de remplir les deux tableaux ci-dessous avant de transférer les consignes de zones vers le contrôleur Climatic50.

Refer to control section page 55 / Se référer à la section régulation page 55

Time Zones / Zones Horaires

Hour	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23
<i>Example</i>	UNO							7h15 ZA			11h00 ZB			14h00 ZC			19h00 UNO							
Monday																								
Tuesday																								
Wednesday																								
Thursday																								
Friday																								
Saturday																								
Sunday																								

Variables to adjust for each time zone / Consignes à renseigner pour chaque zone horaire

	Start z.A		Start z.B		Start z.C		Start UNO	
	hour (3211)	min (3212)	hour (3213)	min (3214)	hour (3215)	min (3216)	hour (3217)	min (3218)
Monday								
Tuesday								
Wednesday								
Thursday								
Friday								
Saturday								
Sunday								

Description	Unit	Menu	Min	Max	Zone A	Zone B	Zone C	UNOC
Sp Room	°C	3311	8	35				
Mini.Air	%	3312	0	100				
Sp Dyna	°C	3321	0	99.9				
Sp Cool	°C	3322	8	35				
Sp Heat	°C	3323	8	35				
Swap Heater	On/Off	3324	~	~				
Activation	On/Off	3331	~	~				
Swap Heater	On/Off	3332	~	~				
Sp.Dehu	%	3341	0	100				
Sp.Humi	%	3342	0	100				
Fan On/Off	On/Off	3351	~	~				
Fan Dead	On/Off	3352	~	~				
F.Air	On/Off	3353	~	~				
CO2	On/Off	3354	~	~				
Comp.Cool.	On/Off	3355	~	~				
Comp.Heat.	On/Off	3356	~	~				
AuxHeat	On/Off	3357	~	~				
Humidif.	On/Off	3358	~	~				
Low Noise	On/Off	3359	~	~	N/A	N/A	N/A	

DELIVERY CHECKS

On receipt of a new equipment please check the following points. It is the customer's responsibility to ensure that the products are in good working order:

- The exterior has not been damaged in any way.
- The lifting and handling equipment are suitable for the equipment and comply with the specifications of the handling instructions enclosed here-in.
- Accessories ordered for on site installation have been delivered and are in good working order.
- The equipment supplied corresponds to the order and matches the delivery note.

If the product is damaged, exact details must be confirmed in writing by registered post to the shipping company within 48 hours of delivery (working days). A copy of the letter must be addressed to Lennox and the supplier or distributor for information purposes. Failure to comply will invalidate any claim against the shipping company.

RATING PLATE

The rating plate provides a complete reference for the model and ensures that the unit corresponds to the model ordered. It states the electrical power consumption of the unit on start-up, its rated power and its supply voltage. The supply voltage must not deviate beyond +10/-15 %. The start-up power is the maximum value likely to be achieved for the specified operational voltage. The customer must have a suitable electrical supply. It is therefore important to check whether the supply voltage stated on the unit's rating plate is compatible with that of the mains electrical supply. The rating plate also states the year of manufacture as well as the type of refrigerant used and the required charge for each compressor circuit.

LENNOX		CE 0062		Usine Higon S.I.L LONGVIC 21600 LONGVIC FRANCE	
TYPE	FHK 085 N2N3M	Usage Climatisation			
UNIT TYPE					
N° SERIE	220891_1 / 1	ANNEE	2004		
SERIAL NUMBER		YEAR			
ALIMENTATION	400	V	3	~	50 Hz
ELEC. SUPPLY					
I. MAXI	55.9	I. DEMARR.	143	A	C. COMMANDE
MAX AM ²		START UP AMF.			CONTRO. CIR.
					24 V
REFRIGERANT	R407C	kg / CIRCUIT			
FLUIDE Groupe 2		12.1	12.1	0	0
		C1	C2	C3	C4
Date d'épreuve	Pression max (PT) déclenchement: pressostat HP				29.3 bar
27/01/2003	Maximum working pressure (FT)				
Temp maxi stockage	50 °C	Temp mini stockage	-35 °C		
Maximum storage temp		Min mum storage temp			

STORAGE

When units are delivered on site they are not always required immediately and are sometimes put into storage. In the event of medium to long-term storage, we recommend the following procedures :

- Ensure that there is no water in the hydraulic systems.
- Keep the heat exchanger covers in position (AQUILUX cover).
- Keep protective plastic film in position.
- Ensure the electrical panels are closed.
- Keep all items and options supplied in a dry and clean place for future assembly before using the equipment.

MAINTENANCE KEY

On delivery we recommend that you keep the key which is attached to an eyebolt in a safe and accessible place. This allows you to open the panels for maintenance and installation work.

The locks are ¼ turn + then tighter (figure 2).




Fig. 1

CONDENSATE DRAINS

The condensate drains are not assembled when delivered and are stored

in the electrical panel with their clamping collars.

To assemble them, insert them on the condensate tray outlets and use a screwdriver to tighten the collars (Figure 3).



Figure 2



DIMENSIONS AND WEIGHTS

Condensation		Airflow configuration								LENGTH (mm)	WIDTH (mm)	HEIGHT (mm)	HOOD (mm)	WEIGHT (kg)			SLING		
Standard	Centrifugal	1	2	3	4	5	6	7	8					std	std gas	high gas	1	2	3
FC/FH 085 - Cooling only and heat pump																			
X	-	X	-	-	-	-	-	-	X	3785	2255	1495	630	1220	-	-	2830	2330	-
X	-	-	-	-	X	-	-	X	-	3785	2255	1495	630	1270	-	-	2830	2330	-
X	-	-	X	X	-	X	X	-	-	3785	2285	1495	630	1275	-	-	2830	2330	-
-	X	X	-	-	-	-	-	-	X	3835	2255	2080	630	1435	-	-	3230	2430	1870
-	X	-	-	-	X	-	-	X	-	3835	2255	2080	630	1485	-	-	3230	2430	1870
-	X	-	X	X	-	X	X	-	-	3835	2285	2080	630	1490	-	-	3230	2430	1870
FC/FH 085 - GAS																			
X	-	X	-	-	-	-	-	-	X	3785	2255	1495	630	-	1320	1390	2830	2330	-
-	X	X	-	-	-	-	-	-	X	3835	2255	2080	630	-	1535	1605	3230	2430	1870
FC/FH 100 - Cooling only and heat pump																			
X	-	X	-	-	-	-	-	-	X	3785	2255	1495	630	1280	-	-	2830	2330	-
X	-	-	-	-	X	-	-	X	-	3785	2255	1495	630	1320	-	-	2830	2330	-
X	-	-	X	X	-	X	X	-	-	3785	2285	1495	630	1320	-	-	2830	2330	-
-	X	X	-	-	-	-	-	-	X	3835	2255	2080	630	1495	-	-	3230	2430	1870
-	X	-	-	-	X	-	-	X	-	3835	2255	2080	630	1545	-	-	3230	2430	1870
-	X	-	X	X	-	X	X	-	-	3835	2285	2080	630	1545	-	-	3230	2430	1870
FC/FH 100 - GAS																			
X	-	X	-	-	-	-	-	-	X	3785	2255	1495	630	-	1380	1450	2830	2330	-
-	X	X	-	-	-	-	-	-	X	3835	2255	2080	630	-	1595	1665	3230	2430	1870



DIMENSIONS AND WEIGHTS

Condensation		Airflow configuration								LENGTH (mm)	WIDTH (mm)	HEIGHT (mm)	CASQUETTE (mm)	WEIGHT (kg)			SLING		
Standard	Centrifugal	1	2	3	4	5	6	7	8					std	std gas	high gas	1	2	3
FC/FH 120 - Cooling only and heat pump																			
X	-	X	-	-	-	-	-	-	X	3585	2255	1470	630	1530	-	-	2700	-	2080
X	-	-	-	-	X	-	-	X	-	3585	2255	1470	630	1580	-	-	2700	-	2080
X	-	-	X	X	-	X	X	-	-	3585	2285	1470	630	1600	-	-	2700	-	2080
-	X	X	-	-	-	-	-	-	X	3635	2255	1930	630	1805	-	-	3000	2410	1880
-	X	-	-	-	X	-	-	X	-	3635	2255	1930	630	1855	-	-	3000	2410	1880
-	X	-	X	X	-	X	X	-	-	3635	2285	1930	630	1875	-	-	3000	2410	1880
FG 120 - GAS																			
X	-	X	-	-	-	-	-	-	X	4035	2255	1470	630	-	1840	1890	3000	-	2310
-	X	X	-	-	-	-	-	-	X	4085	2255	1930	630	-	2115	2165	3300	2700	2080
FC/FH 140 - Cooling only and heat pump																			
X	-	X	-	-	-	-	-	-	X	3585	2255	1470	630	1630	-	-	2700	-	2080
X	-	-	-	-	X	-	-	X	-	3585	2255	1470	630	1680	-	-	2700	-	2080
X	-	-	X	X	-	X	X	-	-	3585	2285	1470	630	1700	-	-	2700	-	2080
-	X	X	-	-	-	-	-	-	X	3635	2255	1930	630	1905	-	-	3000	2410	1880
-	X	-	-	-	X	-	-	X	-	3635	2255	1930	630	1955	-	-	3000	2410	1880
-	X	-	X	X	-	X	X	-	-	3635	2285	1930	630	1975	-	-	3000	2410	1880
FG 140 - GAS																			
X	-	X	-	-	-	-	-	-	X	4035	2255	1470	630	-	1920	1970	3000	-	2310
-	X	X	-	-	-	-	-	-	X	4085	2255	1930	630	-	2000	2050	3300	2700	2080
FC/FH 160 - Cooling only and heat pump																			
X	-	X	-	-	-	-	-	-	X	3595	2255	2070	900	2050	-	-	2700	-	2090
X	-	-	-	-	X	-	-	X	-	3595	2255	2070	900	2120	-	-	2700	-	2090
X	-	-	X	X	-	X	X	-	-	3595	2285	2070	900	2140	-	-	2700	-	2090
-	X	X	-	-	-	-	-	-	X	3645	2255	2070	900	2275	-	-	2700	-	2090
-	X	-	-	-	X	-	-	X	-	3645	2255	2070	900	2345	-	-	2700	-	2090
-	X	-	X	X	-	X	X	-	-	3645	2285	2070	900	2365	-	-	2700	-	2090
FG 160 - GAS																			
X	-	X	-	-	-	-	-	-	X	4045	2255	2070	900	-	2410	2460	3000	-	2320
-	X	X	-	-	-	-	-	-	X	4095	2255	2070	900	-	2635	2685	3000	-	2320
FC/FH 190 - Cooling only and heat pump																			
X	-	X	-	-	-	-	-	-	X	3595	2255	2070	900	2175	-	-	2700	-	2090
X	-	-	-	-	X	-	-	X	-	3595	2255	2070	900	2245	-	-	2700	-	2090
X	-	-	X	X	-	X	X	-	-	3595	2285	2070	900	2265	-	-	2700	-	2090
-	X	X	-	-	-	-	-	-	X	3645	2255	2070	900	2400	-	-	2700	-	2090
-	X	-	-	-	X	-	-	X	-	3645	2255	2070	900	2470	-	-	2700	-	2090
-	X	-	X	X	-	X	X	-	-	3645	2285	2070	900	2490	-	-	2700	-	2090
FG 190 - GAS																			
X	-	X	-	-	-	-	-	-	X	4045	2255	2070	900	-	2540	2600	3000	-	2320
-	X	X	-	-	-	-	-	-	X	4095	2255	2070	900	-	2765	2825	3000	-	2320



DIMENSIONS AND WEIGHTS



MODELS	LENGTH mm	HEIGHT mm	WIDTH mm	AUVENT		WEIGHT (kg) standard kg
				lateral mm	ventil mm	
FX 025	4070	1635	1055	490	600	950
FX 030	4070	1635	1055	490	600	980
FX 035	4750	2255	1290	490	600	1400
FX 040	4750	2255	1290	490	600	1450
FX 055	4750	2255	1290	490	600	1600
FX 070	5050	2255	1725	890	600	1800
FX 085	5050	2255	1725	890	600	1900
FX 100	5050	2255	1725	890	600	2000
FX 110	5650	2255	2000	860	-	2620
FX 140	5650	2255	2000	860	-	2620
FX 170	5650	2255	2000	860	-	2650

HANDLING

The equipment can be moved using the lifting holes on the top of the unit.
The "sling" length is the value that we recommend for safe handling of the equipment.

Some units can only be supported by four slings at right-angles. Others require different lengths (see figures 4).
It is essential that all lifting holes are used and that the slings are all of the same size to avoid damaging the equipment.



Figure for all handling drawings



FC.../FH.../FD... 120 & 140

Sling length = 2700 mm
for angle = 45°C


Sling length = 2080 mm
for angle = 45°C




FC.../FH.../FD... 120 & 140 with centrifugal fans

Sling length = 3000 mm
for angle = 45°C

Sling length = 2410 mm
for angle = 45°C





Sling length = 1880 mm
for angle = 45°C



FG... 120 & 140 with gas burner

Sling length = 2700 mm
for angle = 45°C


Sling length = 2080 mm
for angle = 45°C




FG... 120 & 140 with gas burner and centrifugal fans

Sling length = 3300 mm
for angle = 45°C

Sling length = 2700 mm
for angle = 45°C





Sling length = 2080 mm
for angle = 45°C



**FC.../FH.../FD... 160 & 190
FC.../FH.../FD... 160 & 190 with centrifugal fans**

Sling length = 2700 mm
for angle = 45°C



Sling length = 2090 mm
for angle = 45°C



**FG... 160 & 190
FG... 160 & 190 with centrifugal fans**


Sling length = 3000 mm
for angle = 45°C

Sling length = 2320 mm
for angle = 45°C




FX 25 & 30

Sling length 1 = 3000 mm
Sling length 2 = 2350 mm




FX 35 - 40 - 55

Sling length 1 = 3700 mm
Sling length 2 = 2850 mm




FX 70 - 85 - 100

Sling length 1 = 3900 mm
Sling length 2 = 3000 mm



FX 110 - 140 - 170

Sling length 1 = 4300 mm
Sling length 2 = 3250 mm



PRELIMINARY CHECK

Before installing the equipment, the following points MUST be checked :

- Have the forklift protections been removed ?
- Is there sufficient space for the equipment?
- Is the surface on which the equipment is to be installed sufficiently solid to withstand its weight? A detailed study of the frame must be made beforehand.
- Do the supply and return ductwork openings excessively weaken the structure?
- Are there any obstructing items which could hinder the operation of the equipment?
- Does the electrical power available correspond to the equipment's electrical specifications?
- Is drainage provided for the condensate?
- Is there sufficient access for maintenance?
- Installation of the equipment could require different lifting methods which may vary with each installation (helicopter or crane). Have these been evaluated ?
- Ensure that the unit is installed in accordance with the installation instructions and local applicable codes.
- Check to ensure that the refrigerant lines do not rub against the cabinet or against other refrigerant lines.

In general, make sure no obstacles (walls, trees or roof ledges) are obstructing the duct connections or hindering assembly and maintenance access.

INSTALLATION REQUIREMENTS

The surface on which the equipment is to be installed must be clean and free of any obstacles which could hinder the flow of air to the condensers:

- Avoid uneven surfaces
- Avoid installing two units side by side or close to each other as this may restrict the airflow to the condensers.


Before installing a packaged Rooftop unit it is important to understand :

- The direction of prevailing winds.
- The direction and position of air flows.
- The external dimensions of the unit and the dimensions of the supply and return air connections.
- The arrangement of the doors and the space required to open them to access the various components.

CONNECTIONS

- Ensure that all the pipe-work crossing walls or roofs are secured, sealed and insulated.
- To avoid condensation problems, make sure that all pipes are insulated according to the temperatures of fluids and type of rooms.

NOTE: The AQUILUX protection sheets fitted to the finned surfaces must be removed prior to start up.



MODELS	A	B	C	D
FC/FH/FG/FD				
85 → 140	1400	2000	1400	2300
160 & 190	2000	2000	2000	2300
FX				
25 & 30	*	1100	*	1700
35 → 55	*	1300	*	2300
70 → 100	*	1700	*	2300
110 → 170	*	2000	*	2300

* : according to connection

As levels are adjustable, observe the following recommendations for correct installation of the equipment.

Above all, ensure that all the adjustable returns are facing outward (1-figure 3). They are usually turned inside-out for transport.




Figure 3

Place the roof mounting frame on the trimmer beam by first lining up the inlet and then the outlet. (2 - figure 4).




Figure 4

After levelling the frame, fix the surface flaps onto the trimmer. (figure 5).




Figure 5

When the frame is correctly positioned, it is essential to secure the assembly with welding seam (20 to 30 mm for every 200 mm) along the outside, or by using an alternative method (1 - figure 6).




Figure 6




Figure 7

Assembly joint (1 - figure 7)

Insulate the frame before installation. We recommend the minimum application of 25 mm thick insulation.

Check that the covering is continuous and watertight (2 - figure 7).

CAUTION : To be effective, it must finish behind the lip (3 - figure 7)

Before installing the equipment, make sure that the assembly seal is not damaged. Once in position, the bottom of the equipment must be horizontal and against the roof curb as shown on figure 8.

The installer must comply to local authority standards and specifications.





Figure 8

The unit can be fitted on corner posts using the frame provided. The minimum height of the posts should be 400mm.



THIS WORK MUST ONLY BE CARRIED OUT BY TRAINED REFRIGERATION ENGINEERS

FILL THE COMMISSIONING SHEET AS YOU GO ALONG

BEFORE CONNECTING THE POWER:


- Ensure that the power supply between the building and the unit meets local authority standards and that the cable specification satisfies the start-up and operating conditions.

ENSURE THAT THE POWER SUPPLY INCLUDES 3 PHASES + NEUTRAL IF THE UNIT IS EQUIPPED WITH A POWER EXHAUST FAN

- Check the following wire connections for tightness: Main switch connections, mains wires linked to the contactors and circuit breakers and the cables in the 24V control supply circuit.

PRELIMINARY CHECKS

- Ensure that all drive motors are secure.
- Ensure that the adjustable pulley blocks are secure and that the belt is tensioned with the transmission correctly aligned. Refer to the next section for details.
- Using the electrical wiring diagram, check the conformity of the electrical safety devices (circuit breaker settings, presence and rating of fuses).
- Check the temperature probe connections.




STARTING THE UNIT

At this point the unit circuit breakers should be open

You will need a **DS50** maintenance controller or Climalook with appropriate Interface.

The jumpers are factory set and the configuration switches




are adjusted depending on the option the type of unit.

Connecting the CLIMATIC displays.




Close the 24V Control Circuit breakers.



The CLIMATIC 50 starts after 30s

Reset the DAD photo (If fitted)



Check and adjust the control settings.

Refer to the control section in this manual to adjust the different parameters

POWERING THE UNIT

- Power up the unit by closing the isolator switch (if fitted). - At this point the blower should start unless the climatic does not energise the contactor. In this particular case the blower can be forced by bridging the port NO7 and C7 on connector J14 on the Climatic. Once the fan is running, check the rotation direction. Refer to the rotation arrow located on the fan.

- The fans and compressors direction of rotation is checked during the end of line test. They should therefore all turn in either the right or wrong direction.

NOTE : A compressor rotating in the wrong direction will fail.

- If the fan turns in the wrong direction (the right direction is shown on figure n° 9), disconnect the main power supply to the machine at the building's mains switch, reverse two phases and repeat the above procedure.




Fig. 9


- Close all circuit breakers and power up the unit, remove the bridge on connector J14 if fitted.

- If now only one of the components rotates in the wrong direction, disconnect the power supply at the machine's isolator switch (if fitted) and reverse two of the component's phases on the terminal within the electrical panel.
- Check the current drawn against the rated values, in particular on the supply fan (ref. page 24).
- If the readings on the fan are outside the specified limits, this usually indicates excessive air flow which will affect the life expectancy and the thermodynamic performances of the unit. This will also increase the risks of water ingress into the unit. Refer to the "Air Flow Balancing" section to correct the problem.

At this point attach the manometers to the refrigerant circuit

RUN TEST

Start unit in cooling mode



Thermodynamic readings using manometers and prevailing environmental conditions

No rated values are given here. These depend on the climatic conditions both outside and inside the building during operation. However, an experienced refrigeration engineer will be able to detect any abnormal machine operation.

Safety test

- Check Air pressure switch (if fitted) "Dirty filter" detection test: vary the set-point value (menu page 3413 on DS50) in respect to the air pressure value. Observe the response of the CLIMATIC™.
- Same procedure for detecting "Missing Filter" (page menu 3412) or "Air Flow Detection" (page menu 3411).
- Check the smoke detection function (if fitted).
- Check the Firestart by pressing the test button (if fitted).
- Disconnect the circuit breakers of the capacitor fans and check the high pressure cut-out points on different refrigerant circuits.

Reverse cycle test

This test is designed to check the good operation of the 4-way reversing valves on heat pump reversible systems. Start the reverse cycle by adjusting the cold or hot temperature threshold data according to the indoor and outdoor conditions at the time of test (menu 3320)



BELT TENSION

On delivery, the drive belts are new and correctly tensioned. After the first 50 operating hours check and adjust the tension. 80% of the total elongation of belts is generally produced during the first 15 hours of operation.

Before adjusting the tension, make sure that the pulleys are correctly aligned. To tension the belt, set the height of motor support plate by moving the plate adjustment screws.

This recommended deflection is 16 mm per metre from centre to centre.

Check that according to the diagram below (figure 10), the following ratio remains the same.

$$\frac{A \text{ (mm)}}{P \text{ (m)}} = 20$$



The belts should always be replaced when :

- the disk is set to maximum,
- the belt rubber is worn or the wire is visible.

Replacement belts must have the same rated size as the ones they are replacing. If a transmission system has several belts, they must all be from the same manufacturing batch (compare serial numbers).

NOTE :

An under-tensioned belt will slip, heat and wear prematurely. On the other hand, if a belt is over-tensioned, the pressure on the bearings will cause them to over-heat and wear prematurely. Incorrect alignment will also cause the belts to wear prematurely.




Figure 10


MOUNTING AND ADJUSTING PULLEYS

Fan pulley removal

Remove the 2 screws and put one of them in the extraction threaded screw.

Screw in fully. The hub and the pulley will separate from each other.

Remove the hub and the pulley by hand without damaging the machine.



Fan pulley installation

Clean and de-grease the shaft, hub and conical bore of the pulley. Lubricate the screws and install the hub and pulley. Position the screws without turning them.

Place the assembly on the shaft and screw in the screws alternatively and evenly. Using a mallet or a hammer with a wooden wedge, tap on the face of the hub to keep the assembly in place. Torque the screws to 30 Nm.

Take the pulley in both hands and shake it vigorously to make sure everything is in place. Fill the holes with grease for protection.

NOTE : During installation, the key should never protrude out of its groove. After 50 operating hours, check that the screws are still in place.



Motor pulley installation and removal

The pulley is held in position by the key and a screw located in the groove. After unlocking, removing this screw by pulling against the shaft spindle (if necessary, use a mallet and tap uniformly on the hub to remove it).

To assemble, proceed in the reverse order after having cleaned and de-greased the motor shaft and the pulley bore.

Pulleys alignment

After adjusting one or both of the pulleys, check the transmission alignment using a ruler placed on the inner face of the two pulleys.

NOTE : The warranty may be affected if any major modification is made to the transmission without obtaining our agreement beforehand.





The actual resistance of ductwork systems is not always identical to the calculated theoretical values. To rectify this, it may be necessary to modify the pulley and belt setting. To this effect, the motors are fitted with variable pulleys.

Measure the absorbed amps

If the absorbed amps are greater than the rated values, the ventilation system has a lower pressure drop than anticipated. Reduce the flow by reducing the rpm. If the system resistance is significantly lower than design, there is a risk that the motor will overheat resulting in an emergency cut out.


If the absorbed amps are lower than the rated values, your system has a higher pressure drop than anticipated. Increase the flow by increasing the rpm. At the same time you will increase the absorbed power which may result in having to increase the motor size.

To carry out the adjustment and to avoid a time-consuming re-start, stop the machine and if necessary lock the main switch. First unscrew the 4 Allen screw(s) on the pulley (see figure 11).

Pulley type	Pulley external Ø	Min Ø / Min dist.	Max Ø / Max dist.	nr of turns from fully closed to fully open	Actual Ø (DM) or distance between faces for a given number of turns from fully closed with SPA belt in (mm)										
					0,5	1	1,5	2	2,5	3	3,5	4	4,5	5,0	5,5
8450 / D8450	120	95	116	5	113,9	111,8	109,7	107,6	105,5	103,4	101,3	99,2	97,1	95,0	-
		20,2	28,0	5	21,0	21,8	22,5	23,3	24,1	24,9	25,7	26,4	27,2	28,0	-
8550 / D8550	136	110	131	5	128,9	126,8	124,7	122,6	120,5	118,4	116,3	114,2	112,1	110,0	-
		20,6	31,2	5	21,6	22,7	23,8	24,8	25,9	26,9	28,0	29,1	30,1	31,2	-
8670 / D8670	171	145	166	5	163,9	161,8	159,7	157,6	155,5	153,4	151,3	149,2	147,1	145,0	-
		20,5	31,1	5	21,5	22,7	23,8	24,8	25,7	26,9	27,9	29,0	30,0	31,1	-

The easiest way to determine the fan rotation speed is to use a tachometer. If not available the fan rpm can be estimated using the following two methods.

1st Method with the pulley secured in place :



Measure the distance between the two outside faces of the pulley.

Using table 1 the motor pulley actual diameter can be estimated




Figure 11



2nd method when adjusting the pulley :

- Close the pulley fully and count the number of turns from fully closed position. Using table 2 determine the motor pulley actual diameter.
- Record the fix fan pulley diameter.(DF)
- Determine the fan speed using the following formula:

$$\text{rpm}_{\text{FAN}} = \text{rpm}_{\text{MOTOR}} \times D_M / D_F$$

Where :

rpm MOTOR : from the motor plate or table 2

D_M : from table 2

D_F : from machine

Once the pulleys are adjusted and the belt checked and tensioned, start the fan motor and record the Amps and Voltage between the phases :

Using the measured data and table 2

- Theoretical mechanical power at the fan shaft :

$$P_{\text{meca fan}} = P_{\text{meca Motor}} \times \eta_{\text{Transmission}}$$

$$P_{\text{meca fan}} = P_{\text{elec}} \times \eta_{\text{meca motor}} \times \eta_{\text{Transmission}}$$

$$P_{\text{meca fan}} = V \times I \times \sqrt{3} \times \cos\phi \times \eta_{\text{meca motor}} \times \eta_{\text{Transmission}}$$

This formula can be approximated in this way

$$P_{\text{meca fan}} = V \times I \times 1.73 \times 0.85 \times 0.76 \times 0.9$$

With the fan "rpm" and the mechanical power at the fan shaft an operating point and the supplied airflow can be estimated using the fan curves.

CHECKING AIRFLOW AND ESP

Using the fan curves on page 25, 26, 27, the airflow, the total pressure available (P_{TOT}) and the corresponding dynamic pressure (Pd) can now be estimated, for a specific operating point;

The next step consist in estimating the pressure losses across the unit.

This can be achieved using the "dirty filter pressure sensor" and the accessories pressure drop table:

Also the pressure drop due to the duct inlet into the roof-top unit can be taken as 20 to 30 Pa.

$$\Delta P_{\text{INT}} = \Delta P_{\text{filter}} + \text{coil} + P_{\text{Inlet}} + \Delta P_{\text{Options}}$$

using the results from above, the external static pressure (ESP) can then be estimated:

$$\text{ESP} = P_{\text{TOT}} - P_d - \Delta P_{\text{INT}}$$

Table 3 - Motor information

Motor Size	Nom. Speed	Cos	meca motor
0,75 kW	1400 rpm	0,77	0,70
1,1 kW	1425 rpm	0,82	0,77
1,5 kW	1430 rpm	0,81	0,75
2,2 kW	1430 rpm	0,81	0,76
3,0 kW	1425 rpm	0,78	0,77
4 kW	1425 rpm	0,79	0,80
5,5 kW	1430 rpm	0,82	0,82

Table 4 - Accessories Pressure drops

SIZE	Air flow (m³/h)	Economiser 100% open (Pa)	EU7 Filter (Pa)	Hot water coil		Electric heater		Roofcurb Base frame (Pa)	Horizontal Roofcurb (Pa)	Gaz H (Pa)
				S (Pa)	H (Pa)	S (Pa)	H (Pa)			
85	Min. 14 000	8	73	8	16	5	8	18	44	7
	Nom. 16 000	10	113	13	25	8	8	26	57	10
	Max. 22 000	16	159	18	36	8	10	32	109	12
100	Min. 16 000	10	93	10	20	8	10	26	57	10
	Nom. 20 000	14	135	15	30	10	13	32	90	12
	Max. 22 000	16	159	18	36	13	15	38	109	15
120	Min. 18 000	12	113	13	25	10	13	32	33	29
	Nom. 22 000	16	159	18	36	13	15	38	49	35
	Max. 24 000	18	184	21	41	15	18	44	58	40
140	Min. 20 000	14	135	15	30	10	15	35	40	31
	Nom. 24 000	18	184	21	41	15	18	46	58	40
	Max. 25 000	19	197	22	44	15	20	50	63	43
160	Min. 22 000	16	87	9	18	8	8	24	49	45
	Nom. 28 000	22	132	13	27	8	10	30	79	56
	Max. 32 000	26	165	17	34	13	13	34	103	64
190	Min. 24 000	18	101	10	20	10	10	34	58	64
	Nom. 33 000	27	174	18	36	13	13	41	109	77
	Max. 36 000	30	201	21	41	13	15	48	130	89

EXAMPLE

The unit used for this example is a **FHK 120N** with standard supply and return airflow configuration. It is also fitted with an economiser and an electric heater type H.

It is fitted with 2 **AT 18-18** fans which curve is shown on page 35 and 2x 2.2 kW motors.

For each motor we have :

- Motor rpm : 1430 rpm
- $\cos \varphi = 0.81$
- Voltage = 400 V
- Current = 4,68A

$$P_{\text{mech fan}} = V \times I \times \sqrt{3} \times \cos\varphi \times \eta_{\text{mech motor}} \times \eta_{\text{Transmission}}$$

$$= 400 \times 4.68 \times \sqrt{3} \times 0.81 \times 0.76 \times 0.9 = \underline{1,79 \text{ kW}}$$

The unit is also fitted with 2 transmission kits 1


- Fixed Fan pulley : 250 mm
- Motor adjustable pulley type "8450" opened 1 turn from fully closed or measured distance between pulley end plates is 21,8 mm: from table xxx it can be determined that the motor pulley has a diameter of 111,8 mm

$$\text{rpm}_{\text{FAN}} = \text{rpm}_{\text{MOTOR}} \times D_M / D_F = 1430 \times 118,2 / 250 = \underline{640 \text{ rpm}}$$

Using the fan curve below the operating point can be located.

In order to facilitate the calculation, you won't make any mistake by considering that the external static pressure available is the one fan providing the half of the nominal flow (here 11 000 m³/h)

It can be determined that each fan is providing approximately **11 000 m³/h** with a total pressure $P^{\text{TOT}} = \underline{400 \text{ Pa}}$



The pressure losses in the unit are the sum of all pressure drops across the different parts of a unit :

- Coil and filter (measured) = 105 Pa
- Inlet into the unit = 30 Pa
- Options = 16 Pa for economiser and 13 Pa for electric heater H

$$\Delta P = 105 + 16 + 13 + 30 = \underline{163 \text{ Pa}}$$

The dynamic pressure at 11000m³/h is given at the bottom of the fan curve (page 26)

$$P_d = \underline{85 \text{ Pa}}$$

The external static pressure available is therefore

$$\text{ESP} = P_{\text{TOT}} - P_d - \Delta P_{\text{INT}}$$

$$= 400 - 85 - 163 = \underline{152 \text{ Pa}}$$

Figure 24



KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FC/FH/FD... 085 - Standard			
K1	AT 15-15 G2L	-	33 ^(*)
K2	AT 15-15 G2L	-	33 ^(*)
K3	AT 15-15 G2L	-	33 ^(*)
K4	AT 15-15 G2L	-	33 ^(*)
K5	AT 15-15 G2L	-	33 ^(*)
K6	AT 15-15 G2L	-	33 ^(*)
K7	AT 15-15 G2L	-	33 ^(*)
K8	AT 15-15 G2L	-	33 ^(*)
K9	-	AT 15-15 S	33
K10	AT 15-15 G2L	-	33 ^(*)
K11	-	AT 15-15 S	33
K12	AT 15-15 G2L	-	33 ^(*)
K13	-	AT 15-15 S	33
FC/FH/FD... 100 - Standard			
K1	AT 15-15 G2L	-	33 ^(*)
K2	AT 15-15 G2L	-	33 ^(*)
K3	AT 15-15 G2L	-	33 ^(*)
K4	AT 15-15 G2L	-	33 ^(*)
K5	AT 15-15 G2L	-	33 ^(*)
K6	-	AT 15-15 S	33
K7	AT 15-15 G2L	-	33 ^(*)
K8	-	AT 15-15 S	33 ^(*)
K9	AT 15-15 G2L	-	33 ^(*)

KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FC/FH/FD... 120 - Standard			
K1	-	AT 18-18 S	35
K2	-	AT 18-18 S	35
K3	-	AT 18-18 S	35
K4	-	AT 18-18 S	35
K5	-	AT 18-18 S	35
K6	-	AT 18-18 S	35
K7	-	AT 18-18 S	35
K8	-	AT 18-18 S	35
K9	-	AT 18-18 S	35
FC/FH/FD... 140 - Standard			
K1	-	AT 18-18 S	35
K2	-	AT 18-18 S	35
K3	-	AT 18-18 S	35
K4	-	AT 18-18 S	35
K5	-	AT 18-18 S	35
K6	-	AT 18-18 S	35
K7	-	AT 18-18 S	35
K8	-	AT 18-18 S	35
K9	-	AT 18-18 S	35
FC/FH/FD... 160 - Standard			
K1	-	AT 18-18 S	35
K2	-	AT 18-18 S	35
K3	-	AT 18-18 S	35
K4	-	AT 18-18 S	35
K5	-	AT 18-18 S	35
K6	-	AT 18-18 S	35
K7	-	AT 18-18 S	35
K8	-	AT 18-18 S	35
K9	-	AT 18-18 S	35
K10	-	AT 18-18 S	35
FC/FH/FD... 190 - Standard			
K1	-	AT 18-18 S	35
K2	-	AT 18-18 S	35
K3	-	AT 18-18 S	35
K4	-	AT 18-18 S	35
K5	-	AT 18-18 S	35
K6	-	AT 18-18 S	35
K7	-	AT 18-18 S	35
K8	-	AT 18-18 S	35
K9	-	AT 18-18 S	35
K10	-	AT 18-18 S	35

(*) The performances of twin fan units can be calculated starting from the corresponding operation point for a single fan (see the figure behind) by applying the formulas below.

- pressure : $P_{Twin} = P \times 1$
- volume flow rate : $Q_b = Q \times 2$
- impeller power: $W_b = W \times 2,15$
- fan speed : $N_b = N \times 1,05$
- Lws : $Lwsb = Lws + 3 \text{ dB}$



KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FC/FH/FD... 085 - Side discharge			
K14	-	AT 15-15 S	33
K15	-	AT 15-15 S	33
K16	-	AT 15-15 S	33
K17	-	AT 15-15 S	33
K18	-	AT 15-15 S	33
K19	-	AT 15-15 S	33
K20	-	AT 15-15 S	33
K21	-	AT 15-15 S	33
FC/FH/FD... 100 - Side discharge			
K10	-	AT 15-15 S	33
K11	-	AT 15-15 S	33
K12	-	AT 15-15 S	33
K13	-	AT 15-15 S	33
K14	-	AT 15-15 S	33
K15	-	AT 15-15 S	33
K16	-	AT 15-15 S	33
K17	-	AT 15-15 S	33
K18	-	AT 15-15 S	33
K19	-	AT 15-15 S	33
FC/FH/FD... 120 - Side discharge			
K10	-	AT 18-13 S	34
K11	-	AT 18-13 S	34
K12	-	AT 18-13 S	34
K13	-	AT 18-13 S	34
K14	-	AT 18-13 S	34
K15	-	AT 18-13 S	34
K16	-	AT 18-13 S	34
K17	-	AT 18-13 S	34
K18	-	AT 18-13 S	34
FC/FH/FD... 140 - Side discharge			
K10	-	AT 18-13 S	34
K11	-	AT 18-13 S	34
K12	-	AT 18-13 S	34
K13	-	AT 18-13 S	34
K14	-	AT 18-13 S	34
K15	-	AT 18-13 S	34
K16	-	AT 18-13 S	34
K17	-	AT 18-13 S	34



KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FG... 085 - Gas			
K1	-	AT 15-15 S	33
K2	-	AT 15-15 S	33
K3	-	AT 15-15 S	33
K4	-	AT 15-15 S	33
K5	-	ADN 355L	37
K6	-	AT 15-15 S	33
K7	-	ADN 355L	37
K8	-	AT 15-15 S	33
K9	-	AT 15-15 S	33
K10	-	ADN 355L	37
K11	-	ADN 355L	37
FG... 100 - Gas			
K1	-	AT 15-15 S	33
K2	-	AT 15-15 S	33
K3	-	AT 15-15 S	33
K4	-	AT 15-15 S	33
K5	-	ADN 355L	37
K6	-	AT 15-15 S	33
K7	-	AT 15-15 S	33
K8	-	ADN 355L	37
K9	-	AT 15-15 S	33
K10	-	ADN 355L	37

KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FG... 120 - Gas			
K1	-	ADN 400	38
K2	-	ADN 400	38
K3	-	ADN 400	38
K4	-	ADN 400	38
K5	-	ADN 400	38
K6	-	ADN 400	38
K7	-	ADN 400	38
K8	-	ADN 400	38
FG... 138 - Gas			
K1	-	ADN 400	38
K2	-	ADN 400	38
K3	-	ADN 400	38
K4	-	ADN 400	38
K5	-	ADN 400	38
FG... 160 - Gas			
K1	-	ADN 450 L	39
K2	-	ADN 450 L	39
K3	-	ADN 450 L	39
K4	-	ADN 450 L	39
K5	-	ADN 450 L	39
K6	-	ADN 450 L	39
K7	-	ADN 450 L	39
K8	-	ADN 450 L	39
K9	-	ADN 450 L	39
K10	-	ADN 450 L	39
FG... 190 - Gas			
K1	-	ADN 450 L	39
K2	-	ADN 450 L	39
K3	-	ADN 450 L	39
K4	-	ADN 450 L	39
K5	-	ADN 450 L	39
K6	-	ADN 450 L	39
K7	-	ADN 450 L	39
K8	-	ADN 450 L	39
K9	-	ADN 450 L	39
K10	-	RDN 450 K	36



KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FX... 025 Indoor			
K1	AT 12-12 S	-	32
K2	AT 12-12 S	-	32
K3	AT 12-12 S	-	32
K4	AT 12-12 S	-	32
K5	AT 12-12 S	-	32
K6	AT 12-12 S	-	32
K7	AT 12-12 S	-	32
K8	AT 12-12 S	-	32
K9	AT 12-12 S	-	32
K10	AT 12-12 S	-	32
FX.. 030 Indoor			
K1	AT 12-12 S	-	32
K2	AT 12-12 S	-	32
K3	AT 12-12 S	-	32
K4	AT 12-12 S	-	32
K5	AT 12-12 S	-	32
K6	AT 12-12 S	-	32
K7	AT 12-12 S	-	32
K8	AT 12-12 S	-	32
K9	AT 12-12 S	-	32
K10	AT 12-12 S	-	32
FX... 035 Indoor			
K1	AT 15-15 S	-	33
K2	AT 15-15 S	-	33
K3	AT 15-15 S	-	33
K4	AT 15-15 S	-	33
K5	AT 15-15 S	-	33
K6	AT 15-15 S	-	33
K7	AT 15-15 S	-	33
K8	AT 15-15 S	-	33
FX... 040 Indoor			
K1	AT 15-15 S	-	33
K2	AT 15-15 S	-	33
K3	AT 15-15 S	-	33
K4	AT 15-15 S	-	33
K5	AT 15-15 S	-	33
K6	AT 15-15 S	-	33
K7	AT 15-15 S	-	33
K8	AT 15-15 S	-	33
K9	AT 15-15 S	-	33
K10	AT 15-15 S	-	33
FX... 055 Indoor			
K1	AT 15-15 S	-	33
K2	AT 15-15 S	-	33
K3	AT 15-15 S	-	33
K4	AT 15-15 S	-	33
K5	AT 15-15 S	-	33
K6	AT 15-15 S	-	33
K7	AT 15-15 S	-	33
K8	AT 15-15 S	-	33
K9	AT 15-15 S	-	33
K10	AT 15-15 S	-	33

KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FX... 070 Indoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35
K6	AT 18-18 S	-	35
K7	AT 18-18 S	-	35
K8	AT 18-18 S	-	35
K9	AT 18-18 S	-	35
K10	AT 18-18 S	-	35
K11	AT 18-18 S	-	35
FX... 085 Indoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35
K6	AT 18-18 S	-	35
K7	AT 18-18 S	-	35
K8	AT 18-18 S	-	35
K9	AT 18-18 S	-	35
FX... 0100 Indoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35
K6	AT 18-18 S	-	35
K7	AT 18-18 S	-	35
FX... 110 Indoor			
K1	-	AT 18-18 S	35
K2	-	AT 18-18 S	35
K3	-	AT 18-18 S	35
K4	-	AT 18-18 S	35
K5	-	AT 18-18 S	35
K6	-	AT 18-18 S	35
K7	-	AT 18-18 S	35
FX... 140 Indoor			
K1	-	AT 18-18 S	35
K2	-	AT 18-18 S	35
K3	-	AT 18-18 S	35
K4	-	AT 18-18 S	35
K5	-	AT 18-18 S	35
K6	-	AT 18-18 S	35
K7	-	AT 18-18 S	35
K8	-	AT 18-18 S	35
FX... 170 Indoor			
K1	-	AT 18-18 S	35
K2	-	AT 18-18 S	35
K3	-	AT 18-18 S	35
K4	-	AT 18-18 S	35
K5	-	AT 18-18 S	35
K6	-	AT 18-18 S	35
K7	-	AT 18-18 S	35




KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FX... 025 Outdoor			
K1	AT 12-12 S	-	32
K2	AT 12-12 S	-	32
K3	AT 12-12 S	-	32
K4	AT 12-12 S	-	32
K5	AT 12-12 S	-	32
K6	AT 12-12 S	-	32
FX... 030 Outdoor			
K1	AT 12-12 S	-	32
K2	AT 12-12 S	-	32
K3	AT 12-12 S	-	32
K4	AT 12-12 S	-	32
K5	AT 12-12 S	-	32
FX... 035 Outdoor			
K1	AT 15-15 S	-	33
K2	AT 15-15 S	-	33
K3	AT 15-15 S	-	33
K4	AT 15-15 S	-	33
K5	AT 15-15 S	-	33
K6	AT 15-15 S	-	33
K7	AT 15-15 S	-	33
FX... 040 Outdoor			
K1	AT 15-15 S	-	33
K2	AT 15-15 S	-	33
K3	AT 15-15 S	-	33
K4	AT 15-15 S	-	33
K5	AT 15-15 S	-	33
K6	AT 15-15 S	-	33
K7	AT 15-15 S	-	33
FX... 055 Outdoor			
K1	AT 15-15 S	-	33
K2	AT 15-15 S	-	33
K3	AT 15-15 S	-	33
K4	AT 15-15 S	-	33
K5	AT 15-15 S	-	33
FX... 070 Outdoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35
K6	AT 18-18 S	-	35

KIT NR	FAN TYPE		CURVE PICTURE ON PAGE
	SINGLE	TWIN	
FX... 085 Outdoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35
FX... 100 Outdoor			
K1	-	AT 15-15 S	33
K2	-	AT 15-15 S	33
K3	-	AT 15-15 S	33
K4	-	AT 15-15 S	33
K5	-	AT 15-15 S	33
FX... 110 Outdoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35
K6	AT 18-18 S	-	35
FX... 140 Outdoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35
FX... 170 Outdoor			
K1	AT 18-18 S	-	35
K2	AT 18-18 S	-	35
K3	AT 18-18 S	-	35
K4	AT 18-18 S	-	35
K5	AT 18-18 S	-	35




AT 12-12 FAN






AT 15-15 FAN






AT 18-13






AT 18-18 FAN




RDN 450 FAN






ADN 355 FAN






ADN 400 FAN







ADN 450 FAN



FILTER REPLACEMENT

After opening the filter access panel, lift the filter retaining log.

The filters can then be removed and replaced easily by sliding the dirty filters out and clean ones in.



The CLIMATIC controller can monitor the pressure drop across the filter (If option fitted)

The following set points can be adjusted depending on the installation.

"Airflow" in page 3411 = 25Pa by default

"No filter " in page 3412 = 50Pa by default

"Dirty Filter" in page 3413 = 250Pa by default

The actual pressure drop measured across the coil can be read on the Climatic Display DS50 in menu 2131.

The following faults may be identified

-Fault code 0001 AIRFLOW FAILURE, if measured ΔP across the filter and coil is below the value set in page 3411

-Fault code 0004 DIRTY FILTERS, if measured ΔP across the filter and coil is above the value set in page 3413

-Fault code 0005 MISSING FILTERS, if measured ΔP across the filter and coil is below the value set in page 3412

AIR SOCK CONTROL

FANSTART Operation

The use of air socks for space conditioning allows high air volumes to be distributed at low velocity and is becoming a common feature in many applications. To accommodate this trend, Air-sock control is offered which allows the air socks to be progressively filled with air on start up. BALTIC has been enhanced with an electronic device to soft start the fan. It takes up to 1 minute to go from 0% of air to full air flow.

START - UP

Phase rotation check

If the phase rotation is incorrect the FANSTART Control will display a fault (Red LED). Two of the phases must then be inverted and start again the start up cycle.

The FANSTART control can also display a fixed red LED in two cases:

- Motor absent (6s)
- A phase is missing (6s)



Any adjustment of the FANSTART has to be done power stopped.

This time is divided in several stages:

- The aim of this first voltage input is to "take off belts from the pulleys": 0.5s ("BOOST")
- The second stage is to inflate the air sock: during 30s with approximately half nominal speed
- Finally the air sock is gradually pressurised during the last 30s. The motor reaches nominal speed and the controller is shunted, the motor being fed on line by the tension of the electrical network.

The thermal overload limit on the motor imposes a current limitation during the acceleration stage. Hence if the selected slope is too steep, the predefined current limit can be reached: flashing red LED, adjust the potentiometer P3 and the controller will automatically reduce the voltage set-point accordingly. Then once the current is back under the high current limit it carries on with the start up cycle.

The green LED switches off itself at the end of the FANSTART operation.

Safety


Excessive "slow down" limit

In the engine's acceleration phase, the red led flashing; the motor slows down in an excessive way and stops after 80s at fault (led red fixed).

Current protection of the Thyristor

The FANSTART will display a fault (red LED) if the current exceeds the thyristor current limits:

- 125A during 0.4s
- 87.4A during 2s
- 75A during 6s.
- 62.5A during 20s.



The motor speed control is achieved through a variation of the supply voltage of each phase at constant frequency.

Start up sequence too long

If at the end of 80s the fanstart did not commutate the motor on the electrical network, the motor stops: fixed red led.

Nota : In the case of a resistant air sock, one can reduce the phase of pre-inflation to 5 seconds (thanks to the switch, fig. 12)





Fig. 12

HYDRAULIC CONNECTIONS

The heating coil is connected to the isolating valves. Two keys must be used to tighten the connections, one of the keys maintains the valve body. Failure to use two keys may damage the pipes and invalidates the warranty.

Proceed as follows :

- Open the stop valves and set the 3-way valve to the intermediate position (manual position and turn the thumbwheel to a mid position).
- Fill the hydraulic system and bleed the battery using the air vent (figure 13).
- Check the connections for possible leaks.
- Reset the 3-way valve to automatic.




Figure 13

PROTECTION AGAINST FREEZING

- 1) Use glycol water

GLYCOL IS THE ONLY EFFECTIVE PROTECTION AGAINST FREEZING

The antifreeze must protect the unit and avoid icing under winter conditions.


Warning : monoethylene glycol-based antifreeze may produce corrosive agents when mixed with air.

- 2) Drain the installation

You must ensure that the manual or automatic air vents have been installed on all high points in the system. In order to drain the system check that all the drain cocks have been installed on all low points of the system.

To drain, open all the valves and remember to place the unit in air.

A HEATING COIL FROZEN DUE TO LOW AMBIENT CONDITIONS IS NOT COVERED BY THE WARRANTY.



ELECTROLYTIC CORROSION

Attention is drawn to the corrosion problems resulting from electrolytic reaction created from unbalanced earth connections.

ANY COIL DAMAGED BY ELECTRONIC REACTION IS NOT COVERED BY THE WARRANTY.

PRELIMINARY CHECKS BEFORE START-UP

NOTE :

ANY WORK ON THE GAS SYSTEM MUST BE CARRIED OUT BY QUALIFIED PERSONNEL.

THIS UNIT MUST BE INSTALLED IN ACCORDANCE WITH LOCAL SAFETY CODES AND REGULATIONS AND CAN ONLY BE USED IN WELL VENTILLATED AREA.

PLEASE READ CAREFULLY THE MANUFACTURER'S INSTRUCTIONS BEFORE STARTING A UNIT.

BEFORE COMMISSIONING A UNIT WITH GAZ BURNER, IT IS MANDATORY TO ENSURE THAT THE GAZ DISTRIBUTION SYSTEM (type of gas, available pressure...) IS COMPATIBLE WITH THE ADJUSTMENT AND SETTINGS OF THE UNIT.

Check access and clearance around the unit

- Make sure one can move freely around the unit.
- A minimum one-meter clearance must be left in front of the burnt gas exhaust flue.
- Combustion air inlet and burnt gas exhaust(s) must NOT be obstructed in any way.

Supply Network Pipe Sizing

MALE THREADED CONNECTION FOR GAZ BURNER: 3/4"

Check that the gas supply line can provide the burners with the pressure and the gas flow rate necessary to provide the heating nominal output .

Male threaded connection for Gaz Burner: 3/4"

UNIT SIZE	85	100	120	140	160	190
S POWER	1	1	2	2	2	2
H POWER	2	2	4	4	4	4

GAS FLOW (for G20 at 20 mbar and 15°C) m³/h

UNIT SIZE	85	100	120	140	160	190
S POWER	5,7	5,7	11,5	11,5	11,5	11,5
H POWER	11,5	11,5	17,2	17,2	17,2	17,2

For modulating gas we have just H power for C, D & E-box

- The gas supply to a Rooftop gas unit must be realized according to Sound Engineering Practice and the local safety codes and rules.
- In any case the diameter of pipe-work connected to each Rooftop must not be smaller than the diameter of the connection on the Rooftop unit.
- Make sure that a shut-off isolation valve has been installed before EACH Rooftop.
- Check the supply voltage to the exit of the power supply's transformer T3 of the burner: it must be between 220 and 240V.

STARTING UP THE GAS BURNER



Purge the pipe-work near the connection on the ignition control Valve for a few seconds.

- Check that the unit's treatment "Fan" blower is running.
- Set the control to "ON" This will priorities the gas burner.
- Increase the set temperature (room set point temperature) to a temperature higher than the actual room temperature.

Table 4 - Standard start-up Chronology

Time in seconds	1	2	3	4	5	6	7	8	9	10	11	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	398	399	400	401						
Operations																																							
Control operation sequence																																							
Extraction fan																																							
Smoke extraction fan "ON"																																							
30 to 45 seconds pre-Ventilation																																							
Fire-up spark electrode 4s																																							
Opening of the gas valve "High Heat"																																							
Flame propagation towards the ionisation probe																																							
If Ionisation within 5sec: Normal running																																							
Otherwise fault on gas ignition control block																																							
After 5 minutes, fault reported on the climatic controller																																							

If incorrect sequence refer to the fault analysis table to identify the problem.

**PRESSURE ADJUSTMENTS ON HONEYWELL
PRESSURE REGULATING VALVE TYPE VK 4105**

Pressure regulator adjustment with 300mbar gas supply:




Fig. 14

- The Burner must run in High Heat mode for this check.
- Place the tube of the "accurate" manometer on the **Inlet** pressure port (figure 14) of the Gas Regulating Valve after having loosened the screw by one turn.




Fig. 15

- Check and adjust if necessary the valve **Inlet** pressure to 20.0 mbar (G20) or 25.0 mbar for Groningue (G25) or 37.0 mbar for propane (G31) after gas burner ignition. (figure 15)



High Heat Injection Pressure Checks

- Place the tube of the "accurate" Manometer to the **OUT** port on the Gas injector support bar after having loosened the screw by one turn.





Fig. 16

- Check and adjust if necessary the valve **OUTLET** pressure to 8.4 mbar (G 20) / 12.3mbar for Groningue (G25) and 31.4 mbar for propane (G31)(figure 16).



Low Heat Injection Pressure Checks

- Switch the control to Low Heat
- Check and adjust if necessary the **Outlet** pressure to 3.5 mbar (G20) and 5 mbar for Groningue(G25) or 14 mbar for propane (G31)(figure 17).



Fig. 17

Pressure adjustments table for each type of gas

Category	Supply pressure	Low Heat injection	High Heat Injection
G20	20.0 +/-1	3.5 +/-0.1	8.4 +/-0.2
G25 (Groningue)	25.0 +/-1.3	5.0 +/-0.1	12.3 +/-0.2
G31 (GPL)	37.0 +/-1.9	14.0 +/-0.3	31.4 +/-0.6

Valve electrical control





Fig. 18

- Check these values with an Ohmmeter.



- After the adjustment of the low heat, re-verify the high heat
- re-position the stoppers and close the pressure ports.

BURNER SAFETY CHECKS**Smoke extractor pressure switch Test.**

- With the gas burner running, disconnect the flexible tube fitted to the pressure tapping on the pressure switch (fig. 19)
- The Flame must disappear and the extraction fan must carry on running.
- However, NO fault will be displayed (Gas ignition control block or CLIMATIC).

Fig. 19



- After reconnecting the tube, the Burner will restart after a period of 30 to 45 seconds pre-ventilation.

Gas pressure switch test

- With the gas burner running, close the shut off valve located before the rooftop (fig. 20).


Fig. 20



- The burner stops completely.
- However, No fault light will be displayed on the Gas ignition control block.. After 6 Minutes, the CLIMATIC will display a fault.
- Reset the CLIMATIC.

Ionisation Probe test


- With the gas burner running, disconnect the terminal plug coming from the ionisation probe to the gas ignition control box.



- The flame disappears
- The fan is still running and attempting to restart the burner (restart cycle 30 to 45 seconds).
- if the ignition probe is not reconnected at the end of the ignition sequence the burner will stop completely.
- The fault light on the gas ignition control block is ON.
- Manually reset the gas ignition control block to eliminate the fault.

IN CASE OF PROBLEMS REFER TO THE START UP SEQUENCE FLOWCHART NEXT PAGE

GAS BURNER FIRE-UP SEQUENCE





GAS BURNER TROUBLESHOOTING

If faults reported on CLIMATIC

- Reset the CLIMATIC.
- Check voltage: 230V after circuit breaker.
- Check GAS isolation shut-off valves are open.
- Check GAS pressure at the inlet of the GAS valves. It must be >20 mbar when the Burners shut down.
- Adjust the set points to priorities the burner. Increase the value of the room temperature set point to a temperature higher than actual room temperature.

Table 6

STAGE	NORMAL OPERATION	POSSIBLE FAULT	ACTION	POSSIBLE SOLUTION
Heating Requested	Green, yellow & red L.E.D. ON	All L.E.D. OFF = fault on the blower thermostat	+ Check connections on the blower thermostat	+ Replace thermostat
		Yellow & red L.E.D. OFF = lack of gas supply	+ Check valve's opening & supply pressure	+ Restore gas supply
		Red L.E.D. OFF = fault on the superheat thermostat on the gas burner support bar	+ Check thermostat's operation after manual reset	+ Replace thermostat
L.E.D ON	Extraction Fans	After 10 seconds safety shutdown are running by the ignition control block	+ Check connections of the control block on the gas valve + Check impedance of electro valve's coils: (1) = 2.90k Ω ; (2) = 1.69k Ω (fig. n° 18, p 46)	+ Repositioning of the control block on the valve + Replace valve
		Nothing happens	+ Check the free movement of the fan wheel + Check Electrical connection on the Gas Ignition Control Block and on EF connection Board + Check the Fan supply voltage	+ Replace fan + Replace EF connection board If necessary
Extraction Fan is ON	After 30 to 45 seconds : pre-ventilation the fire-up electrode should spark	Continuous Ventilation without sparks from fire-up electrode	+ Check the fire-up electrode + Check the pressure drop at the pressure switch: It must be higher than 165 Pa +Check the good operation of the pressure switch using an Ohmmeter and by artificially creating a depression in the tube	+ Re-position the pressure switch tube + Change the pressure switch
Continuous ventilation and sparks from fire up electrode	After a few seconds the gas burner fires-up	After 4 seconds the GAS Burner still not operating and safety shutdown by the Ignition Control Block	+ Check injection pressure during start-up (Value for High Heat) +Remove the control box from the gas block	+ Remove the air from the Gas pipe-work + Adjust the injection pressure to high heat value + Change the Control Box if the Gas valve is OK
		Within 4 seconds the gas Burner fires-up BUT safety shutdown from the Ignition Control Block	+ Check the Position and connection of the Ionisation Probe. It must not be Earthed (230V) + Check that R.C circuit of the gas burner's transformer is well connected to the neutral polarity + Measure the Ionisation Current : It must be higher than 1.5 microAmps. + Check the Type of GAS	+Check the whole electrical supply + Adjust the supply and injection pressure if gas is different from natural gas G20 : (G25 Gas of Groningue for example)

DISASSEMBLING THE GAS BURNER FOR MAINTENANCE PURPOSES


Preliminary Safety Recommendations

- Isolate the unit using the main isolator switch.
- Close off the isolating gas valve located before the unit.
- Disconnect the Pipe-work. Do not discard the seals.



Disassembling the gas "burner support bar"


- Disconnect the Electrical Connector on the electric connection board EF 49
- Remove the two screws which hold the gas Bar in Place
- Carefully remove the gas " burner support bar " avoiding any damages to the electrodes.



Disassembling the flue

- Electrically disconnect the fan and remove the screws holding it in place.
- Take care not to loose any cage nuts in the smoke box.

ATTENTION: Check the correct position of the pressure tube used by the extraction pressure switch.




Required Equipment List for maintenance Adjustment and Start-up


- An accurate manometer from 0 to 3500 Pa (0 to 350 mbar): 0.1% full scale.
- A Multimeter with Ohmmeter and Micro-amps scale
- An Adjustable Spanner
- Tube Spanner Set: 8, 9, 10, and 13.
- Flat Screwdrivers diameter 3 and 4, Phillips n°1
- Vacuum cleaner
- Paint brush




GAS INJECTORS SUPPORT BAR




60 KW BURNER FOR FGX 85 AND 100 MODELS



120 KW BURNER FOR FGX 85,100,120,140,160 & 190 MODELS



180 KW BURNER FOR FGX 120,140,160 & 190 MODELS





CLIMATIC 50 SOFTWARE FEATURES AND LOGIC

As a standard feature, CLIMATIC™50 provides 4 scheduling time zones per day on 7 days. On each of the 4 time zones, heating set point, cooling set point, minimum fresh air, humidity set point high and up, and even the different authorisations for cooling and heating can be adjusted. CLIMATIC™ 50 provides a choice of different remote displays depending on customer requirement and application of the system. As a standard feature, it is possible to set alarms (adjustable value low and high) on room temperature and humidity.

CONTROL SOFTWARE LOGIC

With the CLIMATIC™ 50 Lennox is going away from the traditional step control

Capacity factor

It is used to determine the exact capacity required at any time in order to react quicker and more accurately to any change in demand.


The capacity factor is a percentage of the total cooling or heating capacity.

Example:

On a three circuit rooftop unit with two compressors running out of three has a capacity factor of 66%

In the same way, a three circuit rooftop with a modulating electric heater running at 20% of its full capacity has a CF: $CF = 25\%+25\%+25\%+5\% = 80\%$

The Capacity factor will increase, decrease, or freeze depending on the temperature difference between the set point and the room temperature but also on the way this room temperature is changing:



Example:

The room set point is 25°C with a 3 compressor unit.

Delta vs room set point	Room Temp.	Cap. factor	COMP 1	COMP 2	COMP 3
+0	Increasing	0%	OFF	OFF	OFF
+1	Increasing	35%	ON	OFF	OFF
+2	Increasing	70%	ON	ON	OFF
+3	Increasing	100%	ON	ON	ON
+2	Decreasing	100%	ON	ON	ON
+1	Decreasing	100%	ON	ON	ON
0	Decreasing	100%	ON	ON	ON
-1	Decreasing	60%	ON	ON	OFF
0	Increasing	60%	ON	ON	OFF

Reactivity.

The reactivity determines how fast the capacity factor should vary.

It is given in: Percentage of capacity / Degree °C (Room Temp. VS Set Point) / minute

Example :

If the reactivity is set to 3 % / °C / min

Then:

Capacity factor can go from 0 to 30% in 10 minutes if **Delta** Room Temp. VS Set Point is 1°C

Or capacity factor will go from 0 to 60 % in 4 minutes if **Delta** Room Temp. VS Set Point is 5°C

The reactivity can be adjusted with the CLIMATIC™ 50 The larger the reactivity the faster the rooftop will react to a change.

The next table shows the effect of a change of the reactivity on the capacity factor: This shows that by increasing the reactivity, the unit reaches the set point quicker but the energy consumption (capacity factor) is larger.

REACTIVITY : 3

DELTA	15%	75%	100%
DELTA +5	15%	75%	100%
DELTA +3	9%	45%	90%
DELTA +1	1%	15%	30%
	1MIN	5MIN	10MIN

REACTIVITY : 6

DELTA	30%	100%	100%
DELTA +5	30%	100%	100%
DELTA +3	18%	90%	100%
DELTA +1	2%	30%	60%
	1MIN	5MIN	10MIN



OTHER FEATURES

Dynamic Set Point


This feature allows the set point to change according to the outside temperature.

Example:

If the set point is 25°C

And the dynamic set point is set to 6°C

Then, when the outdoor temperature reaches: 31°C (25°C + 6°C) the set point will follow the outdoor temperature with a 6°C temperature difference.



If you do not want to use this feature, set the dynamic set point to **99**

Time Zones and scheduling

With the Climatic50 the scheduling has been completely reviewed:

- * The first day of the week is Monday.
- * Automatic switch from winter time to summer time.
- * Unoccupied mode from one to seven days
- * Three occupied and one unoccupied zone per day

For each zone a series of set points and feature can be adjusted or selected, depending on the type of display which is being used.

LIST OF SET POINTS PER ZONE	CODE	CONFORT DISPLAY	SERVICE DISPLAY
AMBIANT TEMPERATURE			
Average set point	3311	Yes	Yes
Dynamic Set Point	3321	Yes	Yes
Cooling Set Point	3322	0	Yes
Heating Set point	3323	0	Yes
Heating Priority	3324	0	Yes
FRESH AIR REHEAT			
activated	3331	0	Yes
Heating priority	3332	0	Yes
HUMIDITY			
Dehumidification	3341	0	Yes
Humidification	3342	0	Yes
AUTHORIZATION			
Free Cooling		0	Yes
Fresh Air by CO2	3354	0	Yes
Mechanical cooling	3355	0	Yes
Mechanical heating	3356	0	Yes
Auxiliary heating	3357	0	Yes
Humidification: ON/OFF	3358	0	Yes
Low Noise	3359	0	Yes
OTHER			
Fan Mode :On / Off	3351	0	Yes
Fan dead	3352	0	Yes
Minimum fresh air (%)	3353	Yes	Yes
SCHEDULING			
Beginning of the zone for each day		Yes	Yes
Start Uno	3211	Yes	Yes
Start.Uno	3212	Yes	Yes
Start z.A	3213	Yes	Yes
Start.z.A	3214	Yes	Yes
Start z.B	3215	Yes	Yes
Start.z.B	3216	Yes	Yes
Start z.C	3217	Yes	Yes
Start.z.C	3218	Yes	Yes

Example of Zone setting :

	8h00	12h00	14h00	20h00	
Monday	Unoc.	ZA	ZB	ZC	Unoc.
Tuesday					
Wed.					
Thursday					
Friday					
Saturday					
Sunday					

Each zone is determined by its starting time.

Forced modes

3 hours Override

A three hours override period can be forced on the CLIMATIC™50:

With this feature, a new room temperature set point and fresh air requirement can be imposed for a three hour period; It will then revert to the original setting at the end of the override period or earlier by pressing "esc".

Forced unoccupied zone (or ZA, ZB, ZC)

The unoccupied zone (or ZA, ZB, ZC) settings can be forced for a period of up to seven days. It will then revert to the original settings at the end of the defined period or earlier by pressing "esc".

Heating priorities

It is possible to set heating priorities depending on the outdoor temperature.
 For compressors: refer to the instructions 3611, 3612, 3613.
 For electrical heater: refer to the instruction 3721.

Example:

It could be decided based on energy costs, that on a dual fuel unit, it should run in heat pump mode when the temperature is above 0°C and switch to gas burner below that point.

Staggered start

After a power cut, the units can be made to restart one after the other to prevent any current surge.
 There is no need for a link between the units, they just have to be given an address during commissioning and they will restart 10 seconds x their "address number" after the power is switched back on.

Example:


If a unit is given the address N°3 it will be switched-on 30 seconds (3 x 10sec) after the power is switched back on.

Fresh air adjustment and calibration on Economiser

The actual fresh air volume brought into the system is not always proportional to the percentage of opening of the fresh air damper. That is particularly true when the return air duct system has been sized to produce excessive pressure drop.

This often results in bringing into the system an excessive amount of fresh air, hence increasing the running cost of the system.

The control of fresh air is now achieved through the use of three temperature sensors : One in the supply air flow, one in the return air and one for the outdoor temperature.




Using these three sensors, the Climatic50 will calculate and memorise the exact percentage of fresh air for each position of the damper.

$$T_{\text{supply air}} = T_{\text{return air}} \times \%_{\text{return air}} + T_{\text{fresh air}} \times \%_{\text{fresh air}}$$

The calibration sequence will take place periodically when all cooling or heating inputs are off. The instruction 3516 permits us to avoid the calibration.

Dynamic Defrost



This new feature patented under INPI 91.033.063 allows the unit to start the defrost cycle only when required. This is achieved through the measurement of the temperature difference between the coil and the outdoor.

The defrost will be initiated shortly after the Climatic50 has located the largest gradient in the curve.

The defrost cycle ends when one of these two condition is completed whichever comes first :

- + Three defrost cycles.
- + 6 minutes.

Alternate defrost

All dual circuits Baltic units have "Alternate Defrost" as a standard feature.


When one circuit is going through a defrost cycle the second circuit is running in heat pump mode. This reduces the need for costly electric heater to maintain the supply air temperature to an acceptable level of comfort during the defrost cycles.

CO² Sensor

Where a CO² sensor is connected to the unit, the value of the fresh air minimum is calculated according to the CO² ratio. The value measured by the sensor can be read in variable 2132.

Setpoint 3514 defines the number of ppm up to which the fresh air minimum is still achieved.

Setpoint 3515 defines the number of ppm from which 100% fresh air is used.



CONTROL INTERFACES AND DISPLAYS

DC50 COMFORT DISPLAY

This is a remote controller for non-technical customer. This display gives information such as running mode status of the fan, set point, % of fresh air and outside air temperature.

It can be used to set or change the scheduling of the different time zones, the temperature set point, and the % of fresh air for each zone. It also has the capacity to set a 3 hours override and to force the unoccupied mode for up to 7 days. It displays the real time clock and different faults signals.

Display


Type FSTN graphic
 Back light: Green LEDs
Resolution 120x32 pixels

Power Supply

Voltage from main Climatic board.
 Max power: 0.8W

Installation

- The DC50 is designed to be mounted on the wall.
- * Fit the cable from the DT50 board through the back piece
- * Fasten the back piece to the wall using the rounded head screws supplied in the packaging
- * Connect the cable from the main board on the **RJ12** plug on the back of the DC50 display
- * Fasten the front panel on the back piece using the flush head screws supplied
- Finally fit the click-on frame



Jumpers:

"Displays" are supplied directly by the Climatic board with 30Vdc. Take particular care at the path this 30V is taking when several boards are being used.

J14 and J15 can switch on or off the direct current from the power supply:

J14 and J15 set between1-2

Connectors A, B, C and screw connector SC are in parallel. Power supply available to all connectors.

J14 and J15 set between2-3



Connectors B and C are in parallel but line 1 and 6 don't reach connector A and screw connector SC.

"Displays" connected to these ports will not be powered.

If J14 and J15 are set in different positions the "terminal connection board" DT50 DOES NOT WORK.

NOTE:

When a shielded wire is used the metallic case of the "Terminal connection box" DT50 must be earthed.



Terminal connection Board installation guide DT50

The board is fitted with three "telephone" RJ12 plugs. Ensure the board is correctly connected.

- Standard connection is:
- * Climatic on connector C
 - * DC50 on connector A
 - * DS50 on connector B

Terminal display address configuration

- The address of the terminal must be checked after having powered the board.
- To access the configuration mode, press $\uparrow\downarrow\leftarrow$ together and hold them for at least 5 seconds.
- The screen shown in **Fig21** will be displayed with the cursor flashing in the top left hand corner.
- To change the address of the terminal display press the \leftarrow key once.
- Use the $\uparrow\downarrow$ keys to select the desired value and confirm by pressing \leftarrow .
- If the address was changed it will display the screen shown in **Fig22**.



Fig. 23



Fig. 21




Fig. 24



Fig. 22




Fig. 25

Assigning Terminal displays to control boards.


- Access the configuration mode by pressing $\uparrow\downarrow\leftarrow$ for at least 5 seconds.


NOTE : To access the board address menu you must go directly to the bottom of the first screen (shown in **Fig23**) without changing the terminal address as explained above.

- Press the \leftarrow key until the cursor moves to the field "I/O Board address :XX". **Fig 23**
- Use the $\uparrow\downarrow$ key to select the correct Climatic board.(N° of Unit)
- Pressing \leftarrow again will display the screen shown in **Fig 24**.
- Pressing \leftarrow again will display the screen shown in **Fig 25**.


- The field "P:XX " shows the address of the selected board. In the example the value "12" has been selected.
- The filed under the "Adr" column represents the addresses of the terminal displays associated with the board that has the address "12", while the column under "Priv/Shared " indicate the type of terminal selected.
 Ph: Private
 Sh :Shared
 Sp : Shared Printer (N/A)
- To exit the configuration procedure and save the data, select the filed "OK?NO", choose "Yes" using the $\uparrow\downarrow$ keys and confirm by pressing \leftarrow .

If the terminal remains inactive (no button is pressed) for 30 seconds, the configuration procedure is aborted automatically.





Pressing the return key on the main screen will display the following message:



Pressing the return KEY validates the choice and move to the next field
Up and down arrows gives you the choice between different things

If you choose "YES" to the first question the unit is **SWITCHED OFF** and you can not access the override menu.

WARNING : Switching Off the unit disable all safety Protections


If you choose to stop the Machine number 12 in the previous screen the following screen will then appear.



The unit can then be switched back **ON** by pressing the return key once more.

If the first choose is "NO" then the override screen can be accessed a particular time zone can be forced for up to 7 days starting from the day "TODAY".

In this menu you can choose the number of days you want the selected time zone to override.
Increase the number of days by pressing the Up or Down keys.



Clock Menu :

From main screen press the clock key, the following menu appears :


Override 3 hours :

From main screen press any of the two arrow keys as shown bellow:

Main screen :



Override menu :




It will revert back to main screen after 15 seconds, if no activity

Switching ON or OFF the unit or forcing a selected time zone for a period of up to 7 days




Clock Menu :

From main screen press the clock key, the following menu




Major Alarm




"Time Zone" Menu

From main screen press the "Prg" key, the following menu appears:



Alarm History Menu




You can scroll down this menu using the arrow keys and select one of the alarm message by pressing the return key.

It will revert back to main screen after 15 seconds if no activity.


"Scheduling" Menu

The scheduling menu can be accessed from the "time zone" menu by pressing "Prg" again



Alarm details

This menu allows you to view details on the selected fault as shown below:



Alarm screen

Filter Alarm : All keys are locked, the only way to escape this screen is to clean the filter




DS50 SERVICE DISPLAY

This new service display controller is a plug and play feature but it can also be remotely installed. Plugging the DS50 will freeze a DC50


Moving down the menus

Pressing the arrow keys allows you to move up and down the menu tree. The selected item changes to CAPITAL letter. It can then be selected by pressing the "return" or "select" key.

Keys




(0000)01 ZoneA
1-ALARM 12h44
2-Data Tuesday
3-Setting April 03




Sub-menu Data (2000)

Start up screen or Screen(1)




Menu reference



Indicates other menus below


If the menu GENERAL is selected, the controller then displays a second level sub-menu.

Screen (2) language selection





By selecting the item TEMPERATURE and pressing return, a third level page is displayed as shown below:

Five languages are available in addition to English. The required language must be specified at the time of order. In this menu the specified language can be selected using the up and down keys. The "prg" key validates the choice and start the controller.



Main menu (0000)





Pressing "ESC" at any time sends you back one level up the menu tree. In the example shown above "ESC" must be pressed 3 times to go back to the main menu (0000) Pressing "ESC" will invalidate any changes made to a value in a setting page.

Clock settings



The clock setting menu can be accessed from the main menu by selecting the menu "SETTING" and then navigating down through the sub-menus until page (3120).

Alarms



Selecting the HOUR for displays the page 3121 shown below:


Select the alarm menu using the arrow keys and press return. The faults history is then displayed in the page (1000):




Zone Settings

From Main menu (0000) navigate down to sub-menu "SETTINGS", zone settings (3310).


Pressing the "ALARM" key resets all the alarms. The number of active alarms goes to 0, no active alarm shown in the menu, the "bell" key is switched off.



In this particular page, pressing the "prg" key, changes the time zone. If "ROOM SET" is selected, this displays the room set point for the specific time zone shown in the top corner.



Pressing the "return" key will display details of the selected alarm




Pressing the "prg" validates any changes made, and move to the next time zone. "ESC" does not validate the changes and move back one step in the menu tree.

COMMUNICATION LINKS

Master / Slave

Rooftop can now be connected together (up to 12) via a double shielded pair of wire (0.75mm² not supplied by Lennox) and use different running modes, as explained bellow, with no cost increase.



	FAN	SET POINT	ROOM TEMP	COOLING HEAT MODE
1. DC50	MASTER	MASTER	N/A	N/A
2. DC50 Temperature	MASTER	STAND ALONE	MASTER	N/A
3. DC50 Average	MASTER	STAND ALONE	AVERAGE	N/A
4. Master/Slave Temperature	STAND ALONE	STAND ALONE	MASTER	N/A
5. Master/Slave Average.	STAND ALONE	STAND ALONE	AVERAGE	N/A
6. Master/Slave Cooling/Heating	STAND ALONE	STAND ALONE	STAND ALONE	MASTER
7. Back-up	All units are stand alone, one unit is waiting for a failure to start			
8 Rolling Back-up	All units are stand alone; one unit is waiting for a failure to start. This back-up unit changes every Tuesday			

_ 1 : DC50 : Master slave mode "total"

The master gives the ventilation order, and its set point to all other rooftops.

_ 2 : DC50 Temperature : Master slave mode "temperature"

The master gives the ventilation order and its room temperature/humidity to all other rooftops, but they have their own set point.

_ 3 : DC50 Average : Master slave mode "average"

The master gives the ventilation order and the room temperature/humidity used by all rooftop is the average of all rooftop. Each rooftop has its own set point.

_ 4 : Master/Slave Temperature : Master slave mode "temperature"

The master gives its room temperature/humidity to all other rooftops, but they have their own ventilation order & set point.

_ 5 : Master / Slave Average : Master slave mode "average"

rage"

The room temperature/humidity used by all rooftop is the average of all rooftop. Each rooftop has its own ventilation order & set point.

_ 6 : Master / Slave Cooling / Heating : Master slave mode "cooling/heating"

All rooftop are stand-alone but the slaves have to have the same running mode as the master (Cooling or heating).


_ 7 : Back-up mode

One rooftop is the back-up unit and will operate if any of the other rooftop has a failure.


_ 8 : Rolling Back-up mode

Same as above, except the "back-up" unit will be different each Tuesday. On top of that, the outside temperature/humidity given to all rooftop can either be the average of rooftop or be the external humidity/temperature of the master, making possible the use of a single "weather station" for the whole site. DS50 Comfort Display / DC50 Service Display

DS 50 : SERVICE DISPLAY / DC 50 : COMFORT DISPLAY



CLIMALINK / CLIMALOOK





Main Screen	Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory	Max
1-Alarm	1000	#	1100	#	1110	#	1111				
2-Data	2000	1-General	2100	1-Temperature	2110	Outside	2111	°c			
						Room	2112	°c			
						Supply	2113	°c			
						Return	2114	°c			
			2120	2-Humidity	2120	Outside	2121	%.			
						Room	2122	%.			
						Outside	2123	g/Kg			
						Room	2124	g/Kg			
			2130	3-Other	2130	Air Pres.	2131	pa			
						CO2	2132	ppm			
						Sw On/Off	2133	On/Off			
						Sw Reset	2134	On/Off			
						Sw Unoc.	2135	On/Off			
			2140	4-Out. Custom.	2140	BM50.1	2141	On/Off			
						BE50.1	2142	On/Off			
						BE50.2	2143	On/Off			
						BE50.3	2144	On/Off			
						BE50.4	2145	On/Off			
			2150	5-In. Custom.	2150	BM50.1	2151	On/Off			
						BM50.2	2152	On/Off			
						BE50.1	2153	On/Off			
						BE50.2	2154	On/Off			
						BE50.3	2155	On/Off			
						BE50.4	2156	On/Off			
			2160	6-In.% Custom.	2160	BE50.1	2161	°c			
						BE50.2	2162	°c			
						BE50.3	2163	°c			
						BE50.4	2164	°c			
						BE50.1	2165	%.			
						BE50.2	2166	%.			
						BE50.3	2167	%.			
						BE50.4	2168	%.			
		2-Control	2200	1-Room	2210	Sp Cool	2211	°c			
						Sp Heat	2212	°c			
						Capa Cool	2213	%			
						Capa Heat	2214	%			
						Sw Dis.Cool	2215	On/Off			
						Sw Dis.Heat	2216	On/Off			
			2220	2-Reheat	2220	Set Point	2221	°c			
						Capacity	2222	%			
			2230	3-Humidity	2230	Sp Dehu	2231	%			
						Sp Humi	2232	%			
						Capa Dehu	2233	%			
						Capa Humi	2234	%			
			2240	4-TCB	2240	Sw G	2241	On/Off			
						Sw Y1	2242	On/Off			
						Sw Y2	2243	On/Off			
						Sw W1	2244	On/Off			
						Sw W2	2245	On/Off			
						Sw B	2246	On/Off			



Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory Max	Description
3-Fan	2300 1-Ventilation	2310	Config. State	2311	List					[No / 500pa / 100pa]
		2312	Sw State	2313	On/Off					[Stopped / Schedule / Fault / Start]
		2314	Fire/Smoke Relay	2315	On/Off					
		2316	Low Speed	2317	On/Off					
		2320	State Relay	2321	List					[Stopped / Schedule / Fault / Start]
		2322	Relay	2322	On/Off					
		2330	Config. State	2331	List					[No / Yes]
3-Condenser 1		2332	Sw State	2333	On/Off					[Stopped / Schedule / Fault / Start]
		2334	Relay	2334	On/Off					
		2340	Config. State	2341	List					[No / Yes]
		2342	Sw State	2343	On/Off					[Stopped / Schedule / Fault / Start]
4-Condenser 2		2344	Relay	2344	On/Off					
		2350	Config. State	2351	List					[No / Yes]
		2352	Sw State	2353	On/Off					[Stopped / Schedule / Fault / Start]
		2354	Relay	2354	On/Off					
5-Condenser 3		2360	Config. State	2361	List					[No / Yes]
		2362	Sw State	2363	On/Off					[Stopped / Schedule / Fault / Start]
		2364	Relay	2364	On/Off					
		2400	Config. State	2411	List					[No / 0%-50% / Modulation / 100%]
4-Cooler	2400 1-Fresh Air	2412	State	2412	List					[Stopped / Air Flow / Start / Enthalpy / Outside T. / Schedule / Defrost]
		2413	Mini.Air	2413	%					
		2414	Modulat.	2414	%					
		2415	Opening	2415	%					
		2416	Calib.	2416	Yes/No					



Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory Max	Description	
	2-Cold W/Coil	2420	Config.	2421	List		List			[No / Modulation]	
			State	2422	List		List			[Stopped / Air Flow / Start]	
			Opening	2423	%		%				
5-Compressor	2500 1-Compressor 1	2510	Config.	2511	List		List			[No / C. only / H.only]	
			State	2512	List		List			[Stopped / Air Flow / Outside T. / Schedule / Switch / Fault (1) / Ant-Sho-Cy / Start / Start Heat / Defrost]	
			Defrost T	2513	°c		°c				
			Sw State	2514	On/Off		On/Off				
			Sw Low P.	2515	On/Off		On/Off				
			Relay	2516	On/Off		On/Off				
			H.Pump	2517	On/Off		On/Off				
			Sw Disable	2518	On/Off		On/Off				
			Run Time	2519	h		h				
2-Compressor 2		2520	Config.	2521	List		List				
			State	2522	List		List				
			Defrost T.	2523	°c		°c				
			Sw State	2524	On/Off		On/Off				
			Sw Low P.	2525	On/Off		On/Off				
			Relay	2526	On/Off		On/Off				
			H.Pump	2527	On/Off		On/Off				
			Sw Disable	2528	On/Off		On/Off				
			Run Time	2529	h		h				
					Config.	2531	List		List		
3-Compressor 3		2530	State	2532	List		List				
			Defrost T.	2533	°c		°c				
			Sw State	2534	On/Off		On/Off				
			Sw Low P.	2535	On/Off		On/Off				
			Relay	2536	On/Off		On/Off				
			H.Pump	2537	On/Off		On/Off				
			Sw Disable	2538	On/Off		On/Off				
			Run Time	2539	h		h				



Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory Max	Description
	4-Compressor 4	2540	Config. State	2541	List		List			
			Defrost T.	2542	List		List			
			Sw State	2543	°c		°c			
			Sw Low P.	2544	On/Off		On/Off			
			Relay	2545	On/Off		On/Off			
			H.Pump	2546	On/Off		On/Off			
			Sw Disable	2547	On/Off		On/Off			
			Run Time	2548	On/Off		On/Off			
				2549	h		h			
	5-Other	2550	Low Amb.	2551	On/Off		On/Off			
			W/Cond.1	2552	°c		°c			
			W/Cond.2	2553	°c		°c			
6-Heater	2600 1-Gas	2610	Config. State	2611	List		List			[No / 2 steps / 4steps / Modulation]
			Sw State 1	2612	List		List			[Stopped / Air Flow / Schedule / Switch / Fault (1) / Fault (2)]
			Sw State 2	2613	On/Off		On/Off			
			Relay 1	2614	On/Off		On/Off			
			Relay 2	2615	On/Off		On/Off			
			High	2616	On/Off		On/Off			
			Modulat.	2617	On/Off		On/Off			
			Sw Disable	2618	%		%			
				2619	On/Off		On/Off			
	2-Elec. H.	2620	Config. State	2621	List		List			[No / Yes / 2 steps / Modulation]
			Sw State 1	2622	List		List			[Stopped / Air Flow / Outside T. / Schedule / Switch / Fault (1) / Start]
			Sw State 2	2623	On/Off		On/Off			
			Relay 1	2624	On/Off		On/Off			
			Relay 2	2625	On/Off		On/Off			
			Modulat.	2626	On/Off		On/Off			
			Sw Disable	2627	%		%			
				2628	On/Off		On/Off			

Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory Max	Description	
3-Hot W/Coil		2630	Config. State	2631	Config. State	2632	List			[No / Modulation]	
				2633	Opening	2634	Sw Freeze	%			[Stopped / Air Flow / Start / Schedule / Switch / Fault (1) / Fault (2)]
				2635	Sw Disable			On/Off			
				2640	Config. State	2641	Config. State	List			[No / Yes]
				2643	Sw State Relay	2644	Sw State Relay	On/Off			[Stopped / Air Flow / Fault (1) / Start]
4-Pump		2710	Config. State	2711	Config. State	List				[No / Modulation]	
				2712	Sw State	2713	Sw State	List			[Stopped / Air Flow / Schedule / Fault (1) / Start]
				2714	Modulat.			On/Off			
				2810	Value	2811	Value	%			
7-Humidif.	1-Outside	2810	Value	2811	Sensor	2812	°C				
				2813	Link	2814	BMS	°C			
				2815	Value	2816	Sensor	%			
				2817	Link	2818	Link	%			
				2820	Value	2821	Value	°C			
				2822	Sensor	2823	Sensor	°C			
				2824	Link	2825	Link	°C			
				2826	BMS	2827	BMS	°C			
				2828	Value			%			
					Sensor			%			
8-Com. 2800	2-Room	2820	Value	2821	Sensor	2822	°C				
				2823	Link	2824	Link	°C			
				2825	BMS	2826	BMS	°C			
				2827	Value	2828	Value	%			

ALL CODES SHOWING (1) CAN BE ADJUSTED FOR EACH TIME ZONE



Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory	Max	Description	
3-Setting	1-General	3100	1-Order	3110	On/Off	3111	On/Off	~	No	~	[On / Off] Unit	
					Reset Al.	3112	Yes/No	~	No	~	[Reset] Discharges the safety measures of the unit	
					Resume	3113	Yes/No	~	No	~	[Override] Cancel any override action set with the DC50	
					Test	3114	List	0	0	6	[Quickly / Defrost / Gas 1 Low / Gas 1 High / Gas 2 / 24/24 7/7 / Lennox] Test Point Lennox	
					3120							
				2-Clock	3121	Hour	h	0	~	23	[Clock] Clock setting "Hour"	
					3122	Minute	m	0	~	59	[Clock] Clock setting "Minute"	
					3123	Day	~	1	~	31	[Clock] Clock setting "Day"	
					3124	Month	~	1	~	12	[Clock] Clock setting "Month"	
					3125	Year	~	2	~	99	[Clock] Clock setting "Year"	
				3126	Win/Sum	Yes/No	~	Yes	~	~	Automatic control of Winter & Summer zone or Not	
2-Schedule	1-Time	3200	Start Uno	3211	Start Uno	h	0	22	23		[Zone Setting] Starting time "Hour" for "Unoccupied" zone	
					Start.Uno	3212	m	0	0	59		[Zone Setting] Starting time "Minutes" for "Unoccupied" zone
					Start z.A	3213	h	0	6	23		[Zone Setting] Starting time "Hour" for "Zone A"
					Start.z.A	3214	m	0	0	59		[Zone Setting] Starting time "Minutes" for "Zone A"
					Start z.B	3215	h	0	22	23		[Zone Setting] Starting time "Hour" for "Zone B"
				Start.z.B	3216	m	0	0	59		[Zone Setting] Starting time "Minutes" for "Zone B"	
				Start z.C	3217	h	0	22	23		[Zone Setting] Starting time "Hour" for "Zone C"	
				Start.z.C	3218	m	0	0	59		[Zone Setting] Starting time "Minutes" for "Zone C"	
				Foot	3221	Foot	°C	-10	10	20		[Anticipation Function] bottom of the slope in °C. Limit of activation of the function. This allows an anticipated startup in the morning depending on the outdoor temperature. Only for the "Zone-A"
				2-Anticipation	3220	Gradient	m/°C	0	0	100		[Anticipation Function] Slope in "Minutes of anticipation per degrees". This allows an anticipated startup in the morning depending on the outdoor temperature. Only for the "Zone-A"



Main Screen Code	Description	Code	Description	Code	UNIT	Min	Factory	Max	Description
3-Control	1-Customer	3310	Sp Room	3311	°C	8	20	35	[Room SP] Required room temperature set point in °C. Middle of the dead zone.
			Mini.Air	3312	%	0	20	100	[Room SP] Required room minimum fresh air rate in % Middle of the dead zone.
2-Room		3320	Sp Dyna	3321	°C	0	99.9	99.9	[Room SP] Required value for the Dynamic Set Point. Allows the room set point to change according to outdoor temperature
			Sp Cool	3322	°C	8	21	35	[Room SP] Required maximum room emperature in °C. Cooling set point
			Sp Heat	3323	°C	8	19	35	[Room SP] Required minimum room temperature in °C. Heating set point
			Swap Heater	3324	Yes/No	~	No	~	[OFF] Heat Pump and then Heater [ON] Heater and then Heat Pump
3-Reheat		3330	Activation	3331	Yes/No	~	No	~	[F-Air Reheat] Activate reheating of the fresh air in the dead zone to maintain supply temperature.
			Swap Heater	3332	Yes/No	~	No	~	[F-Air Reheat] Prioritise the heating mode for fresh air reheat. [OFF] Heat Pump and then Heater [ON] Heater and then Heat Pump
4-Humidity		3340	Sp Dehu	3341	%	0	100	100	[Humidity] Desired Maximum relative humidity in Room (in %). - Dehumidification set point.
			Sp Humi	3342	%	0	0	100	[Humidity] Desired Minimum relative humidity in Room (in %). - Humidification set point.
5-Enable		3350	Fan On/Off	3351	Yes/No	~	Yes	~	[Enable] Stopping and running of the Fan Blower.[OFF] the blower is stopped, [ON] the blower is running.
			Fan Dead	3352	Yes/No	~	Yes	~	[Enable] Stopping and running of the fan in the "Control Dead Zone". [OFF] the blower is stopped, [ON] the blower is running.
			F.Air	3353	Yes/No	~	Yes	~	[Enable] Run eco: [ON] the Economiser is running, [OFF] the Economiser if stopped.
			CO2	3354	Yes/No	~	Yes	~	[Enable] Run CO2 Sensor: [ON] Switch-on the CO2 on a Zone, [OFF] Stop the CO2 sensor on a zone.
			Comp.Cool.	3355	Yes/No	~	Yes	~	[Enable] [OFF] Force the unloading of compressors in cooling mode.
			Comp.Heat.	3356	Yes/No	~	Yes	~	[Enable] [OFF] Force the unloading of compressors in heating mode.
			AuxHeat	3357	Yes/No	~	Yes	~	[Enable] [OFF] Force the unloading of heating module (electric, gas or heat water coil)
			Humidif.	3358	Yes/No	~	Yes	~	[Enable] [OFF] Force the unloading of humidity control.
			Low Noise	3359	Yes/No	~	No	~	[Enable] Force the noise reduction mode. [ON] 50% of the compressors are unloaded in "Unoccupied" zone



Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory Max	Description
6-Capacity	Room	3360	Room	3361	~	1	4	50	[Capacity Factor] Reactivity : Refer to "Control Software Features" p 54	
	Reheat		Reheat	3362	~	1	4	50	[Capacity Factor] Reactivity: Refer to "Control Software Features" p 54	
	Dehu.		Dehu.	3363	~	1	4	50	[Capacity Factor] Reactivity: Refer to "Control Software Features" p 54	
	Humi.		Humi.	3364	~	1	4	50	[Capacity Factor] Reactivity: Refer to "Control Software Features" p 54	
7-Safety	Room Low	3370	Room Low	3371	°C	5	5	20	[Safety Limit] Room temperature "Low Limit" in °C	
	Room High		Room High	3372	°C	20	40	40	Threshold of activation of an alarm [Safety Limit] Room temperature "High Limit" in °C Threshold of activation of an alarm	
	Sup.Lo.1		Sup.Lo.1	3373	°C	9or5	10or8	19	[Safety Limit] Supply temperature low Limit(in °c) - Threshold of activation of the 1° level of security: Reduce the Capacity Factor by one stage of compressor and switch to minimum Fresh Air.	
	Sup.Lo.2		Sup.Lo.2	3374	°C	7 or 3.8	or 6	17	[Safety Limit] Supply temperature low Limit (in °c) - Threshold of activation of the 2° level of security: Reduce the Capacity Factor to zero and switch to 0% Fresh Air, open the HWC valve.	
	Sup.Lo.3		Sup.Lo.3	3375	°C	5 or 1.6	or 2	15	[Safety Limit] Supply temperature low Limit (in °c) - Threshold of activation of the 3° level of security. - Alarm threshold, the unit is switched off.	
	Sup.Hi.1		Sup.Hi.1	3376	°C	20	40	70	[Safety Limit] Supply temperature high Limit (in °c) Threshold of activation of the 1° level of security: reduce the capacity factor by one stage of compressor. Close the HWC valve.	
	Sup.Hi.2		Sup.Hi.2	3377	°C	20	60	70	[Safety Limit] Supply temperature high Limit (in °c) - Threshold of activation of the 2° level of security: Alarm threshold: Reduce the capacity factor to 0	
	Room Low		Room Low	3378	%	0	0	1000	[Safety Limit] Room relative humidity low Limit (in %) - Threshold of activation of the alarm	
	Room High		Room High	3379	%	0	1000	1000	[Safety Limit] Room humidity high Limit (in %) - Threshold of activation of the alarm	
	4-Ventilation	Air Flow	3410	Air Flow	3411	pa	0	25	1000	[Safety Limit] Airflow Detection Threshold of pressure difference in Pa indicating Low Airflow Rate. If the pressure difference across the filter is lower than this threshold the safety is activated.
		No Filter		No Filter	3412	pa	0	50	1000	[Safety Limit] Missing Filters. Threshold of pressure difference in Pa indicating absence of filters. If the pressure difference across the filter is lower than this threshold the safety is activated.
		Dirty Fil.		Dirty Fil.	3413	pa	0	250	1000	[Safety Limit] Dirty Filters. Threshold of pressure difference in Pa indicating Filters are Dirty. If the pressure difference across the filter is Higher than this threshold the safety is activated.



Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory	Max	Description
5-Fresh Air	3500	..	3510	Out.Limit	3511	°c	-20	-20	40	[Fresh air Damper] minimum outdoor temperature limit in °C. If the outdoor temperature is lower than this limit the control in free cooling is not allowed. The fresh air damper is then set to the minimum setting.	
		..		Maximum	3512	%	0	100	100	[Fresh air Damper] Maximum allowable opening of the fresh air damper in %	
		..		Start Ext	3513	%	0	30	100	[Extraction] Threshold of activation of the power exhaust fan according to the position of the economiser damper in %.	
		..		Mini.Co2	3514	ppm	0	1000	2000	[CO2] Fresh air damper minimum opening threshold in ppm	
		..		Maxi.Co2	3515	ppm	0	1500	2000	[CO2] Fresh air damper maximum opening limit in ppm	
		..		Calib.	3516	Yes/No	~	Yes	~	Allow the calibration of the minimum fresh air.	
		..		Recovery	3517	Yes/No	~	No	~	[NO/YES] Heat recovery	
6-Compressor	3600	1-Out.Limit	3610	Cool. 50	3611	°c	-10 or 10	20	40	[Limit of Regulation] * 1° If Option Regulation all seasons - Reduction speed of the fans condenser - Threshold of outside temperature (in °c). - If the outside temperature is lower than this threshold the fans condenser function in low speed * 2° If not - Unloading 50% of the Compressors in Cooling - Threshold of outside temperature (in °c). - If the outside temperature is lower than this threshold 50% of the compressors are used by the Regulation [Limit of Regulation] * 1° If Option Regulation all seasons - Stopping of the fans condenser - threshold of outside temperature (in °c). - If the outside temperature is lower than this threshold the fans condenser are stopped * 2° If not - Unloading 100% of the Compressors in Cold - Threshold of outside temperature (in °c). - If the outside temperature is lower than this threshold the compressors are not used by the Regulation	
				Cool.100	3612	°c	-10 or 10	12	40	[Limit of Regulation] Unloading 100% of the Compressors in Heating - Threshold of outside temperature (in °c). - If the outside temperature is lower than this threshold the compressors are not used by the Regulation	
				Heat.100	3613	°c	-50	-20	40	[Limit of Regulation] Unloading 100% of the Compressors in Heating - Threshold of outside temperature (in °c). - If the outside temperature is lower than this threshold the compressors are not used by the Regulation.	



Main Screen Code	Description	Code	Description	Code	UNIT	Min	Factory	Max	Description
	2-Defrost	3620	Type	3621	List	0	0	1	[Function Defrost] Choice of defrost: 1 = "cycling" or 0 = dynamic
			Outside	3622	°c	8	10	20	[Function Defrost] Authorization of defrost - Threshold of outside temperature (in °c)
			Coil	3623	°c	-10	-2	10	[Function Defrost] Authorization of defrost - Threshold of coil temperature (in °c)
			Time Limit	3624	m	30	45	90	[Function Defrost] Time limit for icing (in minute) -For the dynamic defrost the unit will run this minimum amount of time. If cycling defrost this is the time delay to start the defrost once the temperature conditions are met.
			Time Fc	3625	~	1	3	5	[Function Defrost] Number of condenser fan start-ups to end defrost. If the number of start-ups can not be achieved within 4min the defrost will end.
	3-Safety	3630	W/Cd Mini	3631	°c	4	5	20	[Safety limit] Low Temperature Limit for water heat exchanger output (in °c) - Threshold of activation of the safety limit.
			W/Cd Maxi	3632	°c	20	45	46	[safety limit] High Temperature Limit for water heat exchanger output (in °c) - Threshold of activation of the safety limit.
7-Heater	1-Gas	3700	.	3710					
	2-Elec. H.	3720	Out.Limit	3721	°c	-20	10	40	[Limit of Regulation] Unloading 100% of heaters - Threshold of outside temperature (in °c). If the outside temperature is higher than this threshold Heaters are switched off.
			Sp Mixing	3722	°c	0	5	10	[Electrical heater] Regulation all seasons of FLEXY FX - Threshold of temperature of mixture (in °c) - If the temperature of mixture is lower than this threshold Electrical Heaters are activated
			Maximum	3723	%	0	100	100	[Electrical heater] For Electric Heater with Triac: Maximum power of use of Electrical heater (in %)
	3-Hot W/Coil	3730	Out.Limit	3731	°c	-20	10	40	Authorise a leak-flow
			Opening	3732	%	0	0	50	
			A.Freeze	3733	List	0	0	?	[0% / 100%] Open or close the V3V
	4-Pump	3740	Mode	3741	List	0	0	?	[No/Frost.Al./Start heat/Start] Choose startup mode for the pump



Main Screen Code	Description	Code	Description	Code	Description	UNIT	Min	Factory	Max	Description
8-Config.	3800 1-Unit	3810	Range	3811	List	0	6	?	Type of unit: BC, BH, BGN, BG, BD, FC, FH, FGN, FG, FD, FX or FW	
			Size	3812	List	0	0	?	See table n° 5	
			Hu. Pack	3813	Yes/No	~	No	~	[Configuration] Activation of the Humidity Management Option	
			TCB	3814	Yes/No	~	No	~	[Configuration] Configuration of the Thermostat Control Board.	
	2-Compressor	3820	LAK	3821	Yes/No	~	No	~	[Configuration] Low Ambient Kit "all season control"	
			Wat/Cond	3822	Yes/No	~	No	~	[Configuration] Activation of the "Optimized Defrost" Option. Only for Flexy 85_100 with split airflow.	
			085/100 +	3823	Yes/No	~	No	~		
	3-Option	3830	AuxHeat	3831	List	0	0	6	[Configuration] Configuration of the Heating Input: HWC; Electric Heater S/M/H or Gas 2/4/2 pro. /4 pro. For 20kW ' 60kW choose "gas 2"; for 120kW ' 180kW choose "gas 4"; "pro." means modulating gas	
			F.Air	3832	List	0	0	3	[Configuration] Configuration of the Fresh Air / Economiser: NO, 100% fixed or 0-50% or 0-100% Modulating.	
			P. Air	3833	List	0	0	2	[Configuration] Configuration of the differential pressure sensor: 0Pa; 500Pa; 1000Pa	

Main Screen Code	Description	Code	Description	Code	Description	UNIT	Min	Factory	Max	Description
	4-Out. Custom.	3840	BM50.1	3841	BM50.1	List	0	0	6	[Configuration] Free output to be customised on the BM50
			BE50.1	3842	BE50.1	List	0	0	6	[Configuration] Free output to be customised (first output of the extension board BE50)
			BE50.2	3843	BE50.2	List	0	0	6	[Configuration] Free output to be customised (Second output of the extension board BE50)
			BE50.3	3844	BE50.3	List	0	0	6	[Configuration] Free output to be customised (Third output of the extension board BE50)
			BE50.4	3845	BE50.4	List	0	0	6	[Configuration] Free output to be customised (Fourth output of the extension board BE50)
	5-In. Custom.	3850	BM50.1	3851	BM50.1	List	0	0	8	[Configuration] Free input to be customised on the BM50
			BM50.2	3852	BM50.2	List	0	0	8	[Configuration] Free input to be customised on the BM50
			BE50.1	3853	BE50.1	List	0	0	8	[Configuration] Free input to be customised (input on the extension board BE50)
			BE50.2	3854	BE50.2	List	0	0	8	[Configuration] Free input to be customised (input on the extension board BE50)
			BE50.3	3855	BE50.3	List	0	0	8	[Configuration] Free input to be customised (input on the extension board BE50)
			BE50.4	3856	BE50.4	List	0	0	8	[Configuration] Free input to be customised (input on the extension board BE50)
	6-In.% Custom.	3860	BE50.1	3861	BE50.1	List	0	0	4	[Configuration] Free input to be customised on the BM50
			BE50.2	3862	BE50.2	List	0	0	4	[Configuration] Free input to be customised on the BM50
			BE50.3	3863	BE50.3	List	0	0	4	[Configuration] Free input to be customised (input on the extension board BE50)
			BE50.4	3864	BE50.4	List	0	0	4	[Configuration] Free input to be customised (input on the extension board BE50)



Main Screen Code	Description	Code	Description	Code	Description	Code	UNIT	Min	Factory	Max	Description
9-Com.	3900 1-Display	3910	Sp Mini.	3911	°C	8	17	21	[Mode] Minimum temperature for the required room temperature set point at the middle of the dead zone.		
			Sp Maxi.	3912	°C	21	27	35	[Mode] Maximum temperature for the required room temperature set point at the middle of the dead zone.		
			Offset	3913	°C	-5	0	5	Offset of the value measured by the ambient temperature sensor		
			Standard Sp	3914	Yes/No	~	No	~	Allows a reset of ALL set point to standard factory settings (when available).No possible for configurations. And clock as there is no factor settings for these.		
<hr/>											
2-Link											
		3920	ID	3921	~	1	1	12	[Configuration] Identification address for the unit from 1 to 12.		
			Number	3922	~	1	1	12	[Configuration] Number of units on the BUS.		
			Type.	3923	List	0	0	6	Unit with address N°1 is always the master.		
			Type	3924	List	0	0	2	Master / Slave relationship: refer to "Control Communication Links" p 63 Configuration of the sharing of the Outdoor humidity and temperature.		
<hr/>											
3-BMS											
		3930	ID	3931	~	1	1	200	[Configuration] Identification number on the 485 Bus		
			Type	3932	List	0	2		Climatic, ModBus or LonWorks		
			Baud	3933	List	3	4		1200, 2400, 4800, 9600 or 19200		
			Watchdog	3934	~	0	0	1000	[BMS] Activation of the control by a computer or an automat - mode BMS is activated if this value is different from zero, This value is decreased every second		
			BMS Unoc.	3935	On/Off	~	Off	~	[BMS] Cancel the override unoccupied mode		
			Speed	3936	On/Off	~	Off	~	Blower Speed Control in the dead zone: [ON] the unit runs in Low Speed mode [OFF] the unit runs in High Speed mode		



UNIT RANGES

FLEXY											
BALTIC											
BCK	BHK	BGK	BDK	BGN	FCK	FHK	FGK	FDK	FXK	FGN	FWN
BCK020NS	BHK020NS	BGK020SS	BDK020SS	BGN001S	FCK085	FHK085	FGK085S	FDK085S	FXK025	FGN002S	FWN002S
BCK025NS	BHK025NS	BGK025SS	BDK025SS	BGN001H	FCK100	FHK100	FGK100S	FDK100S	FXK030	FGN003S	FWN003S
BCK030NS	BHK030NS	BGK030SS	BDK030SS		FCK120	FHK120	FGK120S	FDK120S	FXK035	FGN004S	FWN004S
BCK035NS	BHK035NS	BGK035SS	BDK035SS		FCK140	FHK140	FGK140S	FDK140S	FXK040	FGN005S	FXN005S
BCK040NS	BHK040NS	BGK040SS	BDK040SS		FCK160	FHK160	FGK160S	FDK160S	FXK055	FGN002H	FWN002H
BCK045NS	BHK045NS	BGK045SS	BDK045SS		FCK190	FHK190	FGK190S	FDK190S	FXK070	FGN003H	FWN003H
BCK030ND	BHK030ND	BGK030SD	BDK030SD				FGK085H	FDK085H	FXK085	FGN004H	FWN004H
BCK035ND	BHK035ND	BGK035SD	BDK035SD				FGK100H	FDK100H	FXK100	FGN005H	FWN005H
BCK040ND	BHK040ND	BGK040SD	BDK040SD				FGK120H	FDK120H	FXK110		
BCK045ND	BHK045ND	BGK045SD	BDK045SD				FGK140H	FDK140H	FXK140		
BCK050ND	BHK050ND	BGK050SD	BDK050SD				FGK160H	FDK160H	FXK170		
BCK060ND	BHK060ND	BGK060SD	BDK060SD				FGK190H	FDK190H			
BCK070ND	BHK070ND	BGK070SD	BDK070SD								
		BGK020HS	BDK020HS								
		BGK025HS	BDK025HS								
		BGK030HS	BDK030HS								
		BGK035HS	BDK035HS								
		BGK040HS	BDK040HS								
		BGK045HS	BDK045HS								
		BGK030HD	BDK030HD								
		BGK035HD	BDK035HD								
		BGK040HD	BDK040HD								
		BGK045HD	BDK045HD								
		BGK050HD	BDK050HD								
		BGK060HD	BDK060HD								
		BGK070HD	BDK070HD								



MODBUS Settings and Readings

@ (hexa)	@ (deci)				DS50
01H	1	R/W	L	[On / Off] Unit	3111
02H	2	R/W	L	[Reset] Discharges the safety measures of the unit	3112
03H	3	R/W	L	[Enable] Stopping and running of the Fan Blower.[Off] the blower is stopped, [On] the blower is running.	3351 (BMS)
04H	4	R/W	L	[Enable] Stopping and running of the fan in the "Control Dead Zone". [Off] the blower is stopped, [On] the blower is running.	3352 (BMS)
05H	5	R/W	L	[BMS] Activation of the Inoccupation mode [Off] occupation mode - [On] inoccupation mode	3933
06H	6	R/W	L	[Room regulation] Choices of the priority of regulation in Heating - [Off] Heat Pump then Hot water coil or Electric or Gas [On] Hot water coil or Electric or Gas then Heat Pump	3324 (BMS)
07H	7	R/W	L	[F-Air Reheat] Activate reheating of the fresh air in the dead zone to maintain supply temperature.	3331 (BMS)
08H	8	R/W	L	[F-Air Reheat] Choices of the priority of regulation in Heating - [Off] Heat Pump then Hot water coil or Electric or Gas [On] Hot water coil or Electric or Gas then Heat Pump	3332 (BMS)
09H	9	R/W	L	[Enable] Run eco: [On] the Economiser is running, [Off] the Economiser if stopped.	3353 (BMS)
0AH	10	R/W	L	[Enable] Run CO2 Sensor: [On] Switch-on the CO2 control on a Zone, [Off] Stop the CO2 control on a zone.	3354 (BMS)
0BH	11	R/W	L	[Enable] [OFF] Force the unloading of compressors in cooling mode.	3355 (BMS)
0CH	12	R/W	L	[Enable] [OFF] Force the unloading of compressors in heating mode.	3356 (BMS)
0DH	13	R/W	L	[Enable] [OFF] Force the unloading of heating module (electric, gas or heat water coil)	3357 (BMS)
0EH	14	R/W	L	[Enable] [OFF] Force the unloading of humidity control.	3358 (BMS)
0FH	15	R/W	L	not used	
10H	16	R/W	L	[Clock] [OFF] read hour & minute [ON] write hour & minute	...

R = Read
W = Write
L = Logical



MODBUS Settings and Readings

@ (hexa)	@ (deci)				DC50
11H	17	R/W	L	[Dry contact] Digital Output, Free 1, BM50-J17-NO12	2141
12H	18	R/W	L	[Dry contact] Digital Output, Free 2, BE50-J5-NO1	2142
13H	19	R/W	L	[Dry contact] Digital Output, Free 3, BE50-J6-NO2	2143
14H	20	R/W	L	[Dry contact] Digital Output, Free 4, BE50-J7-NO3	2144
15H	21	R/W	L	[Dry contact] Digital Output, Free 5, BE50-J8-NO4	2145
16H	22	R/W	L	not used	
17H	23	R/W	L	not used	
18H	24	R/W	L	not used	
19H	25	R/W	L	not used	
1AH	26	R/W	L	not used	
1BH	27	R/W	L	not used	
1CH	28	R/W	L	not used	
1DH	29	R/W	L	not used	
1EH	30	R/W	L	not used	
1FH	31	R/W	L	not used	
20H	32	R/W	L	not used	
21H	33	R	L	[Alarm] General	1000
22H	34	R	L	[On/Off] Fan, Blower	2315
23H	35	R	L	[On/Off] Fan, Extraction	2321
24H	36	R	L	[On/Off] Compressor, 1	2516
25H	37	R	L	[On/Off] Compressor, Heat pump, 1	2517
26H	38	R	L	[On/Off] Compressor, 2	2526
27H	39	R	L	[On/Off] Compressor, Heat pump, 2	2527
28H	40	R	L	[On/Off] Compressor, 3	2536
29H	41	R	L	[On/Off] Compressor, Heat pump, 3	2537
2AH	42	R	L	[On/Off] Compressor, 4	2546
2BH	43	R	L	[On/Off] Compressor, Heat pump, 4	2547
2CH	44	R	L	[On/Off] Gas, Burner, 1	2615
2DH	45	R	L	[On/Off] Gas, Burner, 2	2616
2EH	46	R	L	[On/Off] Gas, Burner, High power, 1	2617
2FH	47	R	L	[On/Off] Electrical heaters, 1	2625
30H	48	R	L	[On/Off] Electrical heaters, 2	2626
31H	49	R	L	[Dry contact] Digital Input, Free 1, BM50-J8-ID13	2151
32H	50	R	L	[Dry contact] Digital Input, Free 2, BM50-J8-ID14	2152
33H	51	R	L	[Dry contact] Digital Input, Free 3, BE50-J4-ID1	2153
34H	52	R	L	[Dry contact] Digital Input, Free 4, BE50-J4-ID2	2154
35H	53	R	L	[Dry contact] Digital Input, Free 5, BE50-J4-ID3	2155
36H	54	R	L	[Dry contact] Digital Input, Free 6, BE50-J4-ID4	2156
37H	55	R	L	not used	
38H	56	R	L	not used	
39H	57	R	L	not used	
3AH	58	R	L	not used	
3BH	59	R	L	not used	
3CH	60	R	L	not used	
3DH	61	R	L	not used	
3EH	62	R	L	not used	
3FH	63	R	L	not used	
40H	64	R	L	not used	

MODBUS Settings and Readings

@ (hexa)	@ (deci)				DS50
01H	1	R/W	1 = 1 s	[BMS] Activation of the control by a computer or an automat - mode BMS is activated if this value is different from zero, This value is decreased every second	3932
02H	2	R/W	10 = 1.0°C	[Occupation][Room SP] Required maximum room temperature in °C. Cooling set point	3322 (BMS)
03H	3	R/W	10 = 1.0°C	[Occupation][Room SP] Required minimum room temperature in °C. Heating set point	3323 (BMS)
04H	4	R/W	1 = 1%	[Room SP] Required room minimum fresh air rate in % Middle of the dead zone.	3312 (BMS)
05H	5	R/W	10 = 1.0°C	[Inoccupation][Room SP] Required maximum room temperature in °C. Cooling set point	3322 (Uno)
06H	6	R/W	10 = 1.0°C	[Inoccupation][Room SP] Required minimum room temperature in °C. Heating set point	3323 (Uno)
07H	7	R/W	1 = 1%	[Humidity] Desired Maximum relative humidity in Room (in %). – Dehumidification set point.	3341 (BMS)
08H	8	R/W	1 = 1%	[Humidity] Desired Minimum relative humidity in Room (in %). – Humidification set point.	3342 (BMS)
09H	9	R/W		not used	
0AH	10	R/W		not used	
0BH	11	R/W		not used	
0CH	12	R/W	1 = 1h	[Clock] Hour	3121
0DH	13	R/W	1 = 1m	[Clock] Minute	3122
0EH	14	R/W	1 = 1	[Clock] Day of the month	3123
0FH	15	R/W	1 = 1	[Clock] Month	3124
10H	16	R/W	1 = 2001	[Clock] Year	3125
11H	17	R/W	10 = 1.0°C	[BMS] Room temperature coming from the BMS	2824
12H	18	R/W	10 = 1.0%	[BMS] Room humidity coming from the BMS	2828
13H	19	R/W	10 = 1.0°C	[BMS] Outdoor temperature coming from the BMS	2814
14H	20	R/W	10 = 1.0%	[BMS] Outdoor humidity coming from the BMS	2818
15H	21	R/W		not used	
16H	22	R/W		not used	
17H	23	R/W		not used	
18H	24	R/W		not used	
19H	25	R/W		not used	
1AH	26	R/W		not used	
1BH	27	R/W		not used	
1CH	28	R/W		not used	
1DH	29	R/W		not used	
1EH	30	R/W		not used	
1FH	31	R/W		not used	



MODBUS Settings and Readings

@ (hexa)	@ (deci)				DS50
20H	32	R/W		not used	
21H	33	R	1 = 1	[Alarm] Code Error	1000
22H	34	R	10 = 1.0°C	[Temperature] Room	2112
23H	35	R	10 = 1.0°C	[Temperature] Outdoor	2111
24H	36	R	10 = 1.0°C	[Temperature] Supply	2113
25H	37	R	10 = 1.0°C	[Temperature] Return	2114
26H	38	R	10 = 1.0%	[Relative Humidity] Room	2122
27H	39	R	10 = 1.0 g/Kg	[Absolute Humidity] Room	2124
28H	40	R	10 = 1.0%	[Relative Humidity] Outdoor	2121
29H	41	R	10 = 1.0 g/Kg	[Absolute Humidity] Outdoor	2123
2AH	42	R	1 = 1 pa	[Flow] Differential pressure on the air, in pascal	2131
2BH	43	R	1 = 1 ppm	[CO ₂] Level in ppm	2132
2CH	44	R	1 = 1%	[% of opening] Register of fresh air	2413
2DH	45	R	1 = 1%	[% of opening] Valve gas	2618
2EH	46	R	1 = 1%	[% of opening] Electrical heaters (Triac)	2627
2FH	47	R	1 = 1%	[% of opening] Hot water coil	2633
30H	48	R	1 = 1%	[% of opening] Humidifier	2714
31H	49	R	10 = 1.0°C	[Dry contact] Temperature, Free 1, BE50-J9-B1	2161
32H	50	R	10 = 1.0°C	[Dry contact] Temperature, Free 2, BE50-J9-B2	2162
33H	51	R	10 = 1.0°C	[Dry contact] Temperature, Free 3, BE50-J10-B3	2163
34H	52	R	10 = 1.0°C	[Dry contact] Temperature, Free 4, BE50-J10-B4	2164
35H	53	R	10 = 1.0%	[Dry contact] Humidity, Free 1, BE50-J9-B1	2165
36H	54	R	10 = 1.0%	[Dry contact] Humidity, Free 2, BE50-J9-B2	2166
37H	55	R	10 = 1.0%	[Dry contact] Humidity, Free 3, BE50-J10-B3	2167
38H	56	R	10 = 1.0%	[Dry contact] Humidity, Free 4, BE50-J10-B4	2168
39H	57	R		not used	
3AH	58	R		not used	
3BH	59	R		not used	
3CH	60	R		not used	
3DH	61	R		not used	
3EH	62	R		not used	
3FH	63	R		not used	
40H	64	R		not used	



LONWORKS Settings and Readings

			DS50
R/W	L	[On / Off] Unit	3111
R/W	L	[Reset] Discharges the safety measures of the unit	3112
R/W	L	[BMS] Activation of the Inoccupation mode [Off] occupation mode - [On] inoccupation mode	3933
R/W	L	[Clock] [OFF] read hour & minute [ON] write hour & minute	...
R	L	[Alarm] General	1000
R	L	[On/Off] Fan, Blower	2315
R	L	[On/Off] Compressor, 1	2516
R	L	[On/Off] Compressor, Heat pump, 1	2517
R	L	[On/Off] Compressor, 2	2526
R	L	[On/Off] Compressor, Heat pump, 2	2527
R	L	[On/Off] Compressor, 3	2536
R	L	[On/Off] Compressor, Heat pump, 3	2537
R	L	[On/Off] Compressor, 4	2546
R	L	[On/Off] Compressor, Heat pump, 4	2547
R	L	[On/Off] Gas, Burner, 1	2615
R	L	[On/Off] Gas, Burner, 2	2616
R	L	[On/Off] Gas, Burner, High power, 1	2617
R	L	[On/Off] Electrical heaters, 1	2625
R	L	[On/Off] Electrical heaters, 2	2626

			DS50
R/W	1 = 1 s	[BMS] Activation of the control by a computer or an automat - mode BMS is activated if this value is different from zero, This value is decreased every second	3932
R/W	10 = 1.0°C	[Occupation][Room SP] Required maximum room temperature in °C. Cooling set point	3322 (BMS)
R/W	10 = 1.0°C	[Occupation][Room SP] Required minimum room temperature in °C. Heating set point	3323 (BMS)
R/W	1 = 1%	[Room SP] Required room minimum fresh air rate in %. Middle of the dead zone	3312 (BMS)
R/W	10 = 1.0°C	[Inoccupation][Room SP] Required maximum room temperature in °C. Cooling set point	3322 (Uno)
R/W	10 = 1.0°C	[Inoccupation][Room SP] Required minimum room temperature in °C. Heating set point	3323 (Uno)
R/W	1 = 1%	[Humidity] Desired Maximum relative humidity in Room (in %). – Dehumidification set point.	3341 (BMS)
R/W	1 = 1%	[Humidity] Desired Minimum relative humidity in Room (in %). – Humidification set point.	3342 (BMS)
R/W	1 = 1h	[Clock] Hour	3121
R/W	1 = 1m	[Clock] Minute	3122
R/W	1 = 1	[Clock] Day of the month	3123
R/W	1 = 1	[Clock] Month	3124
R	1 = 1	[Alarm] Code Error	1000
R	10 = 1.0°C	[Temperature] Room	2112
R	10 = 1.0°C	[Temperature] Outdoor	2111
R	10 = 1.0°C	[Temperature] Supply	2113
R	10 = 1.0%	[Relative Humidity] Outdoor	2121
R	10 = 1.0 g/Kg	[Absolute Humidity] Outdoor	2123
R	10 = 1.0%	[Relative Humidity] Room	2122
R	10 = 1.0 g/Kg	[Absolute Humidity] Room	2124
R	1 = 1%	[% of opening] Register of fresh air	2413
R	1 = 1%	[% of opening] Valve gas	2618
R	1 = 1%	[% of opening] Electrical heaters (Triac)	2627
R	1 = 1%	[% of opening] Hot water coil	2633



CODE	DESCRIPTION LIGNE1	DESCRIPTION LIGNE2
1	Flow	Failure
4	Filters	Dirty
5	Filters	Missing
11	Electrical Heater	Faulty
12	Outlet or Supply T.	Over Temp.
13	Inlet or Room T.	Temp. Too Low
14	Gas Burner, 1	Faulty
15	Gas Burner, 2	Faulty
22	Outlet or Supply T.	Temp. To Below
23	Inlet or Room T.	Temp. Too High
31	Humidifier	Faulty
32	Room Humidity	Humidity Too Low
33	Room Humidity	Humidity Too High
40	Flow, Pump	Failure
41	Pump, 1	Faulty
42	Pump, 2	Faulty
70	Real Time Clock	Faulty
71	BE50, 1	Faulty
72	BE50, 2	Faulty
73	BE50, 3	Faulty
74	BE50, 4	Faulty
75	BE50, 5	Faulty
80	Remote S.Point	Faulty
81	Inlet or Room T.	Faulty Sensor
82	Room Humidity	Faulty Sensor
83	Outside Temperature	Faulty Sensor
84	Outside Humidity	Faulty Sensor
85	Outlet or Supply T.	Faulty Sensor
86	Inlet, Recovery	Faulty Sensor
87	Outlet, Recovery	Faulty Sensor
88	Return or Mixing T.	Faulty Sensor
90	Air, Condenser	Faulty
91	Blower, Fan	Faulty
92	Air, Condenser	Faulty, System 1
93	Air, Condenser	Faulty, System 2
94	Air, Condenser	Faulty, System 3
95	Air, Condenser	Faulty, System 4
96	Water, Condenser	Temp. To Below
97	Water, Condenser	Temp. Too High
98	Water, Condenser	Faulty, Flow
99	Fire / Smoke	Faulty
111	Condenser	Faulty Sensor, 1
112	Suction	Faulty Sensor, 1
114	Circuit 1	Elec. power
115	Circuit 1	Cut High Pressure
117	Circuit 1	Cut Low Pressure



CODE	DESCRIPTION LIGNE1	DESCRIPTION LIGNE2
118	Circuit 1	Risk of Frosting
121	Condenser	Faulty Sensor, 2
122	Suction	Faulty Sensor, 2
124	Circuit 2	Elec. power
125	Circuit 2	Cut High Pressure
127	Circuit 2	Cut Low Pressure
128	Circuit 2	Risk of Frosting
131	Condenser	Faulty Sensor, 3
134	Circuit 3	Elec. power
135	Circuit 3	Cut High Pressure
137	Circuit 3	Cut Low Pressure
141	Condenser	Faulty Sensor, 4
144	Circuit 4	Elec. power
145	Circuit 4	Cut High Pressure
147	Circuit 4	Cut Low Pressure
210	P.Lan	EEV 1, Error
211	Low Superheat	EEV 1, Error
212	High Suction T.	EEV 1, Error
213	MOP	EEV 1, Error
214	LOP	EEV 1, Error
215	Valve Not Closed	EEV 1, Error
216	Probe	EEV 1, Error
217	Motor	EEV 1, Error
218	EEPROM	EEV 1, Error
219	Battery	EEV 1, Error
220	P.Lan	EEV 2, Error
221	Low Superheat	EEV 2, Error
222	High Suction T.	EEV 2, Error
223	MOP	EEV 2, Error
224	LOP	EEV 2, Error
225	Valve Not Closed	EEV 2, Error
226	Probe	EEV 2, Error
227	Motor	EEV 2, Error
228	EEPROM	EEV 2, Error
229	Battery	EEV 2, Error

It is possible to connect up to 12 CLIMATIC50 with Climalook2 or 8 rooftops equipped with CLIMATIC2 and 12 with CLIMATIC 50 when Climalook 3 or Climalink is installed.

to have a local display of the installation. It can be connected to up to 12 CL50 controller via a RS485 interface.

CLIMALINK 2

This product consist in a central unit and a communication interface.
 This unit is designed to be connected to a maximum of 12 rooftops fitted with CLIMATIC 50 controllers via a RS485 interface. A connection diagram is provided in the box.
 The central unit must be installed in a dry, secured location.
 Once the unit is connected and powered up, it is entirely automatic and does not require a screen a keyboard or a mouse. After a power failure, the central unit must be restarted using the ON/OFF button.
 To avoid this Lennox recommend to connect the central unit to a pulsating current power outlet or "UPS". Lennox cannot be held responsible in the event this recommendation is not acted upon.

CLIMALOOK 3



Climalook 3 provides the same features as Climalook 2 as it can be connected to 12 rooftops equipped with CLIMATIC 50 controller but it can also be connected to 8 rooftops fitted with CLIMATIC2 controller and KP01 board (Flexy and Linea already on site).

NOTE: In order to connect a unit fitted with CLIMATIC2 you must ensure that the program version is at least LF20. Otherwise it must be upgraded to LF20 before connection to Climalook 3

Climalook uses the internet explorer interface for local operation. The local operating mode is completely automatic and does not require any configuration. Like Climalink, Climalook can receive remote queries thanks to its internal modem and an analogue telephone line.
 Climalook and Climalink do not work with ISDN telephone lines.

CLIMALOOK 2

This product is identical to the CLIMALINK 2 but it is equipped with a 15inch TFT flat screen, a mouse and a numeric keypad




NOTE : To function correctly each RTU requires an address to be set using a KP02 (setpoint 91).
 To register in the climatic the power to the climatic must be switched off twice after entering the value.

Whenever the power is switched on it is necessary to wait 5 minutes after the welcome page is displayed to allow the software to fully update.

CONNECTION TO CLIMATIC2 AND KP01 BOARD


The connections between the units and the Climalink/ Climalook must be done using a double shielded pair of wire (not supplied by Lennox) This cable must have external metal braiding, and its cross-section must be at least 0.5mm² with a maximum of 1mm²

Each cable will be connected to the COM B port on the KP01 Board, and particular attention must be taken to the order of connections. The cable coming out of the KP14 with a BD9 plug at the end will be connected to the SERIAL Port at the back of the central unit.




The cable coming out of the KP14 with a BD9 plug at the end will be connected to the SERIAL Port at the back of the central unit.

CONNECTION TO CLIMATIC™ 50 USING INTERFACE 435/232



Plug for telephone link RJ11. Cable supplied with the unit.



It is possible to connect up to 12 rooftops fitted with CLIMATIC 50 when using a Climalook 3.
The connections between the units and the Climalink/Climalook must be done using a double shielded pair of wire (not supplied by Lennox) This cable must have external metal braiding, and its cross-section must be at least 0.5mm² with a maximum of 1mm²

After the starting procedure of the Climalook 3 central unit, the LED next to the B PORT on the CLIMATIC KP01 board will start to flash. The CPU connects to the boards one after the other, and so it is normal for the LED to stop flashing occasionally.

The wires will be connected to each CLIMATIC50 485 ports
You must ensure the connection order is correct :


When all the connections are established, press the on/off button. The programs are launched automatically, and the LED located to the right of the Com B on the CLIMATIC KP01 board should flash.

- + on +,
- on -
- and gnd on gnd.


Note the site telephone number in order to make the remote query.

Note the site telephone number in order to make the remote query

The cable terminated by a DB9 plug, coming out of the 485/232 interface will be connected to the SERIAL port on the Climalook central unit




Plug for telephone link RJ11. Cable supplied with the unit.




After the starting up procedure is completed the LED on the INTERFACE will start flashing.

SETTINGS FOR THE CONNECTIONS

Depending on the version of Windows you are running, access the « Make new connection » function.




Click on next




Enter the telephone number to which your ClimaLook's modem is connected.

Click




Click

Click on next




Click



Enter the site name

Click on Finish




Type "Administrateur"

Click

Type "VISION"

The modem dials the number, and then the two modems hook up.

In the task bar next to the time display you should see the symbol indicating connection with the remote computer.



On some versions of Windows, a dialogue box may ask you to enter the password again. In this case :

- for User enter Administrateur
- for password enter VISION
- leave the workgroup field empty.

You can now start Internet Explorer.



Type "http:// Lennox" in the Address field

The first time you log in, Windows asks you to confirm your login identifiers:

- for User enter **Administrateur**
- for password enter **VISION**
- leave the workgroup field empty.


After this formality, you gain access to:

THE WELCOME PAGE

First of all you must lower the virtual keyboard window, before choosing the language.

NOTE : To operate the program it is necessary to minimise the virtual keyboard.

Then click on the flag corresponding to the language you want to use.



Enter your access code and confirm. The access code **999** serves as a temporary code until you have configured your own security code.


If your code is valid you will access the next menu. Otherwise you remain on the same page.

There are three access levels :

- 1st level : use of the User, Schedule, Macro and History pages.
- 2nd level : ditto, plus the Service page.
- 3rd level : ditto, plus the Access page.

If the local application is not functioning, it is possible you may remain on the same page, even if your access code is valid. In this case, it is necessary to first restart the local central unit before continuing.


THE MAIN PAGE



The colour outline around the roof-top unit and the operating temperatures indicate the unit's status:

- Green :** Operating mode,
- White :** Stop mode,
- Orange** Night mode,
- Red:** Fault mode,

This page gives you the basic information about how your installation functions. The roof-top unit's number corresponds to its EPROM number.



Position the mouse on one of the units to obtain information indicating this unit's status.

If the unit does not exist, is not powered up, or if communication with it is impossible, its icon disappears from the screen. The program attempts to communicate with absent units every ten minutes.

To access a unit's operating details, just click on it once. 20 seconds automatic refresh on this screen.

THE USER PAGE

This is the page used most frequently. It enables you to display and modify a number of settings on your unit.

Use the refresh function to update the values read.

Some settings are read-only, others can be modified.


Read-only setting :



Modifiable setting :



Unit's day and time



The bottom of the page displays the unit currently being queried, and can also be used to change the unit by clicking. This takes you to the user page for the new machine. If the unit does not exist, is not powered up, or if communication with it is impossible, its icon disappears from the screen. The program attempts to communicate with absent units every ten minutes.


It is possible to modify several settings at the same time.

The settings will only be modified if the «submit» function is confirmed.



If your unit has - or had - a fault, it is outlined in red on the main page. You can use the fault module to trouble-shoot:

If the fault is still present, it is displayed here :




The fault reset function is used to clear the unit's errors if this is possible. If the error persists, the fault returns.

The clear default function is used to reset the software memory of defaults. It does not erase the unit's faults.


For some settings, a small icon is displayed at the end of the line
Click on it to get a history of this setting.



The empty fields correspond to occasions when the CLIMALOOK / CLIMALINK unit has stopped



Use the refresh function to update the values read



- To access the Service page for another unit, simply click on this unit.
- To return to the User page, click on the User menu.
- To access the Schedule page, click on the Schedule menu.

+ Supply temperature / Room temperature / Outdoor air temperature + Faults (last 10 days)

The menus :

Welcome	Welcome page
Main	Main page
Macro	Macro page
History	General History page
Access	Access codes page
Refresh	To refresh the values
Service	Service page or experienced user
Planning	Schedule page which shows all the set points for the different modes.


THE SERVICE PAGE

The Service page is for technical users who know exactly how to adjust air-conditioning units. It is protected by a second level password.

The units are presented in groups, and it is possible to display and modify several settings, as in the User page. The settings will only be modified if the «submit» function is confirmed.

THE SCHEDULE PAGE

This page is used to display and modify all the configuration settings for each zone of a unit's operating schedule. Use the refresh function to update the values read.




In addition it is possible to copy all the displayed settings and then paste them in another unit you have chosen.

The settings will only be modified if the «submit» function is confirmed.

THE MACRO PAGE

This page enables you to modify all the units on your site in one action.
You can choose to perform one or more actions.
Modify the value or values you want to submit.



Click on "Submit"


Select "Entire site"

The standard Macros are :

- Adjust the Comfort thermostat
- Set to Night mode
- Set fresh air to the minimum
- Set the time on the Climatic boards.

THE HISTORY PAGE


This page is provided in addition to the individual history you've already seen in the User page. It tells you when local communication starts and stops, and gives you the users' access codes.



This is a read-only page. The history is automatically cleared to ensure refreshment doesn't take too long.
This page will also show units faults.

THE ACCESS PAGE

This page enables users who have a third level access code to attribute access codes to other users.
The access code 999 is your first access code. Remember to delete it once you have created your own access codes.



To create a new user : Click on name



Use the virtual keyboard on the task bar

Use the keyboard to enter the name, password (maximum of 4 digits) and the access level.

- 1 = use of the User, Schedule, Macro and History pages.
- 2 = same level, plus the Service page.
- 3 = same level, plus the Access page.

Reposition the keyboard in the task bar by clicking on the minus sign in the top right-hand part of the keyboard.



Confirm by clicking on «Submit»

PROBLEM SOLVING

Impossible to enter your access code, you remain on the welcome page.

Local communication has been interrupted. You must restart the local unit.

After restarting, you must wait for 5 to 10 minutes until the unit is ready to be queried once more.

The values read do not seem to move.

The values are not in fact refreshed automatically, and for all the pages you must use the Refresh function to be sure you are reading the latest values.

The keyboard has disappeared from the task bar.
Click on Start / Programs / StartUp



The local unit is not answering the phone.

The local unit is - or was - powered down, and you must press the On/off button.

See recommendations at the beginning of the document.

The unit is not connected to a direct analogue phone line.

How to check the ClimaLink is functioning correctly after installation :

Connect up the unit and the KP14

Connect the cables to the J18 inputs on the Climatic boards. After a few minutes, the central unit should start its dialogue. The LED on the Climatic board to the right of the J18 input should flash.

If this does not happen, check the wiring.

The only way to examine the problem in more detail is to obtain a monitor and a mouse and contact the Lennox services.

After installing a ClimaLook or ClimaLink central unit, it is vital to perform the telephone communication tests.

Take a test telephone set and make sure you have a connection.

Note the telephone number to which the central unit is connected.

Connect the central unit and ask a person on the remote site to test communication.

Obviously the central unit must be the only device installed on the phone line. It cannot share the line with a fax or another modem.



The power cable should be connected to the main isolating switch and is fed from the underside of the unit into the electrical panel.

Refer to the general arrangement drawings in the documentation to locate the exact entry position.

The power cable sizes must be calculated with reference to the electrical characteristics of your machine.

We are unable to state the cross sectional area of the cable

as it is directly related to the type of cable you are using, the distance separating the equipment from the source but also various factors relating to the cable fitting.

In the following pages you will find references to electrical diagrams which will allow you to select the wiring for your equipment.

As the diagrams are valid for the entire range, they will refer to items not included in your scope of supply.

FC Type :	Fh Type :	Fx Type :
01 -	01 Heat Pump	01 Heat Pump (standard)
02 Modulating electric heater	02 Modulating electric heater	02 Modulating electric heater
03 Hot water coil	03 -	03 Hot water coil
04.1 -	04.1 -	04.1 -
05 Economiser	05 Economiser	05 Economiser
06 -	06 -	06 -
07 Exhaust Roofcurb	07 Exhaust Roofcurb	07 Exhaust Roofcurb
08 Firestart	08 Firestart	08 Firestart
09 Smoke Detector	09 Smoke Detector	09 Smoke Detector
10 Advanced Control Pack	10 Advanced Control Pack	10 Advanced Control Pack
11 DS50	11 DS50	11 DS50
12 DC50	12 DC50	12 DC50
13 Hygiene Probe	13 Hygiene Probe	13 Hygiene Probe
14 Air Sock Control	14 Air Sock Control	14 Air Sock Control
15 -	15 -	15 -
16 100% Fresh Air	16 100% Fresh Air	16 -
17 LP-HP Pressure Gauge	17 LP-HP Pressure Gauge	17 LP-HP Pressure Gauge
18 -	18 -	18 -
19 -	19 -	19 -
20 Low Ambient Kit	20 Low Ambient Kit	20 -
21 -	21 -	21 -
22 -	22 -	22 100% Fresh Air
23 Water Cooled Condenser	23 Water Cooled Condenser	23 -
24 TCB	24 TCB	24 TCB
25 Climalook/Climalink	25 Climalook/Climalink	25 Climalook/Climalink
26 Centrifugal Condensing Fan	26 Centrifugal Condensing Fan	26 -
27 -	27 -	27 -
28 -	28 -	28 -



FG Type :	Fd Type :
01 -	01 -
02 -	02 -
03 -	03 -
04.1 Gas Burner 33/60kW	04.1 Gas Burner 33/60kW
04.2 Gas Burner 120kW	04.2 Gas Burner 120kW
04.3 Gas Burner 180kW	04.3 Gas Burner 180kW
05 Economiser	05 Economiser
06 -	06 -
07 Exhaust Roofcurb	07 Exhaust Roofcurb
08 Firestart	08 Firestart
09 Smoke detector	09 Smoke detector
10 Advanced Control Pack	10 Advanced Control Pack
11 DS 50	11 DS 50
12 DC 50	12 DC 50
13 Hygiene Probe	13 Hygiene Probe
14 Air Sock Control	14 Air Sock Control
15 -	15 -
16 100% Fresh Air	16 100% Fresh Air
17 LP-HP Pressure Gauge	17 LP-HP Pressure Gauge
18 -	18 -
19 -	19 -
20 Low Ambient Kit	20 Low Ambient Kit
21 -	21 Dynamic Defrost
22 -	22 -
23 Water Cooled Condenser	23 Water Cooled Condenser
24 TCB	24 TCB
25 Climalook/Climalink	25 Climalook/Climalink
26 Centrifugal Condensing Fan	26 Centrifugal Condensing Fan
27	27
28	28

FGN Type :	Fwn Type :
01 -	01 -
02 -	02 -
03 -	03 -
04.1 Gas Burner 33/60kW	04.1 Gas Burner 33/60kW
04.2 Gas Burner 120kW	04.2 Gas Burner 120kW
04.3 Gas Burner 180kW	04.3 Gas Burner 180kW
05 Economiser	05 Economiser
06 -	06 -
07 -	07 Exhaust Roofcurb
08 Firestart	08 Firestart
09 Smoke detector	09 Smoke detector
10 -	10 Advanced Control Pack
11 DS 50	11 DS 50
12 DC 50	12 DC 50
13 Hygiene Probe	13 Hygiene Probe
14 Air Sock Control	14 Air Sock Control
15 -	15 -
16 -	16 100% Fresh Air
17 -	17 LP-HP Pressure Gauge
18 -	18 -
19 -	19 -
20 -	20 Low Ambient Kit
21 -	21 Dynamic Defrost
22 -	22 -
23 -	23 Water Cooled Condenser
24 TCB	24 TCB
25 Climalook/Climalink	25 Climalook/Climalink
26 -	26 Centrifugal Condensing Fan
27 -	27 -
28 -	28 -

FXA / FXK = Heat pump rooftop

01	Heat pump
02	Electric heater TRIAC
03	Hot water coil
04.1	-
05	Economiser
06	-
07	-
08	Firestat
09	Smoke detector
10FH	Advanced control pack (FC : cooling- FH : heat pump)
11	Digital console KP02
12	Consoles KP17
13	Hygiene probe
14	Air sock control
15	Dry contact kit (KP12.2)
16	RS232 KP14
17	CL06
18	KP07
19	-
20	-
21	-
22	All fresh air
23	Remote set point (KP05)
24	KP12.3 (TCB)
25	KP12.4 (Adaptvision)
26	Climalink/Climalook

DIAGRAM REFERENCE LEGEND

-A1-A2	Air SSocket Control
-B1	External air thermostat
-B2	Smoke detection head
-B4-B5	Gas manifold ionisation probe
-B6-B7	Gas manifold ignition electrode
-B11	Water flow rate controller
-B13	Clogged air filter pressure switch / air flow rate
-B14	Hot water battery antifreeze thermostat
-B15	Hot water battery antifreeze thermostat
-B16	Fire thermostat
-B17-B18	Gas manifold smoke minimum gas pressure switch

-B19-B20	Blower fan motor -MS1-MS2 stoptherme
-B21-B22	Gas manifold extraction air pressure switch
-B23-B24	Extraction fan motor -ME1-ME2 stoptherme
-B25-B26	Electric battery -E1-E2 safety klixon
-B27	Electric battery -E3 safety klixon
-B29-B30	Gas manifold air flow rate safety klixon
-B32-B33	Gas manifold flashback safety klixon
-B41-B42	Compressor -MG1-MG2 high pressure safety switch
-B43-B44	Compressor -MG3-MG4 high pressure safety switch
-B45-B46	Gas manifold 1 / gas manifold 2 regulation klixon
-B51-B52	Compressor -MG1-MG2 low pressure safety switch
-B53-B54	Compressor-MG3-MG4 low pressure safety switch
-B61-B62	Compressor -MG1-MG2 high pressure control switch
-B63-B64	Compressor -MG3-MG4 high pressure control switch
-B71-B72	Condenser -MC1-MC2 fan motor stoptherme
-B73-B74	Condenser -MC3-MC4 fan motor stoptherme
-B81-B82	Scroll compressor -MG1-MG2 protection module
-B83-B84	Scroll compressor -MG3-MG4 protection module

-BE50	Extension Board
-BG10	Hygiene Probe
-BH10	Regulation Hygrometry Probe

-BH11	External hygrometry probe
-BM50	Climatic 50

-BT10	Regulation temperature probe
-BT11	External temperature probe
-BT12	Blower temperature probe

-BT16-BT18	Heat exchanger water outlet probe
-BT17	Return Temperature Sensor

-BT91-BT92	Defrost temperature sensor compressor 1-2
-BT93-BT94	Defrost temperature sensor compressor 3-4

-BX50.1.2	Multiplexer Climatic 50
-DT 50	Connection Board

-E1-E2-E3	Heater -E1-E2-E3
-E4	Vapor humidifier
-E9-E10	Antifreeze heater cords
-E11	Smoke detector printed circuit
-E14	Burner control box

-EF49	Gas Burner Board
-------	------------------

-E51-E52	Compressor -MG1-MG2 housing resistance
-E53-E54	Compressor -MG3-MG4 housing resistance

-KE1-KE2	Heater -E1-E2 contactor
-KE3	Heater -E3 contactor

-KM1-KM2	Blower fan motor -MS1-MS2 contactor
-KM5-KM6	Extraction fan motor -ME1-ME2 contactor

-KM9-KM10	Condenser 1 / condenser 2 fan motor contactor
-KM11-KM12	Compressor -MG1-MG2 contactor
-KM13-KM14	Compressor -MG3-MG4 contactor

-MC1,2	Condenser -MC1-MC2 fan motor
-MC3,4	Condenser -MC3-MC4 fan motor
-ME1-ME2	Extraction fan motor -ME1-ME2 contactor

-MG1-MG2	Compressor -MG1-MG2 contactor
----------	-------------------------------



-MG3-MG4	Compressor -MG3-MG4 contactor
-MR1	Economiser damper motor
-MR3	Fresh air damper motor
-MR4	Extraction damper motor
-MS1-MS2	Blower fan motor -MS1-MS2
-Q1-Q2	Blower fan motor -MS1-MS2 protection
-Q5-Q6	Extraction fan motor -ME1-ME2 protection
-Q9	Condenser -MC1-MC2 fan motor protection
-Q10	Condenser -MC3-MC4 fan motor protection
-Q11-Q12	Compressor -MG1-MG2 protection
-Q13-Q14	Compressor -MG3-MG4 protection
-Q25	Housing resistance protection
-QF1	Primary circuit protection -T1
-QF2	Primary circuit protection -T3
-QF4	Secondary circuit protection - T1
-QG	Main switch
-QE1-QE2	Heater -E1-E2 protection
-QE3	Heater -E3 protection
-T1	Control circuit transformer 400v / 24v
-T3	Burner power supply transformer 400 / 230v
-TCB	control thermostat
UF	Cooling unit
UT	Air treatment unit
-V1.2.3	Electric battery static contactor
-YV2	Hot water 3-way valve
-YV11-YV12	Compressor -MG1-MG2 cycle reversal valve
-YV13-YV14	Compressor -MG3-MG4 cycle reversal valve
-YV31-YV32	Burner gas solenoid valve
-YV41-YV42	Gas manifold safety solenoid valve
-YV51-YV52	Gas manifold main solenoid valve
-Z*	Capacity resistance circuit

-BCD1.2	Condenser Coil
-BEC	Hot Water Coil
-CA 1.2.3.4	Check Valve
-DT1.2.3.4	Thermostatic Expanssion Valve
-FD 1.2.3.4	Filter Drier
-B14-B15	Hot Water Battery Antifreeze Thermostat
-BT12	Blower Temperature Probe
-BT17	Return Regulation Temperature Sensor
-B41-B42	Compressor -MG1-MG2 high pressure safety switch
-B43-B44	Compressor -MG3-MG4 high pressure safety switch
-B51-B52	Compressor -MG1-MG2 low pressure safety switch
-B53-B54	Compressor -MG1-MG2 low pressure safety switch
-B61-B62	Compressor -MG1-MG2 high pressure control switch
-B63-B64	Compressor -MG1-MG2 high pressure control switch
-EE1.2	Water Heat Exchanger
-MC1-MC2	Condenser MC1 / condenser MC2 fan motor
-MC3-MC4	Condenser MC3 / condenser MC4 fan motor
-MG1-MG2	Condenser MG1 - MG2
-MG3-MG4	Condenser MG3 - MG4
-MS1	Blower Fan Motor -MS1
VAM1.2	Manual Check Valve
VRM	Adjustable Manual Valve



BCD1.2	Condenser Coil
-BEC	Hot Water Coil
-BEV 1.2	Evaporator Coil
-CA 1.2.3.4	Check Valve
-DT 1.2.3.4	Thermostatic Expansion Valve
-FD 1.2.3.4	Filter Drier
-B14-B15	Hot water battery antifreeze thermostat
-BT12	Blower Temperature Probe
-BT17	Return Regulation Temperature Sensor
-B41-B42	Compressor -MG1-MG2 high pressure safety switch
-B43-B44	Compressor -MG3-MG4 high pressure safety switch
-B51-B52	Compressor -MG1-MG2 low pressure safety switch
-B53-B54	Compressor -MG1-MG2 low pressure safety switch
-B61-B62	Compressor -MG1-MG2 high pressure control switch
-B63-B64	Compressor -MG1-MG2 high pressure control switch
-EE1.2	Water Heat Exchanger
-MC1-MC2	Condenser MC1 / condenser MC2 fan motor
-MC3-MC4	Condenser MC3 / condenser MC4 fan motor
-MG1-MG2	Condenser MG1 - MG2
-MG3-MG4	Condenser MG3 - MG4
-MS1	Blower Fan Motor -MS1
VAM1.2	Manual Check Valve
VRM	Adjustable Manual Valve
-YV2	Hot water 3-way valve
-YV11-YV12	Compressor -MG1-MG2 cycle reversal valve
-YV13-YV14	Compressor -MG3-MG4 cycle reversal valve

FCA / FCK = Cooling only unit

FHA / FHK = Heat pump rooftop



FXA/FXK = Heat recovery unit

MAIN CURRENT DIAGRAM





FGA / FGK = Cooling only unit with gas fired heating
 FDA / FDK = Heat pump rooftop with gas fired heating



MAIN CURRENT DIAGRAM




MAIN CURRENT DIAGRAM




MAIN CURRENT DIAGRAM




CLIMATIC 50 CONTROLLER





CLIMATIC 50 INPUT




CLIMATIC 50 OUTPUT




DAD SMOKE DETECTOR



INPUT OUTPUT EXTENSION BOARD - ADC




INPUT OUTPUT EXTENSION BOARD - TCB



GAS BURNER 33 / 60 / 120 Kw


04.1

GAZ 33/60kW




04.2





GAZ 120kW




GAS BURNER 180 KW




FULLY MODULATING ELECTRIC HEATER




GENERAL CUSTOMER CONNECTION DIAGRAM




FC 085




FC 100



FC 120




FC 140







FC 160




FC 190




FH 085




FH 100




FH 120




FH 140



FH 160




FH 190








FX 025 - FX 030




PIPE DIAMETERS	
Discharge Line	3/4"
Suction Line	7/8"
Liquid Line	5/8"

— INSULATED PIPING
 — NON-INSULATED PIPING


 STEK OPTION
 R407C OPTION




FX 035 - FX 085




FX035-FX040	
PIPE DIAMETERS	
Discharge Line	3/4"
Suction Line	7/8"
Liquid Line	5/8"

FX055 a FX085	
PIPE DIAMETERS	
Discharge Line	7/8"
Suction Line	1 1/8"
Liquid Line	5/8"


— INSULATED PIPING
 — NON-INSULATED PIPING


 STEK OPTION
 R407C OPTION

FX 110 - FX 140 - FX 170



FX 100





REFRIGERATION

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
LP PROBLEMS and LP CUT OUTS	Refrigerant charge too low	Measure the superheat and sub-cooling: Good if 5°C<SC<10°C and 5°C<SH<10°C Bad if SC>10°C and SH too Low Check superheat adjustment and charge unit (a leak check must be carried out)
	In Heat Pump Mode the temperature difference between T outdoor and T _{evap.} (Dew) is too high 5°C < Delta T < 10°C excellent 10°C < Delta T < 15°C acceptable 15°C < Delta T < 25°C too high	If too high check the coils are clean or check coil internal pressure drop between the liquid line and the suction line Good if < 3bar Too high if > 3bar (coil blocked)
	Refrigeration circuit blocked in distribution	Stop the fan and create icing of the coil. Check all circuits freeze evenly across the whole surface of the coil If some parts of the coil do not freeze this could indicate a problem with the distribution
	Liquid line drier blocked. High temperature difference between inlet and outlet of the drier	Change filter drier
	Contaminant in the expansion valve	Attempt to free the valve adjusting element by freezing the valve and then heating the thermostatic element. Replace the valve if necessary
	Expansion valve not adjusted properly	Adjust the expansion valve
	Ice plug in the expansion valve.	Heat the main body of the valve. If the LP increases and then decreases gradually, empty the circuit and replace the drier.
	Incorrect insulation of the thermostatic bulb of the expansion valve	Superheat too low: adjust superheat Move the thermostatic element along the pipe Insulate the Thermostatic element of the valve
	Low Pressure Switch cut out point too high	Check the cut out pressure of the Low Pressure switch: It must be 0.7+/- 0.2bar and must closes at 2.24 +/- 0.2 bar
	LP cut out due to not enough defrost on heat pumps	Adjust the CLIMATIC settings to extend the defrost cycles or shorten the time between defrosts
HP PROBLEMS AND HP CUT OUTS	Incorrect Airflow rates	<i>Heat pump mode :</i> Check the filter before the indoor coil measure and estimate the airflow rate increase the speed of the fan <i>Cooling mode :</i> Check the condenser fan (Amps)
	Moisture or contaminants in the system	Summer operation Several hours after the unit has stopped, check the correspondance between the measured pressure and the outdoor temperature



REFRIGERATION

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
HP PROBLEMS AND HP CUT OUTS	Moisture or contaminants in the system	If the circuit pressure is higher (<1bar) than the saturated pressure corresponding to the measured outdoor temperature, there is possibility that some contaminants are present in the system. Reclaim the refrigerant, and vacuum the circuit (Ensure very low and slow vacuum for R407c) Recharge the unit
	Condenser coil is obstructed	Check the condenser coil and clean is necessary
	Recycled Hot Air	Check clearance around the condenser
Strong variations of pressure (2 to 3 bar) Thermostatic Expansion Valve "hunting"	Incorrect adjustment of the expansion valve Low refrigerant charge Filter drier obstructed with gas bubbles at the expansion valve inlet Moisture in the system	Refer to LP problems and LP cut out section
Very high discharge temperature, High amps measured at compressor	Very high superheat, very hot compressor	Open the superheat adjustment on the expansion valve. Check the pressure drop on the filter drier in the suction line
	Four Way reversing valve possibly blocked, abnormal noise from the valve, low LP and increasing HP	Check operation of the valve by going through cycle inversions. Change if necessary. Refer to LP problems

INDOOR FAN BLOWER

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
High amps on action Fan motor	Pressure drop in the ducting installation too low.	Reduce the rotation speed of the fan Measure and estimate the airflow and pressure and compare with the specification from customer.
High amps on reaction Fan motor	Pressure drop in the ducting installation too high.	Reduce the rotation speed of the fan Measure and estimate the airflow and pressure and compare with the specification from customer.
Unstable running and high vibration	Fan jumping from one operating point to the other.	Change rotation speed of the fan.



OUTDOOR AXIAL FAN

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
Heat Pump mode : Circuit breaker open	High Amps due to a low voltage from the main supply	Check the voltage drop when all components are running. Change the circuit breaker for one with a higher rating.
	High amps due to freezing of the coil	Check the adjustable amps on the motor starter. Adjust the defrost cycle set points.
	Flexy : Water ingress in the motor connection box.	Change the component

ELECTRIC HEATER

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
High Temperature trip out on electric heater	Low airflow rate	Measure and estimate the airflow and pressure and compare with the specification from customer.
	Incorrect position of the Klixon	Check that the Klixon, is positioned in the airflow, relocate Klixon if necessary Check that there is no heat transfer from the Klixon support.

ELECTRIC HEATER

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
Water found in the ventilation section	Cooling mode: Water carried away from the coil because of excessive airflow and speed on the coil.	Estimate the airflow rate and check the speed is lower than 2.8 m/s
	Low air pressure in the compartment due to a high airflow rate or a high pressure drop before the fan	Check filter Reduce airflow rate
Water ingress in the filter compartment	Check seals around the ventilation section.	Check the door seal Check for the presence of silicone seals in the corners of the door and at the bottom of the refrigeration section bulkhead.
	Water ingress through a leaking fresh air hood or when running 100% fresh air	Check the seals and flanges in the fresh air hood Reduce the airflow rate if necessary



Rooftops are generally placed on the roof but can also be installed in technical rooms. These units are very robust but a minimum regular maintenance is required. Some moving parts in the units can suffer from wear and tear and must be checked regularly (belts). Other parts can get clogged by dirt carried in the air (filters) and must be cleaned or replaced.

These units are designed to produce cooled or heated air through the use of a refrigeration vapour compression system, it is therefore imperative to monitor the refrigeration circuit operating pressures and check the pipe-work for leaks.

The table below, details a possible maintenance plan, including the operations to be carried out and the periodicity at which they must be accomplished. It is recommended to follow such a plan to keep a rooftop unit in good working order. Regular maintenance of your rooftop will extend its operating life and reduce operating faults

<i>Symbols and Legend :</i>	
O	Operation which can be carried out by on-site maintenance technicians.
Δ	Operation which must be carried out by qualified personnel, trained to operate on this type of equipment.

NOTE :

- Times are given for information purpose only and may vary depending on the unit size and type of installation.
- Coil cleaning must be carried out by qualified personnel using appropriate methods that won't damage the fins or the tubes.
- It is recommended to keep a minimum stock of common replacement parts in order to be able to carry out regular maintenance operations (i.e. filters). You can contact your local Lennox representative which can assist you in establishing a parts list for each type of equipment.
- The access ports to the refrigeration circuits **MUST** be leak checked every time gauges are connected to the service ports.



TASK	OPERATING MODE	MONTHLY	QUARTERLY	6 MONTHLY	YEARLY B4 WINTER	ESTIMATED TIME (mn)
Clean or replace filters: Disposable, or metal frame.	Replace filters with new ones if disposable. Vacuum clean or blow the dirt. Wash and dry carefully. +Replace media if necessary. Blocked filter will reduce the performance of the unit. THE UNIT MUST NOT OPERATE WITHOUT FILTERS	0				20
Visual check of the oil level	Visually check the oil level through the sight glass on the side of the compressor casing	0				2
Position check of the compressor crankcase heater.	Check the heating resistance is fitted properly and tight around the compressor body.	0				2
Belt tension check.	Check belt tension (Info in IOM) Replace belt if necessary.	0				10
Centrifugal fan bearings check	Isolate unit from the main power supply; Push the fan wheel manually and check for abnormal noises. Bearings are lubricated for life but may need replacement after 10000 hours	0				10
Check absorbed Amps	Check absorbed Amps on all three phases; compare with the nominal value given in the electrical wiring diagram.		Δ			15
Check Smoke detector	Start the unit. Trigger the smoke detector by moving a magnet around the detector head. Reset unit and control.		Δ			5
Check Climatic control, set-points and variables	Refer to the commissioning sheet; Check all set points are set according to this document.		Δ			15
Check clock settings	Check the time and date of the control		0			5
Check the position and tightness of refrigeration components	Check systematically all connections and fixings on the refrigeration circuit. Check for oil traces, eventually a leak test should be conducted. Check operating pressures correspond to the ones indicated on the commissioning sheet		Δ			30
Check Airflow rate safety switch (if fitted).	Shut down supply fan. The fault must be detected within 5 seconds.			0		
Check freeze protection on HWC				Δ		5
Check three way valve on HWC	Increase room set-point 10°C above the actual room temperature. Check operation of the piston. It must move away from the valve head. Reset the control.			Δ		5
Check economiser actuator operation	Check all fixings and transmission. Stop the unit using the control. The fresh air damper must closes. Start the unit the fresh air damper should open			Δ		5
Check refrigeration 4way valve	With the unit running in cooling mode increase the room set-point temperature by 10°C. The unit should switch to heat pump mode. Reset the control.			Δ		5
Check tightness of all electrical connections	Power down the unit and check and tighten all screws, terminal and electric connections, taking a particular attention to the power lines and low voltage control wires			Δ		30



TASK	OPERATING MODE	MONTHLY	QUARTERLY	6 MONTHLY	YEARLY B4 WINTER	ESTIMATED TIME (mn)
Check HP / LP safety switches	Install manifold gauges on the circuit to be checked. Shut down the axial fans and wait for the HP switch to shut down the compressor: 29bar (+1 / -0) auto-reset 22bar (+ - 0.7) Reconnect fans. Switch off the centrifugal supply fan and wait for the LP switch to cut out: 0.5bar (+ - 0.5) reset 1.5bar (+-0.5).			Δ		15
Check outdoor fans and fan guards	Check the fan blades conditions and all fan guards and protections				0	5
Check position of all sensors	Check the good positioning and operation of all sensors of all sensors. Check the values given in the control system. Replace sensor if necessary				0	5
Check and clean if necessary all fresh air grilles	Check the fresh air grilles (if fitted). If dirty or damaged, remove them from unit and clean with high pressure water cleaner. Refit on unit once clean and dry.				0	5
Check indoor and outdoor coils, clean if necessary	Visually check the coils for dirt. If not too dirty, cleaning with a light brush may be enough (WARNING: Fins and copper tubes are very fragile! Any damage WILL reduce the performances of the unit). If very dirty, deep industrial cleaning is required using de-greasing agents.(External contractors must be called).				0 / Δ	1h if cleaning 1h if replacement
Check electric heater element for excessive corrosion	Isolate the unit; Pull the electric heater out of the heater module box and check the resistances to traces of corrosion; Replace resistance as required;				0	1h if replacement
Check anti-vibration mountings, for wear and tear.	Visually check anti-vibration mountings on compressors and centrifugal fan. Replace if damaged.				0	1h if replacement
Check refrigeration circuit for traces of acid in the oil	Take a sample of oil from the refrigeration circuit.				Δ	
Check Glycol concentration in the HWC circuit	Check the glycol concentration in the pressurised water circuit. (a concentration of 30% gives a protection down to approx. -15°C) check the circuit pressure				Δ	30
Check defrost cycle with 4-way valve inversion.	Switch the unit to heat pump mode. Change the set point to obtain the standard defrost mode and reduce the cycle time to the min value. Check the operation of the defrost cycle.				Δ	30
Gas burner module check for corrosion	Pull out the burner to access the tubes (refer to Gas burner section in the IOM)				Δ	30
Sweeping and cleaning the gas burner	Clean the in-shot burners and the blower wheel lightly with a brush. Sweep the flue and flue box. Wipe-off the dust from the housing of the motor. Clean combustion air inlet louvers Pull-out baffles from the tubes, sweep the tubes CHECK FLUE BOX GASKET				Δ	30
Gas supply pressures / connections checks	refer to Gas burner section in the IOM for details				Δ	15
Gas regulation valve settings	refer to Gas burner section in the IOM for details				Δ	30
Check gas burner safety switches	refer to Gas burner section in the IOM for details				Δ	30



TERMS AND CONDITIONS

In the absence of any other written agreement, the guarantee shall only apply to design faults which occur within a 12 month period (warranty period).

The warranty period starts on the date of commissioning and at the latest six months after the delivery of the Rooftop.

ANTI-CORROSION WARRANTY

10 year warranty terms and conditions for corrosion to the Rooftop casing :

Lennox shall guarantee the casing of its Rooftop units manufactured since May 1991 against corrosion for 10 years commencing from the date of delivery of the material.

The warranty shall not apply in the following cases :

1. If the corrosion of the casing is caused by external damage to the protective layer such as scratches, projections, abrasion, impacts etc..
2. If the casing is not kept continually clean in the course of maintenance work or by a specialist company,
3. If the casing is not cleaned and maintained in accordance with regulations,
4. If the Rooftop units are installed on a site or in an environment which is known to be corrosive, unless a special protective coating has been applied by the owner for these applications, which has been recommended by a competent body not linked to the owner and after carrying out a study of the site.
5. Nevertheless the LENNOX coating is highly resistant to corrosion, the warranty will not be applied for rooftop installed at less than 1000m away from the sea.

Note : With the exception of the casing, the rest of the machine is covered by the warranty of our general terms of sale.

DO NOT CONFUSE THE WARRANTY WITH MAINTENANCE

The warranty will only apply if a maintenance contract has been signed, starting from the date of commissioning, and if the maintenance contract has actually been performed.

The maintenance contract must be made with a specialist, competent company.

The sole effect of any repair, modification or replacement of an item during the warranty period must be to extend the material's warranty period.

Maintenance must be carried out in accordance with regulations.

If a spare part is supplied after the expiry of the warranty period, it shall be guaranteed for a period equal to the initial warranty period and will be subject to the same conditions.

We recommend for a contract four inspections per year (every three months), before the start of each season, in order to check the operation of the equipment in the various operating modes.



REFRIGERATION

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
LP PROBLEMS and LP CUT OUTS	Refrigerant charge too low	Measure the superheat and sub-cooling: Good if 5°C<SC<10°C and 5°C<SH<10°C Bad if SC>10°C and SH too Low Check superheat adjustment and charge unit (a leak check must be carried out)
	In Heat Pump Mode the temperature difference between T outdoor and T _{evap.} (Dew) is too high 5°C < Delta T < 10°C excellent 10°C < Delta T < 15°C acceptable 15°C < Delta T < 25°C too high	If too high check the coils are clean or check coil internal pressure drop between the liquid line and the suction line Good if < 3bar Too high if > 3bar (coil blocked)
	Refrigeration circuit blocked in distribution	Stop the fan and create icing of the coil. Check all circuits freeze evenly across the whole surface of the coil If some parts of the coil do not freeze this could indicate a problem with the distribution
	Liquid line drier blocked. High temperature difference between inlet and outlet of the drier	Change filter drier
	Contaminant in the expansion valve	Attempt to free the valve adjusting element by freezing the valve and then heating the thermostatic element. Replace the valve if necessary
	Expansion valve not adjusted properly	Adjust the expansion valve
	Ice plug in the expansion valve.	Heat the main body of the valve. If the LP increases and then decreases gradually, empty the circuit and replace the drier.
	Incorrect insulation of the thermostatic bulb of the expansion valve	Superheat too low: adjust superheat Move the thermostatic element along the pipe Insulate the Thermostatic element of the valve
	Low Pressure Switch cut out point too high	Check the cut out pressure of the Low Pressure switch: It must be 0.7+/- 0.2bar and must closes at 2.24 +/- 0.2 bar
	LP cut out due to not enough defrost on heat pumps	Adjust the CLIMATIC settings to extend the defrost cycles or shorten the time between defrosts
HP PROBLEMS AND HP CUT OUTS	Incorrect Airflow rates	<i>Heat pump mode :</i> Check the filter before the indoor coil measure and estimate the airflow rate increase the speed of the fan <i>Cooling mode :</i> Check the condenser fan (Amps)
	Moisture or contaminants in the system	Summer operation Several hours after the unit has stopped, check the correspondance between the measured pressure and the outdoor temperature



REFRIGERATION

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
HP PROBLEMS AND HP CUT OUTS	Moisture or contaminants in the system	If the circuit pressure is higher (<1bar) than the saturated pressure corresponding to the measured outdoor temperature, there is possibility that some contaminants are present in the system. Reclaim the refrigerant, and vacuum the circuit (Ensure very low and slow vacuum for R407c) Recharge the unit
	Condenser coil is obstructed	Check the condenser coil and clean is necessary
	Recycled Hot Air	Check clearance around the condenser
Strong variations of pressure (2 to 3 bar) Thermostatic Expansion Valve "hunting"	Incorrect adjustment of the expansion valve Low refrigerant charge Filter drier obstructed with gas bubbles at the expansion valve inlet Moisture in the system	Refer to LP problems and LP cut out section
Very high discharge temperature, High amps measured at compressor	Very high superheat, very hot compressor	Open the superheat adjustment on the expansion valve. Check the pressure drop on the filter drier in the suction line
	Four Way reversing valve possibly blocked, abnormal noise from the valve, low LP and increasing HP	Check operation of the valve by going through cycle inversions. Change if necessary. Refer to LP problems

INDOOR FAN BLOWER

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
High amps on action Fan motor	Pressure drop in the ducting installation too low.	Reduce the rotation speed of the fan Measure and estimate the airflow and pressure and compare with the specification from customer.
High amps on reaction Fan motor	Pressure drop in the ducting installation too high.	Reduce the rotation speed of the fan Measure and estimate the airflow and pressure and compare with the specification from customer.
Unstable running and high vibration	Fan jumping from one operating point to the other.	Change rotation speed of the fan.



OUTDOOR AXIAL FAN

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
Heat Pump mode : Circuit breaker open	High Amps due to a low voltage from the main supply	Check the voltage drop when all components are running. Change the circuit breaker for one with a higher rating.
	High amps due to freezing of the coil	Check the adjustable amps on the motor starter. Adjust the defrost cycle set points.
	Flexy : Water ingress in the motor connection box.	Change the component

ELECTRIC HEATER

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
High Temperature trip out on electric heater	Low airflow rate	Measure and estimate the airflow and pressure and compare with the specification from customer.
	Incorrect position of the Klixon	Check that the Klixon, is positioned in the airflow, relocate Klixon if necessary Check that there is no heat transfer from the Klixon support.

ELECTRIC HEATER

FAULT	POSSIBLE CAUSE AND SYMPTOMS	SOLUTION
Water found in the ventilation section	Cooling mode: Water carried away from the coil because of excessive airflow and speed on the coil.	Estimate the airflow rate and check the speed is lower than 2.8 m/s
	Low air pressure in the compartment due to a high airflow rate or a high pressure drop before the fan	Check filter Reduce airflow rate
Water ingress in the filter compartment	Check seals around the ventilation section.	Check the door seal Check for the presence of silicone seals in the corners of the door and at the bottom of the refrigeration section bulkhead.
	Water ingress through a leaking fresh air hood or when running 100% fresh air	Check the seals and flanges in the fresh air hood Reduce the airflow rate if necessary



Rooftops are generally placed on the roof but can also be installed in technical rooms. These units are very robust but a minimum regular maintenance is required. Some moving parts in the units can suffer from wear and tear and must be checked regularly (belts). Other parts can get clogged by dirt carried in the air (filters) and must be cleaned or replaced.

These units are designed to produce cooled or heated air through the use of a refrigeration vapour compression system, it is therefore imperative to monitor the refrigeration circuit operating pressures and check the pipe-work for leaks.

The table below, details a possible maintenance plan, including the operations to be carried out and the periodicity at which they must be accomplished. It is recommended to follow such a plan to keep a rooftop unit in good working order. Regular maintenance of your rooftop will extend its operating life and reduce operating faults

<i>Symbols and Legend :</i>	
O	Operation which can be carried out by on-site maintenance technicians.
Δ	Operation which must be carried out by qualified personnel, trained to operate on this type of equipment.

NOTE :

- Times are given for information purpose only and may vary depending on the unit size and type of installation.
- Coil cleaning must be carried out by qualified personnel using appropriate methods that won't damage the fins or the tubes.
- It is recommended to keep a minimum stock of common replacement parts in order to be able to carry out regular maintenance operations (i.e. filters). You can contact your local Lennox representative which can assist you in establishing a parts list for each type of equipment.
- The access ports to the refrigeration circuits **MUST** be leak checked every time gauges are connected to the service ports.



TASK	OPERATING MODE	MONTHLY	QUARTERLY	6 MONTHLY	YEARLY B4 WINTER	ESTIMATED TIME (mn)
Clean or replace filters: Disposable, or metal frame.	Replace filters with new ones if disposable. Vacuum clean or blow the dirt. Wash and dry carefully. +Replace media if necessary Blocked filter will reduced the performance of the unit. THE UNIT MUST NOT OPERATE WITHOUT FILTERS	0				20
Visual check of the oil level	Visually check the oil level through the sight glass on the side of the compressor casing	0				2
Position check of the compressor crankcase heater.	Check the heating resistance is fitted properly and tight around the compressor body.	0				2
Belt tension check.	Check belt tension (Info in IOM) Replace belt if necessary.	0				10
Centrifugal fan bearings check	Isolate unit from the main power supply; Push the fan wheel manually and check for abnormal noises. Bearings are lubricated for life but may need replacement after 10000 hours	0				10
Check absorbed Amps	Check absorbed Amps on all three phases; compare with the nominal value given in the electrical wiring diagram.		Δ			15
Check Smoke detector	Start the unit. Trigger the smoke detector by moving a magnet around the detector head. Reset unit and control.		Δ			5
Check Climatic control, set-points and variables	Refer to the commissioning sheet; Check all set points are set according to this document.		Δ			15
Check clock settings	Check the time and date of the control		0			5
Check the position and tightness of refrigeration components	Check systematically all connections and fixings on the refrigeration circuit. Check for oil traces, eventually a leak test should be conducted. Check operating pressures correspond to the ones indicated on the commissioning sheet		Δ			30
Check Airflow rate safety switch (if fitted).	Shut down supply fan. The fault must be detected within 5 seconds.			0		
Check freeze protection on HWC				Δ		5
Check three way valve on HWC	Increase room set-point 10°C above the actual room temperature. Check operation of the piston. It must move away from the valve head. Reset the control.			Δ		5
Check economiser actuator operation	Check all fixings and transmission. Stop the unit using the control. The fresh air damper must closes. Start the unit the fresh air damper should open			Δ		5
Check refrigeration 4way valve	With the unit running in cooling mode increase the room set-point temperature by 10°C. The unit should switch to heat pump mode. Reset the control.			Δ		5
Check tightness of all electrical connections	Power down the unit and check and tighten all screws, terminal and electric connections, taking a particular attention to the power lines and low voltage control wires			Δ		30



TASK	OPERATING MODE	MONTHLY	QUARTERLY	6 MONTHLY	YEARLY B4 WINTER	ESTIMATED TIME (mn)
Check HP / LP safety switches	Install manifold gauges on the circuit to be checked. Shut down the axial fans and wait for the HP switch to shut down the compressor: 29bar (+1 / -0) auto-reset 22bar (+ - 0.7) Reconnect fans. Switch off the centrifugal supply fan and wait for the LP switch to cut out: 0.5bar (+ - 0.5) reset 1.5bar (+-0.5).			Δ		15
Check outdoor fans and fan guards	Check the fan blades conditions and all fan guards and protections				0	5
Check position of all sensors	Check the good positioning and operation of all sensors of all sensors. Check the values given in the control system. Replace sensor if necessary				0	5
Check and clean if necessary all fresh air grilles	Check the fresh air grilles (if fitted). If dirty or damaged, remove them from unit and clean with high pressure water cleaner. Refit on unit once clean and dry.				0	5
Check indoor and outdoor coils, clean if necessary	Visually check the coils for dirt. If not too dirty, cleaning with a light brush may be enough (WARNING: Fins and copper tubes are very fragile! Any damage WILL reduce the performances of the unit). If very dirty, deep industrial cleaning is required using de-greasing agents.(External contractors must be called).				0 / Δ	1h if cleaning 1h if replacement
Check electric heater element for excessive corrosion	Isolate the unit; Pull the electric heater out of the heater module box and check the resistances to traces of corrosion; Replace resistance as required;				0	1h if replacement
Check anti-vibration mountings, for wear and tear.	Visually check anti-vibration mountings on compressors and centrifugal fan. Replace if damaged.				0	1h if replacement
Check refrigeration circuit for traces of acid in the oil	Take a sample of oil from the refrigeration circuit.				Δ	
Check Glycol concentration in the HWC circuit	Check the glycol concentration in the pressurised water circuit. (a concentration of 30% gives a protection down to approx. -15°C) check the circuit pressure				Δ	30
Check defrost cycle with 4-way valve inversion.	Switch the unit to heat pump mode. Change the set point to obtain the standard defrost mode and reduce the cycle time to the min value. Check the operation of the defrost cycle.				Δ	30
Gas burner module check for corrosion	Pull out the burner to access the tubes (refer to Gas burner section in the IOM)				Δ	30
Sweeping and cleaning the gas burner	Clean the in-shot burners and the blower wheel lightly with a brush. Sweep the flue and flue box. Wipe-off the dust from the housing of the motor. Clean combustion air inlet louvers Pull-out baffles from the tubes, sweep the tubes CHECK FLUE BOX GASKET				Δ	30
Gas supply pressures / connections checks	refer to Gas burner section in the IOM for details				Δ	15
Gas regulation valve settings	refer to Gas burner section in the IOM for details				Δ	30
Check gas burner safety switches	refer to Gas burner section in the IOM for details				Δ	30



TERMS AND CONDITIONS

In the absence of any other written agreement, the guarantee shall only apply to design faults which occur within a 12 month period (warranty period).

The warranty period starts on the date of commissioning and at the latest six months after the delivery of the Rooftop.

ANTI-CORROSION WARRANTY

10 year warranty terms and conditions for corrosion to the Rooftop casing :

Lennox shall guarantee the casing of its Rooftop units manufactured since May 1991 against corrosion for 10 years commencing from the date of delivery of the material.

The warranty shall not apply in the following cases :

1. If the corrosion of the casing is caused by external damage to the protective layer such as scratches, projections, abrasion, impacts etc..
2. If the casing is not kept continually clean in the course of maintenance work or by a specialist company,
3. If the casing is not cleaned and maintained in accordance with regulations,
4. If the Rooftop units are installed on a site or in an environment which is known to be corrosive, unless a special protective coating has been applied by the owner for these applications, which has been recommended by a competent body not linked to the owner and after carrying out a study of the site.
5. Nevertheless the LENNOX coating is highly resistant to corrosion, the warranty will not be applied for rooftop installed at less than 1000m away from the sea.

Note : With the exception of the casing, the rest of the machine is covered by the warranty of our general terms of sale.

DO NOT CONFUSE THE WARRANTY WITH MAINTENANCE

The warranty will only apply if a maintenance contract has been signed, starting from the date of commissioning, and if the maintenance contract has actually been performed.

The maintenance contract must be made with a specialist, competent company.

The sole effect of any repair, modification or replacement of an item during the warranty period must be to extend the material's warranty period.

Maintenance must be carried out in accordance with regulations.

If a spare part is supplied after the expiry of the warranty period, it shall be guaranteed for a period equal to the initial warranty period and will be subject to the same conditions.

We recommend for a contract four inspections per year (every three months), before the start of each season, in order to check the operation of the equipment in the various operating modes.



CERTIFICATION



N° QUAL/2001/15834b

LENNOX FRANCE DIVISION DE LGL FRANCE

**CONCEPTION, FABRICATION ET CESSION INTERNE DE ROOF TOP
ET CENTRALES DE TRAITEMENT D'AIR.**

**DESIGN, MANUFACTURING AND INTERNAL TRANSFER OF ROOF TOP
AND AIR HANDLING UNITS.**

2, rue Lavoisier ZI de Longvic BP 60 F-21602 LONGVIC CEDEX

AFAQ certifie que pour les activités et les sites référencés ci-dessus toutes les dispositions mises en oeuvre pour répondre aux exigences requises par la norme internationale :
AFAQ certifies that all the arrangements covering the above mentioned activities and locations are established to meet the requirements of the international standard :

ISO 9001 : 2000

ont été examinées et jugées conformes.
have been examined and found conform.

2003-01-24

2006-01-23

(année/mois/jour)

Il est valable jusqu'au*
*It is valid until**

(year/month/day)

Le Président du Comité de certification
The President of the Certification Committee

C. GUERIN

Le Directeur Général d'AFAQ
The Managing Director of AFAQ

O. PEYRAT

Le Représentant de l'Entreprise
On Behalf of the Firm

E. MOUTON

*Sauf suspension notifiée entre temps par AFAQ à l'entreprise désignée ci-dessus. Le présent document n'a donc qu'une valeur indicative. Seule fait foi la base de données des certificats AFAQ accessible à l'adresse internet : <http://www.afaq.org>
L'organisation AFAQ est conforme aux normes internationales en vigueur (guide ISO/IEC 62 - norme EN 45012). Les accréditations détenues par AFAQ et ses filiales sont disponibles à l'adresse internet : <http://www.afaq.org/accreditations>
AFAQ se réserve le droit de modifier, à tout moment et sans préavis la forme de ce document de certification. Ce document, et notamment le logo y figurant, ne peut être utilisé par son titulaire que dans le respect des obligations légales et d'une communication claire et sincère.
**Excepting notification by AFAQ to the above-mentioned company of its suspension. This document is for information purposes only. For up-to-date information, the only official source is the AFAQ certificates database at <http://www.afaq.org>
The AFAQ organization complies with the international standards in force (ISO/IEC Guide 62 - EN 45012 standard). Information on the accreditations held by AFAQ and its subsidiaries is available at: <http://www.afaq.org/accreditations>
AFAQ reserves the right to modify, at anytime and without any notice, the shape of this certification document. This document and most specifically the logo featuring on this document can only be used by its holder in the frame respecting the legal requirements and a clear and sincere communication.*



Site Industriel de LONGVIC
ZI de LONGVIC – BP 60
21602 LONGVIC – France

Téléphone : +33 (0)3 80 77 41 41
Fax : +33 (0)3 80 66 66 35

DECLARATION DE CONFORMITE DU CONSTRUCTEUR
Conformément
à la Directive européenne « Equipement sous pression » 97/23/CE,

CE CONFORMITY DECLARATION
As defined by
« Pressure equipment » Directive 97/23/EC,

LGL France SA, ZI Les Meurières – 69780 Mions – France

La société soussignée certifie sous sa seule responsabilité que l'ensemble de nos fabrications de roof top désignés par les types suivants :

The company hereby declare, under its own responsibility, that the entire roof top range which designations are :

FCA FHA FGA FDA FCK FHK FGK FDK
FXA FXK
BCK BHK BGK BDK

Qui contiennent des fluides frigorigènes classés en groupe 2 (R22 et R407C),
Which are containing refrigerating fluids classified in group 2 (R22 et R407C),

Sont conformes aux dispositions de la Directive « Equipements sous pression », 97/23/CE
Is in compliance with the requirements of « Under pressure equipments » directive, 97/23/EC :

Catégorie *Category* : **II**

Module d'évaluation *Evaluation Module* : **D1**

Organisme notifié *Notified body* : **Bureau VERITAS**

17 bis, place des reflets – La DEFENSE 2 – 92400 Courbevoie.

Sont conformes aux dispositions de la Directive - *Are in compliance with the requirements of*
« Machines », 98/37/CE - « *Machinery* », 98/37/EC

« Basse Tension », 73/23/CEE modifiée - « *Low voltage* », 73/23/EEC amended

« CEM », 89/336/CEE - « *EMC* », 89/336/EEC

« Appareils à gaz », 90/396/CEE modifiée - « *Gas machines* », 90/396/EEC amended

Ces produits sont fournis avec un marquage de conformité .

The products are provided with a marking of conformity.

Date : 10 Mai 2004 / May 10th 2004

E. MOUTON
Directeur du site de Longvic


LENNOX France, Division climatisation de LGL France

Siège social : LGL France – ZI « Les Meurières » - BP71 – 69780 MIONS – France

Société anonyme au capital de 309.615.120F – RCS LYON B 309 528 115 – N° IDENTIFICATION TVA FR 59 309 528 115 – APE 292F



SÉCURITÉ FEU
Réaction au feu



PROCÈS-VERBAL DE CLASSEMENT DE RÉACTION AU FEU D'UN MATÉRIAU

Prévu à l'article 88 de l'Arrêté du Ministère de l'Intérieur du 30 juin 1983,
modifié par l'arrêté du 28 août 1991
Laboratoire pilote agréé du Ministère de l'Intérieur (arrêté du 05/02/59, modifié)

N° RA00-461

Valable 5 ans à compter du 17 octobre 2000

Matériau présenté par : La Société SAINT GOBAIN ISOVER FRANCE
Les Miroirs
18 avenue d'Alsace
92400 COURBEVOIE

Marque commerciale : CLIMAVER 202 - FIB-AIR ISOL

Description sommaire :
Feutre en laine de verre (fibres de verre liées par une résine thermodurcissable) revêtu sur une face d'une feuille d'aluminium renforcée d'une grille de verre. Le complexe aluminium est contrecollé à l'aide d'une colle polyéthylène.
Épaisseurs : 25 à 50 mm. Masse volumique nominale de la laine de verre : 30 kg/m³

Nature de l'essai : Essai par rayonnement avec joint simulé suivant avis CECMI en date du 08 avril 1993.
Mesure du Pouvoir Calorifique Supérieur

Classement :

MO

Durabilité du classement (Annexe 22) : Non limitée
compte tenu des critères résultant des essais décrits dans le rapport d'essais N° RA00-461 annexé.

Le classement indiqué ne préjuge pas de la conformité des matériaux commercialisés aux échantillons soumis aux essais et ne saurait en aucun cas être considéré comme un certificat de qualification tel que défini par la loi. Cette conformité peut être attestée par les certificats de qualification reconnus par le ministère chargé de l'industrie, et notamment par la marque NF - Réaction au Feu.

Champs/Marne le : 17 octobre 2000

Le technicien vérificateur

Bruce LE MADEC

Le Chef du laboratoire Réaction feu
responsable de l'essai

Martial BONHOMME

Sont seules autorisées les reproductions intégrales du présent procès-verbal de classement ou de l'ensemble procès-verbal de classement et rapport d'essais annexé.

PARIS - MARNE-LA-VALLÉE - GRENOBLE - NANTES - SOPHIA ANTIPOLIS
CENTRE SCIENTIFIQUE ET TECHNIQUE DU BÂTIMENT

84, avenue Jean-Jaurès - Champs-sur-Marne - BP 2 - F-77421 Marne-la-Vallée Cedex 2
Tél. : 01 64 68 84 12 - Fax : 01 64 68 84 79 - E-mail : reaction@cstb.fr - http://www.cstb.fr/feu

Certificat Certificate

CE 0049

(Directive 90/396/CEE « Appareils à gaz »)
(« Gas appliances » 90/396 EEC Directive)

Numéro : **49AR1675** (rév. 6)

AFNOR CERTIFICATION, après examen et vérifications, certifie que l'appareil :
AFNOR CERTIFICATION, after examination and verifications, certifies that the appliance:

- **Fabriqué par :**
Manufactured by **LENNOX FRANCE**
Z.I. LONGVIC
BP 60
F-21602 LONGVIC CEDEX
- **Marque commerciale et modèle(s) :**
Trade mark and model(s) : **LENNOX**
➤ **GM 060/2**
- **Genre de l'appareil :**
Kind of the appliance : **MODULE DE CHAUFFAGE POUR**
CLIMATISEURS DE TOITURE
GAS AIR HEATER UNIT FOR ROOF TOP
- **Désignation du type :**
Type designation: **GM 060/2**

Pays de destination <i>Destination countries</i>	Pressions (mbar) <i>Pressures (mbar)</i>	Catégories <i>Categories</i>
FR	20/25 ; 37	I12Er3P
BE	20/25 ; 37	I2EB ; I3P
PT-CH-ES-GB	20 ; 37	I12H3P
DE	20 ; 50	I2E ; I3P
IT	20	I2H
NL	25 ; 37-50	I12L3P

est conforme aux exigences essentielles de la directive "Appareils à gaz" 90/396/CEE (29/06/1990).
is in conformity with the essential requirements of the "Gas appliances" directive 90/396/EEC (29/06/1990).

AFNOR CERTIFICATION
Le Directeur Exécutif


Jacques BESLIN



Paris le : 27 mars 2002

Rév. 6 : 49AR1675 du 96/09/02

11 avenue Francis de Pressensé - 93571 Saint-Denis La Plaine Cedex - France

Tél. : +33 (0)1 41 62 76 60 - Fax : +33 (0)1 49 17 91 91

certification@afnor.fr

www.afnor.fr - www.marque-nf.com



AFNOR CERTIFICATION

Certificat Certificate

CE 0049

(Directive 90/396/CEE « Appareils à gaz »)
(« Gas appliances » 90/396 EEC Directive)

Numéro : **49AR1860** (rév. 6)

AFNOR CERTIFICATION, après examen et vérifications, certifie que l'appareil :
AFNOR CERTIFICATION, after examination and verifications, certifies that the appliance:

- **Fabriqué par :**
Manufactured by **LENNOX FRANCE**
Z.I. LONGVIC
BP 60
F-21602 LONGVIC CEDEX
- **Marque commerciale et modèle(s) :**
Trade mark and model(s) : **LENNOX**
➤ **GM 120/2**
- **Genre de l'appareil :**
Kind of the appliance : **MODULE DE CHAUFFAGE POUR**
CLIMATISEURS DE TOITURE
GAS AIR HEATER UNIT FOR ROOF TOP
- **Désignation du type :**
Type designation: **GM 120/2**

Pays de destination <i>Destination countries</i>	Pressions (mbar) <i>Pressures (mbar)</i>	Catégories <i>Categories</i>
FR	20/25 ; 37	I12Er3P
BE	20/25 ; 37	I2EB ; I3P
PT-CH-ES-GB	20 ; 37	I12H3P
DE	20 ; 50	I2E ; I3P
IT	20	I2H
NL	25 ; 37-50	I12L3P

est conforme aux exigences essentielles de la directive "Appareils à gaz" 90/396/CEE (29/06/1990).
is in conformity with the essential requirements of the "Gas appliances" directive 90/396/EEC (29/06/1990).

AFNOR CERTIFICATION
Le Directeur Exécutif


Jacques BESLIN



Paris le : 27 mars 2002



Rév. 6 : 49AR1860 du 96/09/02

11 avenue Francis de Pressensé - 93571 Saint-Denis La Plaine Cedex - France

Tél. : +33 (0)1 41 62 76 60 - Fax : +33 (0)1 49 17 91 91

certification@afnor.fr

www.afnor.fr - www.marque-nf.com

Certificat

Certificate

CE

0049

(Directive 90/396/CEE « Appareils à gaz »)
 (« Gas appliances » 90/396 EEC Directive)

Numéro : **49BL3276** (rév. 1)


AFNOR CERTIFICATION, après examen et vérifications, certifie que l'appareil :
 AFNOR CERTIFICATION, after examination and verifications, certifies that the appliance:

- **Fabriqué par :** **LENNOX FRANCE**
Manufactured by **Z.I. LONGVIC**
BP 60
F-21602 LONGVIC CEDEX
- **Marque commerciale et modèle(s) :** **LENNOX**
Trade mark and model(s) : **> GM 180/4**
- **Genre de l'appareil :** **MODULE DE CHAUFFAGE POUR**
Kind of the appliance : **CLIMATISEURS DE TOITURE**
GAS AIR HEATER UNIT FOR ROOF TOP
- **Désignation du type :** **GM 180/4**
Type designation:

Pays de destination <i>Destination countries</i>	Pressions (mbar) <i>Pressures (mbar)</i>	Catégories <i>Categories</i>
FR	20/25 ; 37	I12Er3P
BE	20/25 ; 37	I2EB ; I3P
PT-CH-ES-GB	20 ; 37	I12H3P
DE	20 ; 50	I2E ; I3P
IT	20	I2H
NL	25 ; 37-50	I12L3P

est conforme aux exigences essentielles de la directive "Appareils à gaz" 90/396/CEE (29/06/1990).
 is in conformity with the essential requirements of the "Gas appliances" directive 90/396/EEC (29/06/1990).

AFNOR CERTIFICATION
 Le Directeur Exécutif



Jacques BESLIN



Paris le : 27 mars 2002



Rév. 1 : 49BL3276 du 2000/06/30

11 avenue Francis de Pressensé - 93571 Saint-Denis La Plaine Cedex - France
 Tél. : +33 (0)1 41 62 76 60 - Fax : +33 (0)1 49 17 91 91
 certification@afnor.fr
 www.afnor.fr - www.marque-nf.com



Organisme certificateur
AFNOR CERTIFICATION
11, avenue Francis de Pressensé
93571 SAINT-DENIS LA PLAINE Cedex
☎ : (33) 1.47.62.76.60 - Fax : (33) 1.49.17.91.91
Site Internet : <http://www.marque-nf.com>

Marque NF – Matériels de Détection Incendie



Organisme mandaté
Comité National Malveillance Incendie Sécurité SAS
C.N.M.I.S. SAS - 16, avenue Hoche - 75008 PARIS
☎ : (33) 1.53.89.00.40 - Fax : (33) 1.45.63.40.63
Site Internet : <http://www.cnmis.org>

**CERTIFICAT DE DROIT D'USAGE DE LA MARQUE NF
(LICENCE)**

N° DROIT D'USAGE
DAD 020 B0

La Société : **ANELEC**
Pour son usine de
**37, place de Loire SILIC 139
94523 RUNGIS Cedex**

Correspondant C.N.M.I.S SAS
José CAMPO Tél : **01 53 89 00 48**
Fax : **01 45 63 40 63**

Date de fin de validité :
31/03/2004

N° Dossier C.N.M.I.S SAS
99 06 55
Conformité aux normes :
**NF S 61-950 de Novembre 1985
NF S 61-961 de Septembre 1989**

MODIFICATIONS

Est autorisée à apposer la marque NF sur le matériel désigné ci-après :

Désignation technique du matériel : **Détecteur Autonome Déclencheur**
Désignation commerciale : **DAD 4480 CGDI**
Caractéristiques certifiées : **Type 2**
Nombre de détecteurs : **2**
(Les autres caractéristiques sont reprises dans les rapports d'essai)
Ce matériel fonctionne avec : **Le détecteur SIJ-EF (E4 064 B0)**
(Les autres produits associés sont repris dans les certificats d'association)
Références et date des rapports d'essais : **DH 95 01 11 du 14 Mars 1996**
Fonctions supplémentaires : **Voir rapports référencés ci-dessus**

N.B : Cette décision dispense le titulaire de la présentation des Procès Verbaux d'essai (incluant les rapports d'essais) de conformité aux normes du matériel ci-dessus.

PARIS, le 14 février 2003
Par mandat d'AFNOR CERTIFICATION
Le C.N.M.I.S. S.A.S

Le Directeur Général
Denis CLUZEL



ACCREDITATION N° 5-0015

Ce certificat annule et remplace tout certificat antérieur, sa date de validité est confirmée sous réserve des contrôles effectués par AFNOR CERTIFICATION et/ou le C.N.M.I.S. SAS qui peuvent prendre toute sanction conformément aux Règles Générales de la marque NF et au Règlement R075. Ce certificat atteste que les produits désignés sont certifiés conformes au référentiel technique du Règlement R075 et que le système qualité de la société a été évalué selon ce même Règlement. Il n'engage en aucun cas AFNOR CERTIFICATION et le C.N.M.I.S. SAS quant à la conformité réglementaire de l'installation dans laquelle les produits objets de ce certificat seront utilisés.

13/06 2003 VEN 14:51 FAX

002/002



Organisme certificateur
AFNOR CERTIFICATION
11, avenue Francis de Pressat
93571 SAINT-DENIS LA PLAINE Cedex
☎ : (33) 1.47.62.76.60 • Fax : (33) 1.49.17.91.91
Site Internet : <http://www.marque-nf.com>

Marque NF – Matériels de Détection Incendie



LA SECURITE CERTIFIEE
Organisme mandaté
Comité National Matériels Incendie Sécurité SAS
C.N.M.I.S. SAS - 16, avenue Hoche - 75008 PARIS
☎ : (33) 1.53.89.00.40 - Fax : (33) 1.45.63.40.63
Site Internet : <http://www.cnmis.org>

CERTIFICAT DE DROIT D'USAGE DE LA MARQUE NF (LICENCE)

N° DROIT D'USAGE	
DAD 013 J0	Le 27/05/2003

La Société : **FINSECUR**
Pour son usine de **15, rue du Général Négrier**
78800 HOUILLES

Correspondant C.N.M.I.S. SAS	
José CAMPO	Tél : 01 53 89 00 48
	Fax : 01 45 63 40 63

Date de fin de validité : 31/03/2004

N° Dossier C.N.M.I.S. SAS 03 03 18
Conformité aux normes : NF S 61-961 de Septembre 2000

MODIFICATIONS

Est autorisée à apposer la marque NF sur le matériel désigné ci-après :

Désignation technique du matériel : **Détecteur Autonome Déclencheur**
Désignation commerciale : **LOTUS 1 W2C**
Caractéristiques certifiées : **Type II**
Elément sensible : **2 TYPE E4**
(Les autres caractéristiques sont reprises dans les rapports d'essai)
Ce matériel fonctionne avec : **Voir liste des matériels associés**
Références et date des rapports d'essais : **DH 03 01 76 du 14 Mai 2003 (Fiche Technique N° 1441)**
Fonctions supplémentaires : **Voir rapports:référéncés ci-dessus**

N.B : Cette décision dispense le titulaire de la présentation des Procès Verbaux d'essai (Incluant les rapports d'essais) de conformité aux normes du matériel ci-dessus.

PARIS, le 11 juin 2003
Par mandat d'AFNOR CERTIFICATION
Le C.N.M.I.S. S.A.S

Le Directeur Général
Denis CLUZEL



LA SECURITE CERTIFIEE


Ce certificat annule et remplace tout certificat antérieur, sa date de validité est confirmée sous réserve des contrôles effectués par AFNOR CERTIFICATION et/ou le C.N.M.I.S. SAS qui peuvent prendre toute sanction conformément aux Règles Générales de la marque NF et au Règlement R075. Ce certificat atteste que les produits désignés sont certifiés conformes au référentiel technique du Règlement R075 et que le système qualité de la société a été évalué selon ce même Règlement. Il n'engage en aucun cas AFNOR CERTIFICATION et le C.N.M.I.S. SAS quant à la conformité réglementaire de l'installation dans laquelle les produits objets de ce certificat seront utilisés.



ACCREDITATION N° 1-0118



SÉCURITÉ FEU
Réaction au feu



PROCÈS-VERBAL DE CLASSEMENT DE RÉACTION AU FEU D'UN MATÉRIAU

Prévu à l'article 88 de l'Arrêté du Ministère de l'Intérieur du 30 juin 1983,
modifié par l'arrêté du 28 août 1991
Laboratoire pilote agréé du Ministère de l'Intérieur (arrêté du 05/02/59, modifié)

N° RA01-279

Valable 5 ans à compter du 26 juin 2001

Matériau présenté par : La Société CAMFIL FARR
Route d'Avrigny
ZI Saint Martin Longueau
60722 PONT SAINTE MAXENCE

Marque commerciale : A300F1

Description sommaire :
Média filtrant 100% fibres polyester non ignifugé.
Masse surfacique nominale : 198 g/m². Épaisseur nominale : 20 mm. Coloris : Blanc

Nature de l'essai : Essai au Brûleur Électrique
Essais Complémentaires

Classement :

M1

Durabilité du classement (Annexe 22) : Non limitée a priori (Filtre non régénérable)
compte tenu des critères résultant des essais décrits dans le rapport d'essais N° RA01-279 annexé.

Le classement indiqué ne préjuge pas de la conformité des matériaux commercialisés aux échantillons soumis aux essais et ne saurait en aucun cas être considéré comme un certificat de qualification tel que défini par la loi. Cette conformité peut être attestée par les certificats de qualification reconnus par le ministère chargé de l'Industrie, et notamment par la marque NF - Réaction au Feu.

Champs/Marne le : 26 juin 2001

Le technicien responsable de l'essai

Nicolas ROURE

Le chef du laboratoire Réaction au Feu

Martial BONHOMME

Sont seules autorisées les reproductions intégrales du présent procès-verbal de classement ou de l'ensemble procès-verbal de classement et rapport d'essais annexé.

PARIS - MARNE-LA-VALLÉE - GRENOBLE - NANTES - SOPHIA ANTIPOLIS
CENTRE SCIENTIFIQUE ET TECHNIQUE DU BÂTIMENT

84, avenue Jean-Jaurès - Champs-sur-Marne - BP 2 - F-77421 Marne-la-Vallée Cedex 2
Tél. : 01 64 68 84 12 - Fax : 01 64 68 84 79 - E-mail : reaction@cstb.fr - http://www.cstb.fr/feu



SÉCURITÉ FEU
Réaction au feu

Accréditation
n° 1-0300



PROCÈS-VERBAL DE CLASSEMENT DE RÉACTION AU FEU D'UN MATÉRIAU

Prévu à l'article 88 de l'Arrêté du Ministère de l'Intérieur du 30 juin 1983,
modifié par l'arrêté du 28 août 1991
Laboratoire pilote agréé du Ministère de l'Intérieur (arrêté du 05/02/59, modifié)

N° RA01-065

Valable 5 ans à compter du 25 janvier 2001

Matériau présenté par : La Société HOLLINGSWORTH and VOSE Compagny LTD
Postlip mills - Winchcombe
GLOS GL54 5BB
ROYAUME UNI

Marque commerciale : MEDIA A100G

Description sommaire :
Média filtrant en fibres de verre non tissées liées par une résine acrylique.
Masse surfacique nominale : 63 g/m². Épaisseur nominale : 0,47 mm. Coloris présenté :
blanc.

Nature de l'essai : Essai au Brûleur Électrique

Classement :

M3

Durabilité du classement (Annexe 22) : Non limitée a priori Article non régénérable
compte tenu des critères résultant des essais décrits dans le rapport d'essais N° RA01-065 annexé.

Le classement indiqué ne préjuge pas de la conformité des matériaux commercialisés aux échantillons soumis aux essais et ne saurait en aucun cas être considéré comme un certificat de qualification tel que défini par la loi. Cette conformité peut être attestée par les certificats de qualification reconnus par le ministère chargé de l'Industrie, et notamment par la marque NF - Réaction au Feu.

Champs/Marne le : 25 janvier 2001

Le technicien responsable de l'essai

Le chef du laboratoire Réaction au Feu

David BETTOIA

Martial BONHOMME

Sont seules autorisées les reproductions intégrales du présent procès-verbal de classement ou de l'ensemble procès-verbal de classement et rapport d'essais annexé.

PARIS - MARNE-LA-VALLÉE - GRENOBLE - NANTES - SOPHIA ANTIPOLIS
CENTRE SCIENTIFIQUE ET TECHNIQUE DU BÂTIMENT

84, avenue Jean-Jaurès - Champs-sur-Marne - BP 2 - F-77421 Marne-la-Vallée Cedex 2
Tél. : 01 64 68 84 12 - Fax : 01 64 68 34 79 - E-mail : reaction@csfb.fr - http://www.csfb.fr/feu

BELGIUM,
LUXEMBOURG : LENNOX BENELUX N.V./S.A.
tel. : + 32 3 633 30 45
fax : + 32 3 633 00 89
e-mail : info.be@lennoxbenelux.com

CZECH REPUBLIC : JANKA LENNOX a.s.
tel. : + 420 2 510 88 111
fax : + 420 2 579 10 393
e-mail : janka@janka.cz

FRANCE : LENNOX FRANCE
tel. : + 33 1 64 76 23 23
fax : + 33 1 64 76 35 75
e-mail : marketing.france@lennoxfrance.com

GERMANY : LENNOX DEUTSCHLAND GmbH
tel. : + 49 69 42 09790
fax : + 49 69 42 09 79 40
e-mail : info.de@lennoxdeutschland.com

NETHERLANDS : LENNOX BENELUX B.V.
tel. : + 31 33 2471 800
fax : + 31 33 2459 220
e-mail : info@lennoxbenelux.com

POLAND : LENNOX POLSKA Sp. z o.o.
tel. : + 48 22 832 26 61
fax : + 48 22 832 26 62
e-mail : info@lennoxpolska.pl

PORTUGAL : LENNOX PORTUGAL LDA.
tel. : +351 22 90 66 050
fax : +351 22 90 66 059
e-mail : info@lennoxportugal.com

RUSSIA : LENNOX DISTRIBUTION MOSCOW
tel. : + 7 095 246 07 46
fax : + 7 502 933 29 55
e-mail : lennox.dist.moscow@netmaster.ru

SLOVAKIA : LENNOX SLOVENSKO s.r.o.
tel. : + 421 2 44 87 19 27
fax : + 421 2 44 88 64 72
e-mail : lennox.slovensko@lennox.sk

SPAIN : LENNOX REFAC S.A.
tel. : + 34 915 40 18 10
fax : + 34 915 42 84 04
e-mail : marketing@lennox-refac.com

UKRAINE : LENNOX DISTRIBUTION KIEV
tel. : + 380 44 213 14 21
fax : + 380 44 213 14 21
e-mail : jankauk@uct.kiev.ua

UNITED KINGDOM,
IRELAND : LENNOX INDUSTRIES LTD
tél. : + 44 1604 599400
fax : + 44 1604 594200
e-mail : ukmarketing@lennoxind.com

OTHER EUROPEAN COUNTRIES,
AFRICA,
MIDDLE-EAST : LENNOX DISTRIBUTION
tel. : + 33 4 72 23 20 14
fax : + 33 4 72 23 20 28
e-mail : marketing@lennoxdist.com



LENNOX®

www.lennox europe.com

FLEXY-IOM-0704-E

Due to Lennox's ongoing commitment to quality, Specifications, Ratings and Dimensions subject to change without notice and without incurring liability. Improper installation, adjustment, alteration, service or maintenance can cause property damage or personal injury. Installation and service must be performed by a qualified installer and servicing agency.