




CODE	LO	
DIAGNOSTIC	Room temperature lower than 8° C	
EFFECT	Only alarm indication, unit does not stop Unit would operate on these conditions only for short periods of time	
RESET	AUTOMATICALLY	
CHECK	Sensor values (relationship temperature-resistance), sensor position and air distribution	
CODE	HI	
DIAGNOSTIC	Room temperature higher than 37° C	
EFFECT	Only alarm indication, unit does not stop Unit would operate on these conditions only for short periods of time	
RESET	AUTOMATICALLY	
CHECK	Sensor values (relationship temperature-resistance), sensor position and air distribution	

CODE	EOP	
DIAGNOSTIC	The white wire that connects the terminal to the power board, terminal TX, is not connected.	
EFFECT	Only alarm indication, unit does not stop There is not communication between terminal and power board Modifications introduced on terminal will not be read by power board	
RESET	AUTOMATICALLY	
CHECK	Connection of white wire to terminal TX Check for possible loose connection, cable breakage	