



DP	Presostato diferencial aire	Air pressure diferencial Switch	K	Contactora	Contactora
EH	Batería eléctrica	Electrical Heater	MT	Termostato de seguridad	Safety Thermostat
F7	Fusibles	Fuses	OT	Sonda Exterior	Outdoor Sensor
F20	Magnetotérmico	Circuitbreaker	R	Relé auxiliar	Auxiliary Relay
Q	Interruptor General	Main Switch	RC	Control Remoto	Remote Control
*1	R6 en LVHA/K 44D-48D-56D-64D-76D-86D KNHK		*2	K2 en LVHA/K 44D-48D-56D-64D-76D-86D KNHK	
	R7 en LVHA/K 100D			K3 en LVHA/K 100D	

Lennox Refac S.A.	ESQUEMA ELECTRICO ELECTRIC DIAGRAM	<b>BATERIA ELECTRICA</b> <b>LVHK/ANHK 44D...100D</b>	4Z-33-489-528 25F 3 ~400V 50HZ + PE
-------------------	---------------------------------------	---	--